


Worship System Installation



To set up the Worship Communication System:

1. Remove all components from the box.
2. Connect power to FM +Transmitter, Wireless Access Point, Router, and POE Injector.
3. Connect a Cat5e cable from the **Power Over Ethernet (POE) Injector In Port** on the Wireless Access Point to **Data Out Port** of the POE Injector.
4. Connect a Cat5e cable from **Data In Port** on the POE Injector to the **LAN 1 Port** on the Router.
5. Connect Cat5e cable from **LAN 2 Port** of the Router to the **Ethernet Port** on the FM+.
6. Use the provided bracket to attach the Wireless Access Point onto the folding stand.
7. Adjust the folding stand to the tallest setting.
8. Follow instructions for setting up your FM + system and wireless network.

To listen to WaveCAST Audio on Personal Devices:

1. Listeners will need to download the WaveCAST App to their personal device from the Apple App Store or Google Play Store (App is iOS and Android compatible)
2. On a personal device with the WaveCAST App installed, join the worship communications system's WaveCAST Wi-fi Network.
3. Tap on the WaveCAST Audio Receiver app on the personal device and select a channel to listen to the audio.

If personal devices are not available, distribute FM or WaveCAST Receivers (purchased separately) and select a channel to listen to the audio.