Dewey the Document Camera Stand - Assembly Guide



Assembly Guide DCS5_DCS5A_DCS6_2015_B

Check out our other products online at **www.copernicused.com**

For assistance, please contact us:

1-800-267-8494


Email info@copernicused.com

Have your packing slip ready for reference

WARNING

- This product is meant to be assembled by an adult.
- In its unassembled state, small parts present a hazard.
- To be used under direct supervision of an adult.

Patent Pending





205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com

Check out some of our other great products!



www.copernicused.com

Need Tech Support? Have a Question?



Email our Tech Support Service

iPad® not included.

Document Camera and Microscope Function only works with most Smartphones iPad mini™, iPad 2™ & Newer.





Warning! Hazard Risks!

Please read the warnings below for important safety information regarding your product. Failure to read these warnings or to follow the instructions below could result in personal injury or damage to your product that could void your warranty.



Small Parts In its unassembled state, this product contains parts that can be hazardous to small children. This product should be assembled by an adult.



This product is to be used under the supervision of an adult.



Only

This product is intended for indoor use only. To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. The internal components are not sealed from the environment.



Powerbar Specifications Read your powerbar's electrical specifications. Only plug in devices that are approved for use with this powerbar. Connect the supplied power bar directly to a wall outlet. **Do not connect to another power bar or use an extension cord.** Unplug when not in use.



Read the electrical specifications of any electronic equipment you are using with your Copernicus products. Failure to read these specifications and follow their instructions could result in damage to your equipment or personal injury.



Ensure that any cables extending across the floor to your product are properly bundled and marked to avoid tripping or falling which may lead to personal injury.



Do not install or use the electrical components of this unit during a lightning storm.



Do not climb on, hang from or suspend objects from any components of your product unless otherwise specified.



Tips for Assembly



Watch for These Helpful Symbols

 This symbol denotes a 2 Person Task. For safety, please ensure that there are two people working on steps displaying this symbol



 Watch for this symbol throughout the Assembly Instructions. Wherever you see it, pay close attention. The symbol denotes a step needing extra attention to ensure it is done correctly.



The Star symbol highlights an advisory note

Before You Begin



- Layout and identify all of the included parts
- The hardware has been packed by step
- Read the assembly instructions over once to familiarize yourself with them
- Please note that in its unassembled state, this product contains parts that can be a hazard to small children; it should be assembled by an adult.



As You Assemble the Unit

- Follow the steps in sequence
- Before beginning each step, find the part(s) that you need for that step
- Pay attention to the labeling on the parts, they are there to help direct you at certain stages
- The title of each step states what you will be doing. Review the text and the pictures as you build the unit.



Validate Your Warranty On-Line

To validate your warranty submit the ON-LINE form at www.copernicused.com


"The beautiful thing about learning is that no one can take it away from you." - B. B. King



Dewey the Document Camera Stand - Assembly Guide




Please note that in its unassembled state, this product contains parts that can be hazardous to small children. This product should be assembled by an adult.







Dewey - Parts

Before beginning, you should have:









3A

Actual Size:




M6 Lock Nylon Washer 2x



M6 Knob **1x**

You will need: (Not to Scale)


FOR DCS5 and DCS5A ONLY



Attach Adjustment Lip and Knob to Top Arm Pre-Assembly.

Place threaded post on Adjustment Lip through hole.

Tighten knob.



3B

Actual Size:



M6 Lock Nylon Washer



E M6 Knob

You will need: (Not to Scale)

FOR DCS6 ONLY

Dewey Microscope Assembly 1x

DCS5_DCS5A_DCS6 - Version B - 27 January 2015 - Copernicus Educational Products Inc.


Adjustment Lip

1x


Attach Microscope Assembly to Top Arm Pre-Assembly.

Place threaded post on Adjustment Lip through hole and Microscope Arm. Tighten knob.





adapter cable and then loop over the edge of the top mechanism.









Actual Size:

You will need: (Not to Scale)

OPTIONAL -DCS5A/DCS6





Positioning the Magnetic LED Light (OPTIONAL DCS5A and DCS6)


Use the magnet on the LED to attach it anywhere on Dewey's Neck.



Suggested spots to mount the Magnetic LED Light without getting hot spots.








FOR DCS6 ONLY

When using the Microscope Assembly (DCS6) here are suggested locations for the LED to be mounted.



Tablet + Microscope Assembly

Smartphone + Microscope Assembly








Dewey the Document Camera Stand - Tips for Use

To Change Projected Image

Holding onto top mechanism - turn iPad® 90 degrees








If swivel tension ever

needs to be tighter, tighten this nut with 10mm wrench. Landscape Position

NOTE: Sometimes when you rotate the iPad® your projected image does not rotate, in that case you need to tilt down the top mechanism to allow the iPad® to adjust




Securing Dewey to a Surface

Mount Dewey to a surface using the holes on the base.



The holes are made for 1/4" or M6 bolts/screws.

The length of your hardware depends on your surface thickness.







Dewey - Tips for Use

Using Dewey with 10" iPad®











Loosen the Adjustment Lip Knob to slide the bottom lip out into the maximum position and tighten.

Using Dewey with iPad mini™












Using Dewey with Smartphones










Smartphones must be used with Dewey in the Landscape position.






Dewey - Tips for Use with Microscope Assembly

Microscope Assembly adjustments with Smartphones



Loosen knob first to allow you to move Arm in and out to help position specimen under camera(•). Tighten knob.



Arm, Lens and Stage can also swivel independently to help position specimen in view of camera(•).




To switch from using Magnifying Arm with Smart Phone to iPad®:


Loosen knob slightly

Swing arm around to desired location


Tighten knob



Magnifier Arm adjustments with iPad®



Loosen knob first to allow you to move Arm in and out to help position specimen under camera(•). Tighten knob.



Arm, Lens and Stage can also swivel to help position specimen in view of camera(•).





Dewey the Document Camera Stand - Tips for Use

Connecting to Your Projector


For iPad mini™, iPad 2™ or newer only:

Use Apple® VGA Adapter and a VGA cord (with two VGA male outlets) to connect projector to the iPad®.

OR Use Apple TV® to Connect wirelessly!

For Smartphones:

Use apps such as AllCast, Reflector or purchase a micro-USB to HDMI adapter.



To hold the VGA cable in place use provided VGA Strap

- Tie the strap around the VGA cable and then loop over the edge of the top mechanism.

Supported Paper Size

The Document Camera Stand covers surfaces from 13.25 x 10.0" up to 20.63" x 15.31" at different hole positions.

NOTE: The provided template is for positioning 8.5" x 11" paper.



Suggested Apps

Smartphones, iPad mini™, iPad 2™ Or Newer:





AllCast

Board Cam

This app allows you to write on top of your image that you are projecting.



Reflector

This app lets you send photos, music, and videos on your Android to your TV! You can cast to: Chromecast, Amazon Fire TV, Apple TV, Roku, WDTV, Samsung, Sony and Panasonic Smart Tvs



Mirror your device on a big screen without wires or complicated setups. Play games, watch movies, demo apps or present on the big screen from your iPhone or iPad.



Educreations

This app turns your iPad into a recordable whiteboard. It allows you to create a video tutorial. It has voice recording, realistic digital ink, photo imports, and simple sharing features.



Nearpod Student & Teacher Version This app enables teachers to use their iPads to manage content on student's iPads.

Teachers version manages students content and flow of lecture.

Students version receives content, participate in activities and submit responses.


NOTE: If the screen of your iPad® turns off while in use, adjust sleep mode time by going to Setting>General>Auto-Lock. And when you are not using your device put it into sleep mode.





Dewey the Document Camera Stand - Tips for Use

Basic Usage Tips




2. Place your iPad® into the stand. (See point 3 & 4)



*


If your case has a flip cover, make sure it's open to the side.




4. Place your iPad® or iPad mini™ into the top mechanism




G




6. Use Apple® VGA Adapter to connect your iPad® to your projector




Use the provided VGA Strap to hold your VGA Adapter in place and stop it from being disconnected






Hold on to the stand's neck to prevent any sudden drops

8. The Provided template helps locate your 8.5" x 11" paper without looking through the camera. (Optional)






9. By rotating the top mechanism 90 degrees, change between landscape and portrait projection.





10. By tilting down the top mechanism, switch between document camera and stand position.







Dewey the Document Camera Stand - Assembly Guide



Assembly Guide DCS5_DCS5A_DCS6_2015_B

Check out our other products online at **www.copernicused.com**

For assistance, please contact us:

1-800-267-8494

Email info@copernicused.com

Have your packing slip ready for reference

Dear Educator,

Thank you for purchasing one of our products.

I hope the assembly of your **Dewey - the Document Camera Stand** went well.

If you have any questions, or concerns, or ideas for how we can improve, please call us at 1-800-267-8494, where someone will be happy to help.

Enjoy using your new product, and happy teaching,

Jim Phillips President





205 Westwood Ave, Long Branch, NJ 07740 Phone: 866-94 BOARDS (26273) / (732)-222-1511 Fax: (732)-222-7088 | E-mail: sales@touchboards.com

Quality schools are the result of quality teachers going above and beyond the call of duty.

VICKI CARUANA

In everyone's life at some time our inner fire goes out. It is then burst into flame by an encounter with another human being. We should all be thankful for those people who rekindle the inner spirit.

ALBERT SCHWEITZER

My idea of education is to unsettle the minds of the young and inflame their intellects.

> ROBERT MAYNARD HUTCHINS

Nothing has a better effect upon children than praise.

SIR PHILLIP SIDNEY

