



## Please follow these care and cleaning instructions for our clear dry-erase products:

For best results and to prevent your acrylic from damage such as warping, scratching and clouding, follow these cleaning instructions:

- Never use any kind of glass cleaner or anything containing ammonia, abrasives, alcohol or bleach.
- Use soap and water or an acrylic cleaner (like Brillianize or Plaskolite Plastic Cleaner) to wipe down the surface.
- Use a lint-free microfiber cloth to prevent scratching (DO NOT use paper towels, they can leave scratches).
- Do not aggressively rub down the acrylic as this can cause scratches.
- Use the dry side of the cloth to buff the acrylic. This will allow for more time between cleanings and reduces the risk of future stains.
- Use only water-soluble dry-erase markers

Our warranty is only valid if these proper care and cleaning guidelines are followed.