

Packing List

The following items are included:



DT50

Spanner 1 unit

0033504-080424

JBC

www.jbctools.com

INSTRUCTION MANUAL



DT50

Spanner
for D530 Tip Range

Features

DT50 is a spanner that allows the user to safely insert, remove and store tips from DT530 Desoldering Iron even when they are hot.

It works with D530 Tip Range. Different tip sizes are available for through-hole desoldering and for pad cleaning. Find the model that best suits your soldering needs at: www.jbctools.com

Through-Hole
Desoldering



Pad Cleaning



D530

Tip Range

(not included)



www.jbctools.com




Changing Tips


This operation should be done while the tip is hot and at a minimum temperature of 250 °C, so that any tin left inside is still molten, facilitating the removal of the tip.

Removing

Use JBC's spanner to unscrew the tip (1). The tip will remain attached to the spanner so that it can be moved safely.



To remove the tip from the spanner, simply place the tip in one of the holes on the stand (2), screw it in slightly (3) and pull the spanner out.



Inserting

Grab the new tip with the spanner. Fit it into the heating element (4) and screw it in with the spanner (5). Screw the tip all the way in so that the union is air-tight.

