

Network Time Machine

Quick Start Guide: Portable 1.2 Model

Your Network Time Machine (NTM) comes with the software already installed and licensed. After you have unpacked it from its shipping container, proceed as follows:

1. Connect cables as shown in the figure below.
2. Turn on the AC power and wait for the computer to boot up. The power switch is located in the upper right hand corner when facing the rear of the computer.
3. Start the NTM application by selecting **Start > All Programs > ClearSight > ClearSight Network Time Machine**.
4. When the Login screen appears, click **OK**. No password is needed.

Connect one of these Ethernet ports to your control network for remote operation of this NTM using Remote Desktop.

Connect these Ethernet ports to the network(s) from which you want to monitor, capture frames, and perform analysis.



Connect a USB keyboard and mouse here.

Connect the power cable here.



Contacting Fluke Networks



www.flukenetworks.com



support@flukenetworks.com



+1-425-446-4519

- Australia: 61 (2) 8850-3333 or 61 (3) 9329 0244
- Beijing: 86 (10) 6512-3435
- Brazil: 11 3759 7600
- Canada: 1-800-363-5853
- Europe: +31-(0) 40 2675 600
- Hong Kong: 852 2721-3228
- Japan: 03-6714-3117
- Korea: 82 2 539-6311
- Singapore: 65-6799-5566
- Taiwan: (886) 2-227-83199
- USA: 1-800-283-5853
- Anywhere in the world: +1-425-446-4519

Visit our website for a complete list of phone numbers.

Tequipment
_____.NET



205 Westwood Ave
Long Branch, NJ 07740
1-877-742-TEST (8378)
Fax: (732) 222-7088
salesteam@Tequipment.NET