

Network Time Machine

Quick Start Guide: Express 3 Model

Your Network Time Machine (NTM) comes with the software already installed and licensed. After you have unpacked it from its shipping container, proceed as follows:

1. Install the NTM in a 19-inch rack.
2. Connect cables as shown in the figure below.
3. Turn on the AC power and wait for the server to boot up.
4. When the Windows 2008 Server login screen appears, login with username **operator** and password **ClearSight1**.
5. Start the NTM application by selecting **Start > All Programs > ClearSight Distributed > ClearSight Network Time Machine Distributed Agent Manager**.
6. After it launches, add the Agent:
 - Host: **localhost**
 - Username: **Admin**
 - Password: (leave blank)
7. Connect to the Agent.



Connect these Ethernet ports to the network(s) from which you want to monitor, capture frames, and perform analysis.

Connect a monitor here.

Connect a USB keyboard and mouse here.

Connect one of these Ethernet ports to your control network for remote operation of this NTM.

Connect the power cables here.

Contacting Fluke Networks



www.flukenetworks.com



support@flukenetworks.com



+1-425-446-4519

- Australia: 61 (2) 8850-3333 or 61 (3) 9329 0244
- Beijing: 86 (10) 6512-3435
- Brazil: 11 3759 7600
- Canada: 1-800-363-5853
- Europe: +31-(0) 40 2675 600
- Hong Kong: 852 2721-3228
- Japan: 03-6714-3117
- Korea: 82 2 539-6311
- Singapore: 65-6799-5566
- Taiwan: (886) 2-227-83199
- USA: 1-800-283-5853
- Anywhere in the world: +1-425-446-4519

Visit our website for a complete list of phone numbers.



**205 Westwood Ave
Long Branch, NJ 07740
1-877-742-TEST (8378)
Fax: (732) 222-7088
salesteam@Tequipment.NET**