OWNER'S MANUAL

KPRO

PRECISION
Coffee Scale 3kg

IMPORTANT

Read and follow all warnings and instructions before assembly and use.
Keep this manual for future reference.

Specifications

- Model number: 742526
- Dimensions: 17x13x2.5cm
- Voltage: Built-in 3.7V 300mAh lithium-ion battery

Product features

- Silicone protective mat protects weighing surface from scratches and spills
- Measures weight in grams and pounds, plus volume in millilitres and fluid ounces
- Measures up to 3kg with 0.1g precision
- Features a built-in timer for pour-over coffee and an LED display showing weight or volume
- Auto timing and manual timing modes
- Tare function enables accurate measurement
- Automatically powers off after five minutes of inactivity
- USB-C rechargeable lithium-ion battery
- Low battery indicator
- Full charge time is approximately three hours
- USB-C cable included

Power supply options

This rechargeable scale comes with a built-in lithium-ion battery which is rechargeable via the included USB-C cable and port and any standard USB charger (such as those used for smartphones), enabling it to be recharged without the need for disposable batteries.

Get to know the KPRO Precision Coffee Scale 3kg

Component	Description
Platform	Weighing surface
Buttons	M, U, ⏻/T, and Timer (II▶) control buttons
Type-C charging terminal	USB Type-C port for charging
Silicone mat	Removable non-slip mat on platform
LED display	Shows weight, timer, and status icons

Charging

Specification	Details
Battery	3.7V / 300mAh polymer lithium battery
Adapter output	5V / 1A
Full charge time	Approximately three hours

Charging status

Charging: LED displays "– – – –"


Fully charged: LED displays "FULL"



Note:

- Charge fully before first use or after extended storage.
- To protect the battery, top up the charge every three months during storage.
- If the scale isn't responding, a full charge will reset it.

LED icons indication




Button sounds

With button sounds enabled, every press gives an audible sound.
When timing, the scale emits a "beep" sound each minute.


Button functions

Button	Function
⏻/T	Scale is off: Press briefly to turn on. Scale is on: Press briefly to tare. Press and hold to turn off.
U	Unit conversion: Press briefly to cycle through six units — g → mL → oz → lb → lb:oz → fl'oz.
M	Mode conversion: Press briefly to switch between manual timing mode and auto timing mode. Press and hold to activate/deactivate the button sound function.
II▶	Timer: Press briefly to start/stop timing. Press and hold to reset to zero.


Weighing




1. Place the scale on a solid, flat surface. Press ⏻/T to turn on the scale and wait for the LED to display 0.



2. Press U to switch units if needed, then place a container on the platform.




3. Press T (⏻/T button) to tare the scale to zero.



4. Load items into the container. The LED displays the weight or volume value. The scale will automatically turn off if idle for five minutes.

Brewing coffee: manual timing mode


1. Turn on the scale, install the brewing device, and press T to tare.




2. Pour in coffee powder.




3. Press T to tare.



4. Press II► to start timing and begin pouring in water.




5. After brewing is finished, press II► to stop the timer. Take away the brewing device and enjoy your coffee. The scale will automatically turn off if idle for three minutes.




Brewing coffee: auto timing mode


1. Turn on the scale, install the brewing device, and press T to tare.



3. Press T to tare.



5. Pour in water. Timing starts automatically.




Note: The display will sleep after three minutes of inactivity and the scale powers off after 10 minutes.


2. Pour in coffee powder.



4. Press M to switch to auto timing mode. The scale enters this mode after a three second countdown displayed on the LED screen.




6. After brewing is finished, take away the brewing device. Timing and weighing end automatically, then the measuring value flashes. It's time for your coffee. The scale will automatically turn off if idle for three minutes.



Warnings


WARNING 1 — Low battery

Low battery: do not use the scale any more. The scale will automatically turn off after the LED displays LO. Please charge promptly.



WARNING 2 — Overloaded

Overloaded (maximum capacity is shown on the product). Please remove the object to prevent damage to the scale.



Cleaning and maintenance

1. Wipe clean with a slightly damp cloth. Never submerge in water or use chemical or corrosive cleaners. Store in a cool, dry place.
2. Clean plastic parts immediately after contact with fats, spices, vinegar, strongly flavoured or coloured foods, and citrus juice.
3. Always weigh on a solid, flat surface and keep the scale still during use.
4. This is a precision instrument, handle with care. Avoid drops, knocks and shaking.
5. Won't turn on? Check the battery level.
6. Use only a standard charger, no fast-charging. Do not use the scale while it's charging.
7. Keep away from heat. Do not attempt to disassemble.
8. Do not dispose of with household waste. Take to an electronic equipment recycling facility.
9. For household use only. Not suitable for commercial use.

Note: This product is a high precision device that can sense weight changes caused by the evaporation of high temperature liquid. During coffee weighing, it is normal for the weight to change due to water evaporation.

Get in touch with Customer Service

If you experience any issues with your KPRO Precision Coffee Scale, get in touch with our Customer Service team by email at customerservice@kitchenwarehouse.com.au or by phone on 1800 332 934 between the hours of 9am and 7pm (AEST) Monday to Friday.

Warranty

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The benefits of this warranty are in addition to any rights and remedies imposed by Australian State and Federal legislation that cannot be excluded. Nothing in this warranty excludes, restricts or modifies any State or Federal legislation applicable to the supply of goods which cannot be so excluded, restricted or modified.

Guarantee

We warrant that, subject to the exclusions and limitations below, the Product will be free from defects in materials and workmanship under normal domestic household use for the five year warranty period. The warranty period commences on the date of sale by the original retailer to the original purchaser. The warranty applies only while the Product is owned by the original purchaser.

Use of the Product in a commercial capacity will void this warranty. If a defect appears in the Product before the end of the warranty period and we find the Product to be defective in materials or workmanship, we will replace the Product with a product comparable in quality and value.

We reserve the right to change or discontinue our product ranges at any time without notice and without liability.

Exclusions

This warranty does not apply if proper care and/or usage instructions are not followed. This warranty does not cover scratches, stains, discoloration or damage caused by misuse.

How to claim

If a fault/defect is identified cease using the Product immediately. To make a claim on this guarantee, take the Product, proof of purchase and full details of the alleged defect to any Kitchen Warehouse store.

Limitations

We make no express warranties or representations other than as set out in this guarantee. The replacement of the Product or the refund of the purchase price is the absolute limit of our liability under this guarantee.

Distributed by Kitchen Warehouse.
KPRO is a registered trademark of Kitchen Warehouse Pty Ltd. The printed material appearing in this document and related packaging is protected by copyright. Illustrations in this manual are for reference only and may differ from the actual product.

Kitchen Warehouse Pty Ltd
1 Pensioner Guard Road
North Fremantle, WA, 6159
www.kitchenwarehouse.com.au
1800 332 934

customerservice@kitchenwarehouse.com.au