sodastream FRESH™




user guide

quick start guide



user manual


Carbonation Button
Easy Bottle
Attachment Head
Carbonating Tube
Drip Tray
Back Cover
sodastream


1L Fresh Carbonating Bottle
Filling line (max)
0.84L / 28fl.oz
CO2 Quick
Connect
Cylinder
sodastream
fizz.
swap.
save.

USER LICENSE

FOR ONE SODASTREAM QUICK CONNECT CYLINDER NOT FOR SALE.
PROPERTY OF SODASTREAM INDUSTRIES LTD. OR ITS AFFILIATES PROVIDED UNDER LICENSE AND PATENTED IN EU.

This is a legally binding document between Sodastream Industries Ltd. or its affiliates ("Sodastream") and the consumer regarding the right to use a Sodastream CO_2 Quick Connect Cylinder (the "Cylinder"). The Cylinder is proprietary to Sodastream, patended and protected by other intellectual property rights. Sodastream possesses the legally required knowledge and expertise to be responsible for strict legal compliance that can only be guaranteed if the Cylinder is maintained, examined, retested and refilled by it. Thus, the Cylinder remains the property of Sodastream and is provided under License.

1. When empty, please return the Cylinder to either Sodastream or an authorized Sodastream distributor in exchange for a full Cylinder, for the price of the gas refill only.
2. Refilling an empty Cylinder by third parties may infringe Sodastream's intellectual property rights, including patents and other proprietary rights, may be risky and may violate certain laws. Sodastream only warrants the safety of Cylinders refilled by it, bearing a Sodastream tamper proof valve seal.
3. If you return the Cylinder to Sodastream or an authorized Sodastream distributor, without exchanging it for a full one, you will be entitled to a return fee of 2$ or local equivalent.
4. The Cylinder, together with this User License, may be transferred to a third party provided the third party agrees to be bound by the conditions and ownership rights expressed herein.


For questions, please contact Sodastream International BV, Dongenseweg 200, 5047 SH Tilburg, The Netherlands.

Please keep in a safe place www.Sodastream.com

FIRST TIME SET UP


SODASTREAM® CO_2 QUICK CONNECT CYLINDER

Please note that the Sparkling Water Maker is only compatible with the CO_2 Quick Connect Cylinder and is NOT compatible with the Sodastream CO_2 Screw System Cylinder or other cylinders.



INSTALLING THE CO_2 QUICK CONNECT CYLINDER

1. Place the Sodastream Fresh Sparkling Water Maker on a flat sturdy surface.
2. Remove the Back Cover.
3. Remove the seal and cap from the Sodastream CO_2 Quick Connect Cylinder. **WARNING!** Never insert or replace the CO_2 Quick Connect Cylinder while a Carbonating Bottle is installed in the Sparkling Water Maker. This can cause the Carbonating Bottle to be ejected or burst.
4. Raise black cylinder handle.
5. Insert the CO_2 Quick Connect Cylinder, bottom first into the Sparkling Water Maker base.
6. Lower the Cylinder Handle.
7. Reinstall the Back Cover. Now you are ready to create the bubbles.



CREATE THE BUBBLES

1. Fill the Plastic Carbonating Bottle with cold water up to the fill line. **WARNING!** Do not carbonate anything other than water. Other liquids can contaminate and clog internal parts, potentially resulting in excessive pressure, bottle failure during carbonation and serious injury. Never carbonate after flavouring has been added.
2. To insert the Carbonating Bottle tilt the carbonated head up and make sure that the Carbonating Bottle rest is angled forward. **WARNING!** Never pull the carbonating tube or use a Sparkling Water Maker with a broken carbonating tube. This can cause excessive pressure, bottle failure and serious injury. Insert the Carbonating Bottle neck into the easy bottle attachment head. Push the Carbonating Bottle up and back. The easy click bottle system will hold the Carbonating Bottle.
3. To carbonate, press the carbonating button in short 1 second presses; 3 presses for standard carbonation and 5 presses for strong carbonation.
4. After carbonating is achieved, gently pull the Carbonating Bottle towards you until it reaches its fully forward position. This will release the pressure in the Carbonating Bottle and allow the Carbonating Bottle to be released from the easy click bottle system. **WARNING!** Do not remove Carbonating Bottle until after hearing the sound of excess CO_2 being released. Never force the Carbonating Bottle out of the easy click bottle system. Always allow the Sparkling Water Maker to release the Carbonating Bottle. If the Carbonating Bottle does not immediately release from the easy click bottle system wait a few moments. If it still does not release, then push the Carbonating Bottle back into the vertical position and gently pull it towards you again. Attempting to remove the Carbonating Bottle while it is still pressurized can cause uncontrolled ejection of the Carbonating Bottle and may result in serious injury. Note: when inserted correctly, there is a small gap between the bottom of the Carbonating Bottle and the base. Do not carbonate if the Carbonating Bottle is resting on the base, or water will splash out. **Note:** Small pieces of ice may appear in the water during carbonation of very cold water that will simply melt.



CARE

SPARKLING WATER MAKER CARE

- Never use abrasive cleaners or sharp tools to clean. If needed, use a mild liquid dish soap and a soft damp cloth to gently clean.
- Wipe spills to keep base dry.
- Do not place in water or wash in a dishwasher, doing so will seriously damage your Sparkling Water Maker.

PLASTIC CARBONATING BOTTLE CARE

To reduce the risk of bottle failure which can result in personal injury and property damage:

- For Plastic Carbonating Bottles not marked as dishwasher-safe, do not expose to heat above 50°C. Never wash or rinse in hot water.
- Do not wash in dishwasher.
- For dishwasher safe Plastic Carbonating Bottles, do not expose to heat above 70°C.
- Do not place the Plastic Carbonating Bottle next to a heat source such as your kitchen oven/stove.
- Do not leave the Plastic Carbonating Bottle in your car.
- Do not place the Plastic Carbonating Bottle in the freezer or in extreme cold below 1°C.
- Do not use the Plastic Carbonating Bottle if damaged, deformed, scratched, worn, or discoloured.
- Do not use a Plastic Carbonating Bottle after its expiration date.

Only carbonate with Plastic Carbonating Bottle specifically designed to work with this Sparkling Water Maker.

Please follow the care instructions provided with the bottle included in your package:

fuse / classic 	1. For Plastic Carbonating Bottles which are not dishwasher safe, to clean, rinse Plastic Carbonating Bottles with cold or lukewarm water. **WARNING!** Do not expose to heat above 50°C / 120°F. Never wash or rinse in hot water. Do not wash in dishwasher. 2. For dishwasher safe Plastic Carbonating Bottles, to clean, either wash in dishwasher or rinse Plastic Carbonating Bottles with cold or lukewarm water. **WARNING!** Do not expose to heat above 70°C / 158°F.
enso  **FRESH** 	1. For Plastic Carbonating Bottles which are not dishwasher safe, to clean, rinse Plastic Carbonating Bottles with cold or lukewarm water. **WARNING!** Do not expose to heat above 50°C / 120°F. Never wash or rinse in hot water. Do not wash in dishwasher. 2. For dishwasher safe Plastic Carbonating Bottles, to clean, either wash in dishwasher or rinse Plastic Carbonating Bottles with cold or lukewarm water. **WARNING!** Do not expose to heat above 70°C / 158°F. 3. The bottle base is removable. Removing the base & cap before cleaning ensures best hygiene. After removing the base, follow cleaning instructions of the bottle as shown above. 4. The plastic cap is hand wash only. The plastic base maybe cleaned in dishwasher. Metal cap & base may be cleaned in the dishwasher. 5. To remove the base – hold the bottle, gently turn and pull the base until it comes loose. After cleaning, put it back by turning until it clicks into place.

FOR YOUR SAFETY

SAVE THESE INSTRUCTIONS AND PROVIDE THEM TO ANY SUBSEQUENT USERS. WARNING! Before using the Sparkling Water Maker , to reduce risk of personal injury and damage to your product, please read this important safety information. Before allowing anyone to use your Sparkling Water Maker , please be sure they understand how to do so safely. Any servicing or repair should be performed by a Sodastream® authorized service representative. The Sparkling Water Maker is only intended for use by people over the age of 12. People with reduced physical or mental capabilities should only use the product if they are supervised by an adult responsible for their safety and after they have been given instruction concerning the safe use of the product.

TO REDUCE THE RISK OF EITHER SERIOUS INJURY OR DAMAGE TO THE SPARKLING WATER MAKER DURING CARBONATION

- Only use your Sparkling Water Maker in its upright position, on a flat, stable surface.
- Do not place your Sparkling Water Maker on a hot surface (e.g. kitchen oven/stove) and never use it near a heat source (e.g. close to an open flame) or leave in direct sunlight.
- Carbonate water only.

CARBON DIOXIDE CO_2 CYLINDER

To reduce the risk of a CO_2 leak, personal injury and property damage:

- Do not use any cylinder other than the Sodastream® CO_2 Quick Connect Cylinder compatible with the Sodastream Fresh Plus Pink Handle System.
- Do not insert a CO_2 Cylinder into the Sparkling Water Maker when a plastic carbonating bottle is installed.
- Do not use if damaged. Inspect the CO_2 Cylinder and CO_2 Cylinder valve prior to use for dents, punctures, or other damage. If damaged, contact a Sodastream authorized service representative.
- Do not tamper with the CO_2 Cylinder in any way, including puncturing, incinerating or removing the valve.
- Do not expose the CO_2 Cylinder to heat above 50°C / 120°F or near a heat source. Protect from sunlight. Store in a well ventilated area.
- Do not remove a CO_2 Cylinder from the Sparkling Water Maker when it is being operated.
- Do not handle or remove a CO_2 Cylinder while it is discharging CO_2.
- In the event of a CO_2 leak, ventilate the area, breathe fresh air and if feeling unwell seek immediate medical attention.

FOR BOTTLE WITH WARNING ICONS:



Read the manual



Bottle failure may result in personal injury



Never use after expiry date



Never wash in dishwasher



Never expose to temperatures above 120°F / 50°C or below 34°F / 1°C



Carbonate water only



Never use if damaged or deformed

FOR DISHWASHER-SAFE BOTTLE



Never expose to temperatures above 158°F / 70°C or below 34°F / 1°C



Dishwasher safe

SODASTREAM LIMITED WARRANTY

SODASTREAM SPARKLING WATER MAKERS

Great care has been taken to ensure that your Sparkling Water Maker was delivered to you in good condition. Sodastream warrants, subject to the terms and conditions set forth in this limited warranty, that your Sparkling Water Maker will be free of defects in materials and workmanship under normal home use for 2 (two) years following the date of purchase. It is recommended that you register your Sparkling Water Maker online by visiting www.Sodastream.com and completing the product registration form available on the website. If your Sparkling Water Maker malfunctions within the warranty period, and we determine the problem is due to faulty workmanship or materials, Sodastream will repair or replace it free of charge at Sodastream's discretion within the limitations set out in this warranty. Sodastream may replace your Sparkling Water Maker with a reconditioned Sparkling Water Maker, or an equivalent one if the model you purchased is no longer available. No refunds shall be given. This limited warranty is available to consumers who purchased the Sparkling Water Maker for personal, family or household use.

This warranty DOES NOT cover damages to Sparkling Water Maker resulting from:

- Abuse, misuse, alteration of the Sparkling Water Maker, or commercial use.
- Carbonating liquids other than water.
- Normal wear and tear (e.g. discoloration).
- Product malfunctions that were a result, in whole or in part, by alteration, disassembly, or repair of the Sparkling Water Maker by a servicer other than an authorized Sodastream Service Center.
- The use of CO_2 Cylinders or carbonating bottles other than those approved by Sodastream for use with your Sparkling Water Maker.
- The use of the Sparkling Water Maker with an adapter connected to the Cylinder valve or to the Sparkling Water Maker.
- The use of an expired plastic carbonating bottle.
- Accident, shipment or anything other than normal household use.

This warranty DOES NOT cover the carbonating bottles and CO_2 Cylinders. Sodastream is not liable for incidental or consequential damages. The consumer's sole and exclusive remedy shall be repair or replacement according to the terms and conditions of this warranty. Some local laws do not allow the exclusion or limitation of these damages, so these exclusions may not apply to you. To the extent that this warranty is inconsistent with local law, this warranty shall be deemed modified to be consistent with such local law. You may also have other rights, which vary in accordance with local laws. The benefits given to the consumer by this warranty are in addition to other rights and remedies that may be afforded to the consumer by law in relation to this Sparkling Water Maker.

TO OBTAIN WARRANTY SERVICE FOR YOUR SPARKLING WATER MAKER

If your Sparkling Water Maker is in need of warranty service, please contact Sodastream Customer Service by visiting www.Sodastream.com. A Sodastream representative will give you specific instructions on how to arrange for the shipment of your Sparkling Water Maker, at your expense, to one of our authorized service centers. Only Sodastream, or its agents, are authorized to provide warranty repairs or service to your Sparkling Water Maker.

NON-WARRANTY SERVICE

If Sodastream or its authorized agents determine that the malfunction or damage to your Sparkling Water Maker is not covered by the warranty, Sodastream will repair the Sparkling Water Maker only upon payment of the determined repair charge.

SODASTREAM® CO_2 QUICK CONNECT CYLINDERS

Your Sparkling Water Maker has been designed to operate with a Sodastream CO_2 Quick Connect Cylinder. The use of other CO_2 Cylinders is not recommended as they may not be compatible with a Sodastream Sparkling Water Maker. Damages resulting from the use of a cylinder other than a the Sodastream CO_2 Quick Connect Cylinder or use of the Sodastream CO_2 Quick Connect Cylinder not in accordance with the instructions included in this User Guide are not covered by the warranty. The Sodastream CO_2 Quick Connect Cylinder is provided to you under license. The license allows you to exchange your empty Cylinder for a full one for the price of the CO_2 only.

TERMS AND CONDITIONS FOR ALL EXCEPT U.S.A. CONSUMERS

Any and all claims, complaints, demands for judgment or legal actions brought hereunder relating in any way to your Sparkling Water Maker, plastic carbonating bottle or CO_2 Cylinder shall be governed by, and construed in accordance with, the laws of the local Country in which the Sodastream Sparkling Water Maker was purchased.

FOR AUSTRALIAN RESIDENTS

Our Sparkling Water Maker comes with guarantees that cannot be excluded under the Australian Consumer Law. Australian residents are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. Australian residents are also entitled to have the Sparkling Water Maker repaired or replaced if it fails to be of acceptable quality and the failure does not amount to a major failure. The issuer of this warranty is SodaStream Australia Pty Ltd., 21 Henderson Road, Knoxfield, Victoria 3180, Australia, Telephone No.: 1300 763 278, email: sales-australia@sodastream.com Should the Sparkling Water Maker suffer a major failure or other reasonably foreseeable damage, contact us at the above phone number, email or mailing address to present your claim for the warranty. If Australian residents are returning the Sparkling Water Maker in accordance with their rights under the Australian Consumer Law: (a) the Sparkling Water Maker does not need to be in its original packaging to be returned, however you must ensure that the Sparkling Water Maker is adequately protected for transit; and (b) Australian residents will be required to pay any delivery costs when returning items to us, however SodaStream Australia Pty Ltd., will refund reasonable delivery costs if they are entitled to a remedy under the Australian Consumer Law (subject to you providing proof of these costs). The benefits to the Australian consumer given by this warranty are in addition to other rights and remedies that may be afforded to the Australian consumer by law in relation the Sparkling Water Maker.

PRODUCT DISPOSAL INSTRUCTIONS

Please recycle your expired and damaged Plastic Carbonating Bottles in accordance with local recycling laws. The packaging in which Sodastream products are supplied is made of recyclable materials. Contact your local authority for further information on recycling.


MACHINE RATING INFORMATION

Maximum Working Pressure: 116 psi/8 bar
Maximum Allowed Operating Temperature: 40°C/104°F

Sodastream is a registered trademark of Sodastream (Switzerland) GmbH or its affiliates.

4011370980 - 02/26

we make it easy for you to keep things bubbly



fizz

enjoy easily made fizzy drinks at home



swap

exchange your empty cylinders in-store or online




save

save up to 50% on swapped cylinders*

*compared to new spare Sodastream cylinders, actual savings may vary by country





sodastream®

drink better.
push for better.®

welcome to a world of flavours freshly made by you,
while replacing over a thousand single-use plastic bottles.

4011370980 - 02/26