

DE

Inbetriebnahme oder Funktionsstörung:

AB-Taste gedrückt halten bis der Tisch automatisch stoppt.

AB-Taste erneut gedrückt halten bis die Minimalposition erreicht ist. **AB**-Taste loslassen und nochmal für mindestens 8 Sekunden gedrückt halten. Tisch fährt in die unterste mechanische Position, Taste loslassen. Tisch fährt automatisch in die Minimalposition zurück. Tisch nach ca. 10 Sekunden in Betrieb nehmen.

Betrieb:

Die **AUF**- oder **AB**-Taste gedrückt halten bis die gewünschte Position erreicht ist. Vor Erreichen der mechanischen Endposition wird automatisch gestoppt.

Speicherfunktionen (nur bei Memory):

Tisch in die gewünschte Höhe fahren. **LOGO**-Taste unter dem Display drücken. Im Display wird **P_** angezeigt. Drücken Sie eine der **MEMORY**-Tasten (z.B.1). Im Display wird **P_1** angezeigt. Der Speichervorgang ist abgeschlossen.

Gespeicherte Position abrufen:

Halten Sie die Taste der gewünschten Speicherposition (z.B.1) gedrückt. Der Tisch fährt in diese Position.

QR-Code: Siehe auch Unterseite der Tischplatte. Weitere Informationen entnehmen Sie bitte der Bedienungsanleitung.

EN

Start-up or malfunction:

Keep the **DOWN** button pressed until the table stops automatically.

Keep the **DOWN** button pressed again until the minimum position is reached.

Release the **DOWN** button and keep it pressed again for at least 8 seconds.

The table moves to the lowest mechanical position, release the button. The table returns automatically to the minimum position. After 10 seconds the table can be operated.

Operation:

Keep the **UP** or **DOWN** button pressed until the desired height is reached.

The table stops automatically before the mechanical end position is reached.

Memory functions (memory only):

Move the table to desired position. Press the **LOGO** button below the display.

The display shows **P_**. Press a **MEMORY** button (for example 1). The display shows **P_1**. The saving process is completed.

Retrieving a saved position:

Press the button for desired position (for example 1), the table moves to the saved position.

QR code: see also underside of tabletop. Further information is available in the instruction manual.