


Connector "A"	
Pin N°	Description
1	open command
2	+ 12 V battery
3	D+ IGNITION
4	close command
5	D+ HAND BRAKE
6	(-) GND
7	COMMON PUSH-BOTTON
8	--

Connector "B"	
Pin N°	Description
1	black wire (motor)
3	red wire (motor)



INTERNAL TO STEP