



| Exploded View Number | MPN | Part Sku | Part Name | Serviceable Part? | Serial Range | Quantity |
|----------------------|---------|-----------------|---|-------------------|--------------|----------|
| 1 | 9266303 | PL3024UI2WSG59 | L3024UI1WSG-LH 24" Compressor Cover | Yes | | 1 |
| 2 | 9264664 | PABR151SG1 | L3024UI1WSG-LH R600a Dryer Filter | Yes | | 1 |
| 3 | 9265807 | PL3024UI2WSG2 | L3024UI1WSG-LH Power Cord | Yes | | 1 |
| 4 | 9265793 | PL3024UI2WSG4 | L3024UI1WSG-LH Condensate Tray | Yes | | 1 |
| 5 | 9265792 | PL3024UI2WSG5 | L3024UI1WSG-LH Compressor | Yes | | 1 |
| 6 | 9265849 | PL3015UI1BSG5A | L3024UI1WSG-LH Compressor Relay | Yes | | 1 |
| 7 | 9265850 | PL3015UI1BSG5B | L3024UI1WSG-LH Compressor Overload | Yes | | 1 |
| 8 | 9266268 | PL3015UI1BPR5C | L3024UI1WSG-LH Capacitor | Yes | | 1 |
| 9 | 9264375 | PCBR1501SSOD8 | L3024UI1WSG-LH Power Board Box | Yes | | 1 |
| 10 | 9265745 | PL3024UI1WSG9 | L3024UI1WSG-LH SZ Wine Main Power Board | Yes | | 1 |
| 11 | 9264527 | PBR7000SS13.1 | L3024UI1WSG-LH Decorative Nail | Yes | | 4 |
| 12 | 9266116 | PL3024UI2WSG13 | L3024UI1WSG-LH Top/Bottom Light Cover | Yes | | 2 |
| 13 | 9266117 | PL3024UI2WSG14 | L3024UI1WSG-LH LED Light | Yes | | 1 |
| 14 | 9266111 | PL3024UI2WSG15 | L3024UI1WSG-LH Side Light Cover | Yes | | 2 |
| 15 | 9265838 | PL3024UI1WSG17 | L3024UI1WSG-LH Evaporator | Yes | | 1 |
| 16 | 9264441 | PCBR1501SSOD17 | L3024UI1WSG-LH Fan | Yes | | 1 |
| 17 | 9265446 | PABR151SG34W | L3024UI1WSG-LH Temperature Sensor: White Connector | Yes | | 1 |
| 18 | 9266131 | PL3024UI2WSG25 | L3024UI1WSG-LH Sensor Cover | Yes | | 1 |
| 19 | 9266123 | PL3024UI2WSG28 | L3024UI1WSG-LH Carbon Filter | Yes | | 1 |
| 20 | 9265922 | PL3024UI1MSG36B | L3024UI1WSG-LH Track Support (Back Right) | Yes | | 1 |
| 21 | 9265942 | PL3024UI1MSG34B | L3024UI1WSG-LH Track Support (Front Right) | Yes | | 1 |
| 22 | 9266319 | PL3024UI2WSG40H | L3024UI1WSG-LH Door Handle | Yes | | 1 |
| 23 | 9266149 | PL3024UI2WSG38 | L3024UI1WSG-LH Magnet for Door Switch | Yes | | 1 |
| 24 | 9266146 | PL3024UI2WSG39 | L3024UI1WSG-LH Lock Hook | Yes | | 1 |
| 25 | 9266312 | PL3024UI2WSG40L | L3024UI1WSG-LH Door w/ Hinge, Gasket, and Handle | Yes | | 1 |
| 26 | 9266304 | PL3024UI2WSG40G | L3024UI1WSG-LH Door Gasket | Yes | | 1 |
| 27 | 9266174 | PL3024UI2WSG41 | L3024UI1WSG-LH 24" Main Wine Shelf w/Trim and Sliding Track | Yes | | 5 |
| 28 | 9265981 | PL3024UI1WSG32 | L3024UI1WSG-LH Bottom Shelf w/Trim and Sliding Track | Yes | | 1 |
| 29 | 9265939 | PL3024UI1MSG34A | L3024UI1WSG-LH Track Support (Front Left) | Yes | | 1 |
| 30 | 9265927 | PL3024UI1MSG36A | L3024UI1WSG-LH Track Support (Back Left) | Yes | | 1 |



NOTE

*Values are only provided in the Serial Range column when parts are specific to a serial generation. If no value is provided, the part will work for any serial number for the relevant Landmark model.

| Exploded View Number | MPN | Part Sku | Part Name | Serviceable Part? | Serial Range | Quantity |
|----------------------|---------|----------------|--|-------------------|--------------|----------|
| 31 | 9266175 | PL3024UI2WSG47 | L3024UI1WSG-LH 24" Kick Plate w/Lock | Yes | | 1 |
| 32 | 9266168 | PL3024UI2WSG48 | L3024UI1WSG-LH Door Switch | Yes | | 1 |
| 33 | 9266291 | PL3024UI2WSG50 | L3024UI1WSG-LH Lock Support | Yes | | 1 |
| 34 | 9265443 | PABR151SG34R | L3024UI1WSG-LH Temperature Sensor: Red Connector | Yes | | 1 |
| 35 | 9265662 | PL3024UI1MSG29 | L3024UI1WSG-LH Control Panel | Yes | | 1 |
| 36 | 9265663 | PL3024UI1MSG30 | L3024UI1WSG-LH Display Box | Yes | | 1 |
| 37 | 9265593 | PL3024UI1MSG10 | L3024UI1WSG-LH Display Board | Yes | | 1 |
| 38 | 9266315 | PL3024UI2WSG51 | L3024UI1WSG-LH Leveling Leg | Yes | | 4 |
| 39 | 9266317 | PL3024UI2WSG52 | L3024UI1WSG-LH 24" Bracket for Leveling Legs | Yes | | 1 |
| 40 | | PL3024UI2WSG53 | L3024UI1WSG-LH Condenser | No | | 1 |
| 41 | 9264441 | PCBR1501SSOD17 | L3024UI1WSG-LH Fan | Yes | | 1 |
| 42 | 9265471 | PAFRKEYS | L3024UI1WSG-LH Keys (Set of Two) | Yes | | 2 |