



| Exploded View Number | Part Sku | Part Name | Serviceable Part? | Serial Range | Quantity |
|----------------------------|----------------|---|----------------------|--------------|----------|
| 1 | PDRAW06F1B26 | DRAW06F1B Electronic Control Box Subassembly | Yes | | 1 |
| 2 | PDRAW09F1B26 | DRAW06F1B Cover Of Electronic Control Box | Yes | | 1 |
| 3 | PDRAW06F1B28 | DRAW06F1B Main Control Board Subassembly | Yes | | 1 |
| 4 | PDRAW09F1B31 | DRAW06F1B Wire Joint | Yes | | 1 |
| 5 | PDRAW09F1A19F | DRAW06F1B Pipe Temperature Sensor | Yes | | 1 |
| 6 | PDRAW09F1A19E | DRAW06F1B Room Temperature Sensor | Yes | | 1 |
| 7 | PDRAW06F1B11 | DRAW06F1B Evaporator Assembly | Yes | | 1 |
| 8 | PDRAW09F1A12 | DRAW06F1B Bearing Holder | Yes | | 1 |
| 9 | PDRAW09F1A13 | DRAW06F1B Bearing Components | Yes | | 1 |
| 10 | PDRAW06F1B16 | DRAW06F1B Cross Flow Fan | Yes | | 1 |
| 11 | PDRAW09F1B3 | DRAW06F1B Display Box Subassembly | Yes | | 1 |
| 12 | PDRAW09F1B4 | DRAW06F1B Display Board Subassembly | Yes | | 1 |
| 13 | PDRAW09F1A10 | DRAW06F1B Fan Motor Cover | Yes | | 1 |
| 14 | PDRAW09F1B12 | DRAW06F1B Brushless Dc Motor | Yes | | 1 |
| 15 | PDRAW06F1B10 | DRAW06F1B Horizontal Louver Assembly | Yes | | 1 |
| 16 | PDRAW06F1B21 | DRAW06F1B Front Cover Of Chassis(Left) | Yes | | 1 |
| 17 | PDRAW06F1B20 | DRAW06F1B Vertical Vane Subassembly | Yes | | 1 |
| 18 | PDRAF18F1A9 | DRAW06F1B Insulated Axis | Yes | | 1 |
| 19 | PDRAW09F1A16A | DRAW06F1B Stepper Motor | Yes | | 1 |
| 20 | PDRAW06F1B22 | DRAW06F1B Electrical Control Box Holder | Yes | | 1 |
| 21 | PDRAW09F1A18 | DRAW06F1B Installation Plate | Yes | | 1 |
| 22 | PDRAW09F1A40 | DRAW06F1B Activated Carbon with Electrostatic Fiber Filters | Yes | | 2 |
| 23 | PDRAW09F1B23 | DRAW06F1B Pipe Clamp Board | Yes | | 1 |
| 24 | PDRAW09F1B32 | DRAW06F1B Remote Controller | Yes | | 1 |
| 25 | PDRAW09F1B37 | DRAW06F1B Bracket Of Remote Controller | Yes | | 1 |
| 26 | PDRAD09F1A9E | DRAW06F1B Check Valve | Yes | | 1 |
| 27 | PDRA1U18S1A13B | DRAW06F1B Copper Nut | Yes | | 1 |
| 28 | PDRA5U48M1A21 | DRAW06F1B Copper Nut | Yes | | 1 |
| 29 | PDRAW06F1B8 | DRAW06F1B Front Cover Of Chassis(Right) | Yes | | 1 |
| 30 | PDRAW09F1A28 | DRAW06F1B Drain Hose | Yes | | 1 |
| 31 | PDRAW09F1A22 | DRAW06F1B Seal Ring | Yes | | 1 |
| 32 | PDRAW09F1A23 | DRAW06F1B Drain Hose | Yes | | 1 |



Version: 1.0 03232023 Page 3/3

| Exploded View Number | Part Sku | Part Name | Serviceable Part? | Serial Range | Quantity |
|----------------------------|--------------|---|----------------------|--------------|----------|
| 33 | PDRAW09F1B8 | DRAW06F1B Cover Board For Wiring | Yes | | 1 |
| 34 | PDRAW06F1B7 | DRAW06F1B Screw Cap | Yes | | 1 |
| 35 | PDRAW06F1B35 | DRAW06F1B Pipe Connect Board | Yes | | 1 |
| 36 | PDRAW06F1B6 | DRAW06F1B Panel Frame Assembly | Yes | | 1 |
| 37 | PDRAW09F1B5 | DRAW06F1B Cover Of Electrical Equipment | Yes | | 1 |
| 38 | PDRAW06F1B2 | DRAW06F1B Air Filter | Yes | | 2 |
| 39 | PDRAW06F1B1 | DRAW06F1B Panel Assembly | Yes | | 1 |

NOTE

*Values are only provided in the **Serial Range** column when parts are specific to a serial generation. If no value is provided, the part will work for any serial number for the relevant Durastar mini–split SKU.

www.durastar.com • questions@durastar.com *Warranty service should be performed by an authorized service representative only,