



Exploded View Number	Part SKU	Part Name	Serviceable Part?	Serial Range	Quantity
1	PDRA5U48M1A17	DRA5U48M1B Front Panel	Yes		1
2	PDRA1U24S1A11	DRA5U48M1B Air Outlet Grille	Yes		2
3	PDRA5U48M1A23	DRA5U48M1B Top Cover Assembly	Yes		1
4	PDRA5U48M1A18	DRA5U48M1B Axial Flow Fan	Yes		2
5	PDRA5U48M1A19	DRA5U48M1B Brushless DC Motor	Yes		2
6	PDRA5U48M1B29	DRA5U48M1B 4-Way Valve Assembly	Yes		1
7	PDRA5U48M1B20	DRA5U48M1B Fan Motor Bracket	Yes		1
8	PDRA5U48M1A26A	DRA5U48M1B 4-Way Valve	Yes		1
9	PDRA3U28M1A21B	DRA5U48M1B Gas Valve	Yes		1
10	PDRA5U48M1A15	DRA5U48M1B Left Side Plate Assembly Of Cabinet	Yes		1
11	PDRA5U48M1B3	DRA5U48M1B Condenser Assembly	Yes		1
12	PDRA5U48M1B2	DRA5U48M1B Condenser Assembly	Yes		1
13	PDRA5U48M1A50	DRA5U48M1B Rear Net	Yes		1
14	PDRA5U48M1B4	DRA5U48M1B Pipe Temperature Sensor	Yes		1
15	PDRA5U48M1A47	DRA5U48M1B Pipe Temperature Sensor	Yes		1
16	PDRA5U48M1A1	DRA5U48M1B Room Temperature Sensor	Yes		1
17	PDRA5U48M1B35	DRA5U48M1B Electronic Control Box Subassembly	Yes		1
18	PDRA5U48M1B40	DRA5U48M1B Electronic Installing Box	Yes		1
19	PDRA5U48M1B39	DRA5U48M1B Inverter Module Subassembly	Yes		1
20	PDRA5U48M1B36	DRA5U48M1B Installation Plate Of Electric Parts Subassembly	Yes		1
21	PDRA5U48M1B37	DRA5U48M1B Outdoor Main Control Board Subassembly	Yes		1
22	PDRA5U48M1B38	DRA5U48M1B Electronic Installing Box	Yes		1
23	PDRA5U48M1B42	DRA5U48M1B Terminal Board Subassembly	Yes		1
24	PDRA5U48M1B46	DRA5U48M1B Terminal Instalation Subassembly	Yes		1
25	PDRA5U48M1B43	DRA5U48M1B Wire Joint	Yes		1

Exploded View Number	Part SKU	Part Name	Serviceable Part?	Serial Range	Quantity
26	PDRA3U28M1A20A	DRA5U48M1B Terminal	Yes		1
27	PDRA4U36M1A20A	DRA5U48M1B Terminal	Yes		1
28	PDRA5U48M1A8	DRA5U48M1B Water Collector	Yes		1
29	PDRA5U48M1B59	DRA5U48M1B Waterproof Board	Yes		1
30	PDRA5U48M1A5	DRA5U48M1B Big Handle Assembly	Yes		1
31	PDRA5U48M1A6A	DRA5U48M1B Handle	Yes		1
32	PDRA5U48M1A6	DRA5U48M1B Rear Right Clapboard Assembly	Yes		1
33	PDRA5U48M1A22	DRA5U48M1B Discharge Temperature Sensor	Yes		1
34	PDRA5U48M1A30	DRA5U48M1B Suction Pipe Assembly	Yes		1
35	PDRA5U48M1A30A	DRA5U48M1B Pressure Switch	Yes		1
36	PDRA5U48M1B49	DRA5U48M1B Liquid Valve Assembly	Yes		1
37	PDRA3U28M1A23A	DRA5U48M1B Liquid Valve	Yes		1
38	PDRA5U48M1B26	DRA5U48M1B Discharge Pipe Assembly	Yes		1
39	PDRA5U48M1B28	DRA5U48M1B Muffler	Yes		1
40	PDRA3U28M1A21C	DRA5U48M1B Pressure Switch	Yes		1
41	PDRA5U48M1B32	DRA5U48M1B Liquid Valve Assembly	Yes		1
42	PDRA1U09S1A18A	DRA5U48M1B Liquid Valve	Yes		5
43	PDRA1U24S1A22B	DRA5U48M1B Electronic Expansion Valve Body	Yes		5
44	PDRA5U48M1A35	DRA5U48M1B Gas Valve Assembly	Yes		1
45	PDRA2U18M1A16A	DRA5U48M1B Gas Valve	Yes		3
46	PDRA1U12S1A17A	DRA5U48M1B Gas Valve	Yes		2
47	PDRA5U48M1A28U	DRA5U48M1B Compressor Wire Subassembly	Yes		1
48	PDRA5U48M1A24	DRA5U48M1B DC Inverter Rotary Compressor	Yes		1
49	PDRA1U09S1ARP	DRA5U48M1B Outdoor Unit Rubber Pads	Yes		4
50	PDRA5U48M1A13	DRA5U48M1B Liquid-Storage Tank	Yes		1

Exploded View Number	Part SKU	Part Name	Serviceable Part?	Serial Range	Quantity
51	PDRA5U48M1A38	DRA5U48M1B Crankcase Electric Heating Strip	Yes		1
52	PDRA3U28M1A30	DRA5U48M1B Electric Heating Tube	Yes		1
53	PDRA5U48M1B57	DRA5U48M1B Electronic Expansion Valve Subassembly	Yes		1
54	PDRA5U48M1B58	DRA5U48M1B Electronic Expansion Valve Body	Yes		1
55	PDRA5U48M1A9	DRA5U48M1B Front Right Clapboard Assembly	Yes		1
56	PDRA5U48M1A21	DRA5U48M1B Copper Nut	Yes		3
57	PDRA1U18S1A13A	DRA5U48M1B Copper Nut	Yes		2
58	PDRA1U18S1A13B	DRA5U48M1B Copper Nut	Yes		5
59	PDRA4U36M1ATC1	DRA5U48M1B Outdoor Unit Transfer Connector 1/2"-3/8"	Yes		2
60	PDRA4U36M1ATC2	DRA5U48M1B Outdoor Unit Transfer Connector 1/4"-3/8"	Yes		2
61	PDRA4U36M1ATC3	DRA5U48M1B Outdoor Unit Transfer Connector 1/2"-5/8"	Yes		2
62	PDRA3U28M1A43	DRA5U48M1B Outdoor Unit Transfer Connector 3/8"-1/2"	Yes		3



NOTE

*Values are only provided in the **Serial Range** column when parts are specific to a serial generation. If no value is provided, the part will work for any serial number for the relevant Durastar mini-split SKU.