







# **ADA-Compliant Wall Tiles**

Instruction Sheet 100-00117 Rev A





©2024 | Legrand AV, Inc. All rights reserved.

Information in this document is subject to change without notice. The AV equipment described in this document is furnished under a license agreement or nondisclosure agreement. The equipment may be used or copied only in accordance with the terms of those agreements. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or any means electronic or mechanical, including photocopying and recording for any purpose other than the purchaser's personal use without the written permission of Legrand AV.

Middle Atlantic is a brand of Legrand AV.

www.legrandav.com | Phone: (866) 977-3901 | Fax: (877) 894-6918 | Email: av.middleatlantic.techsupport@legrand.com

Visit us at www.legrandav.com for firmware updates, specifications, drawings, manuals, technical support information, and more.

Middle Atlantic is a registered tradmark of Legrand AV, Inc.

Legrand AV is an ISO 9001 and ISO 14001 Registered Company.

All patents are protected under existing designations. Other patents pending. For more information, refer to the Patents page on the website at www.legrandav.com/resources/patents.

All other brand names or marks are used for identification purposes and are trademarks of their respective owners.

Legrand AV Inc. Brands: Chief | Da-Lite | Middle Atlantic | C2G | Luxul | On-Q | Sanus | Vaddio

## SUPPLIED COMPONENTS AND HARDWARE

If any pieces are missing or damaged, please report it immediately to Technical Support at av.middleatlantic.techsupport@legrand.com or (866) 977-3901.



#### NOTE:

• To order more hardware, contact support at av.middleatlantic.techsupport@legrand.com or (866) 977-3901.

#### **REQUIRED TOOLS**

- Electric Drill
- #2 Phillips Bit
- Level
- 1/2" Drill Bit

**WARNING**: Use tools with caution and follow all necessary safety protocols.

**ADVERTENCIA:** Utilice las herramientas con precaución y siga todos los protocolos de seguridad necesarios.

**AVERTISSEMENT**: Utiliser des outils avec prudence et suivre tous les protocoles de sécurité nécessaires.

## FOLDING THE ADA-COMPLIANT WALL TILES

**NOTE:** Orient side with cut lines facing up prior to folding your ADA-Compliant Wall Tile. (**FIGURE A**)



## FOLDING ADA-COMPLIANT WALL TILES

• Follow the step-by-step guide to fold your (2x) ADA-Compliant Wall Tiles (A) for mounting installation.





## FOLDING THE MOUNTING PANEL

**NOTE:** Mounting Panel (B) will be attached to wall with arrow pointing upwards.

• Fold the bottom section of mounting panel (B) backwards, as shown. (FIGURE B)



## **DETERMINING MOUNTING LOCATION FOR ADA-COMPLIANT WALL TILES**

#### NOTE:

- This topic will show you how to mount your ADA-Compliant Wall Tile (A) at default distance from side door and default height.
- A minimum of 22" (558.8 mm) from the side of the display stand is needed to fully open bottom doors and meet ADA requirements. (**FIGURE C**)
- A maximum of 27" (685.8 mm) from the floor to the bottom of your wall tile meets the ADA requirements needed to mount panel to wall.
- For more information, refer to the ADA Standards for Accessible Design at: https://www.ada.gov





- 1. Align a ruler or level to the top surface of your display stand doors.
- 2. Use a pencil to draw Line 1 approximately 34" (864 mm) away from the side door surface and mark a dot, as shown. (**FIGURE E**)
- 3. Draw Line 2 vertically at 34" (864 mm) to intersect with Line 1. Line 2 should be longer than 4 <sup>3</sup>/<sub>8</sub>" (112 mm)



## DETERMINING MOUNTING LOCATION FOR ADA-COMPLIANT WALL TILES

- 4. Draw Line 3 approximately 4 3/6" (112 mm) below Line 1. (FIGURE F)
- 5. Use Line 2 as a centerline and mark (2x) hole locations on Line 3 approximately 5 ½" (140 mm) away from the centerline, as shown. (**FIGURE G**)

NOTE: The holes should be symmetrical to Line 2 and 11" (279.4 mm) apart. (FIGURE H)



6. Repeat the previous steps for attaching the second mounting panel (B) to the other side of your display stand.

## ATTACHING MOUNTING PANEL TO WALL (CONTINUED)

1. Use electric drill and  $\frac{1}{2}$ " drill bit to drill holes in the marked locations.

#### NOTE:

- If you are securing your panel directly to wood studs, you must provide your own hardware.
- If securing to cinderblocks, avoid drilling into webs and sides as shown. (FIGURE J)
- Adjust torque on electric drill to the "drill" setting.
- Plastic Cap D Plastic Straps FIGURE K
- 4. Secure the anchor by firmly sliding the plastic cap along the straps until the flange of the cap is flush with the wall.
- 5. Snap off plastic straps from the anchor by carefully bending them toward the wall. (**FIGURE M**)



- 2. Insert SNAPTOGGLE® anchor (D) into a hole by holding the metal channel flat alongside the plastic straps and sliding the channel through the hole as shown.
  (FIGURE K)
- 3. Make the plastic strap handles even to force the metal channel perpendicular to the entire anchor. (**FIGURE L**)



- 6. Repeat steps 2 5 to insert SNAPTOGGLE anchors (D) into all of your location holes drilled during step 1.
- Align holes on mounting panel (B) with drilled holes. (FIGURE N)

## NOTE:

- Mounting panel (B) arrow should be pointing up when attaching to the wall.
- Adjust torque on electric drill to lightest setting and only increase as necessary.
- Use electric drill and Phillips bit to screw ¼"-20 x 2½" bolts (F) and ¼" washers (E) through each hole on your panel and into each corresponding anchor.



Sides FIGURE J

Web

## ATTACHING ADA-COMPLIANT WALL TILE

1. Carefully lift your ADA -Compliant wall tile (A) and insert the back face of your tile into mounting panel (B), as shown. (**FIGURE P**)

**NOTE:** Mounting panel should be secured to a wall prior to attaching your wall tile.



**FIGURE P** 

2. Repeat the previous step to your second wall tile.

**NOTE:** Side view of wall tile and mounting panel assembly shown for clarity.



#### WARRANTY

For warranty information, refer to www.legrandav.com/policies/warranty\_information.

#### **Contacting Corporate Headquarters**

P: (866) 977-3901 | F: (877) 894-6918 | www.legrandav.com | av.support@legrand.com

#### **Contacting Middle Atlantic Canada**

P: (888) 766-9770 | F: (888) 599-5009 | ca.middleatlantic.com | av.canada.customerservice@legrand.com

**Contacting Middle Atlantic Europe, Middle East, and Africa (EMEA) Technical Support** P: +31 495-726-003 | av.emea.middleatlantic.support@legrand.com

United States (US) Legrand | AV Headquarters 6436 City West Parkway Eden Prairie, MN, 55344, USA **European Union (EU)** Legrand AV Netherlands B.V. Franklinstraat 14 6003 DK, Weert, Netherlands United Kingdom (UK) Starline Holding Technology Ltd. (Authorized Representative) Unit C, Island Rd. Reading RG2, 0RP- UK

At Legrand AV Inc. we are always listening. Your comments are welcome. Legrand AV is an ISO 9001 and ISO 14001 Registered Company.

