





INSTALLATIONS INSTRUCTION



MODEL: SUNC-ST600-7965SS/ SUNC-ST600-7977BLACK
SUNC-ST1200-7966SS/ SUNC-ST1200-7978BLACK
SUNC-ST1800-7967SS/ SUNC-ST1800-7979BLACK


Side table, x 1 (600mm)

MODEL: SUNC-ST600-7965SS/ SUNC-ST600-7977BLACK





Side table, x 2 (1200mm)

MODEL: SUNC-ST1200-7966SS/ SUNC-ST1200-7978BLACK




Side table, x 3 (1800mm)

MODEL: SUNC-ST1800-7967SS/ SUNC-ST1800-7979BLACK




4.Connection Steps


Step 1



Step 2



Step 3



Step 4

