

# SKELDERVIK<sup>o</sup>

DIGNITY AND DESIGN – MADE IN SWEDEN



Together with selected elements, professional knowledge and classic lines - we give you the experience of functionality, quality and style.

Skeldervik is an outdoor kitchen manufactured in Sweden, built to stand the weather of four seasons, year after year.

## USE - Charcoal grill

Lift off the detachable grill rack and fill with charcoal or briquettes. Add lighter fluid and let the charcoal absorb the fluid before lighting the grill. Empty the ashes by pulling out the tray below the grill.

Light the grill and let it burn out before using for the first time!



## CARE INSTRUCTIONS - Skeldervik outdoor kitchen

- Protect your outdoor kitchen from the elements and extend its lifespan with the help of a protective cover.
- Always keep the grill and its parts clean with the help of detergent, water and a brush.
- Avoid strong cleaning agents to prevent damage to the surface finish.
- Always use protective pads under serving dishes, cutting boards and other tableware placed on the outdoor kitchen's work surfaces. Note that the black surface is a painted finish and thus has an increased sensitivity to scratching.
- **Black painted worktops:** Should only be cleaned by wiping, do not polish.
- **Stainless steel worktops:** Ideally polished and always in the direction of the grain. Use a suitable agent for stainless steel.

# WARRANTY - Rusting

Body - high-alloyed stainless steel 304 SS - 10 years

Grill cover - 5 years

Rusting-through that occurs within 10 years after purchase is covered by the warranty. However, surface rust is a common occurrence and can, for example, occur due to inadequate cleaning. Exercise care and follow the care instructions.

The charcoal box is a consumable and thus may need to be replaced over time. The warranty only covers proven design faults.

The warranty **does not** cover:

- Improper use
- Improper cleaning
- Inadequate cleaning
- Accidents after receipt of the product

## WARNING!

- The grill shall never be used close to combustible and flammable materials.
- Intended only for outdoor use.
- Children and pets must be kept at a safe distance from the grill.
- Place the grill on a flat, stable surface with space for good ventilation.
- The grill shall never be moved when in use.
- Keep flammable fluids and substances sealed and at a safe distance from the grill.
- When lighting the grill, only fluids approved according to EN 1860-3 may be used.
- Never use petrol, alcohol or similar fluids to light the grill.
- Always exercise the utmost care during use. Parts of the grill become warm and can cause burns.
- Always use appropriate tools and utensils designed for grilling to avoid burns.
- Never empty ashes until the charcoal and/or briquettes have burned out and do not pose a fire hazard.
- Avoid strong cleaning agents and sharp objects when cleaning the grill as these can damage the surface finish.





# SKELDERVIK<sup>o</sup>

DIGNITET OCH DESIGN – ETT SVENSKT HANTVERK



Tillsammans med noga utvalda beståndsdelar, en gedigen yrkeskunskap och tidlösa linjer välkomnar vi upplevelsen av skandinavisk design. Upplevelsen av stil, funktion och kvalité.

Ett svensktillverkat utekök som i höglegerat stål är anpassat för det europeiska klimatet, år efter år.

# ANVÄNDNING - Kolgrill

Lyft bort det avtagbara grillgallret och fyll på med kol eller briketter. Tillsätt tändvätska och låt kolen absorbera innan grillen tänds. Töm askan genom att dra ut lådan under grillen.

Tänd gärna upp grillen och låt brinna ut innan en första användning!



## SKÖTSELRÅD - Skeldervik utekök

- Skydda ditt utekök från yttre påfrestningar och förläng livslängden med hjälp av ett skyddsöverdrag.
- Håll alltid grillen och dess delar rena med hjälp av diskmedel, vatten och borste.
- Undvik starka rengöringsmedel då det kan skada ytbehandlingen.
- Använd alltid skydd i form av tassar under serveringsporslin, skärbrädor och övriga detaljer som placeras på utekökets arbetsytor. Observera att den svarta ytan är lackerad och har därmed en ökad repkänslighet.
- **Svartlackerade bänkytor:** Bör endast rengöras med hjälp av avtorkning, får ej poleras.
- **Rostfria bänkytor:** Poleras med fördel och alltid i fiberriktning. Använd anpassat medel för rostfritt stål.

# GARANTI - Genomrostning

- Stomme - höglegerat rostfritt stål 304 SS - 10 år
- Grillkåpa - 5 år

Genomrostning som uppstår inom 10 år efter köpet täcks av garantin. Ytrost är dock vanligt förekommande och kan t.ex uppstå efter bristfällig rengöring. Var därför noga och följ skötselråden.

Kollådan är en förbrukningsvara och kan därför behöva bytas över tid. Garantin täcker endast påvisade konstruktionsfel.

Garantin gäller ej:

- Felaktigt bruk
- Felaktig rengöring
- Bristfällig rengöring
- Olycksfall efter mottagen produkt

## VARNING!

- Grillen ska aldrig användas nära brännbart och brandfarligt material.
- Endast avsedd för utomhusbruk.
- Barn och husdjur ska hållas på ett säkert avstånd från grillen.
- Placera grillen på plant, stabilt underlag med utrymme för god ventilation.
- Grillen ska aldrig flyttas under pågående användning.
- Håll brandfarliga vätskor och ämnen förslutna och på ett säkert avstånd från grillen.
- Vid tändning av grillen ska endast vätskor godkända enligt EN 1860-3 användas.
- Använd aldrig bensin, sprit eller motsvarande vätskor vid tändning.
- Största försiktighet ska alltid vidtas vid användning. Delar av grillen blir varma och kan ge upphov till brännskador.
- Använd alltid anpassade verktyg och redskap avsedda för grillning för att undvika brännskador.
- Töm aldrig askan förens kolen och/eller briketterna brunnit ut och är utom risk för brandfara.
- Undvik starka rengöringsmedel och skarpa föremål vid rengöring av grillen då det kan skada ytan.

