



LEMDW Emergency Lighting

Recessed Downlight

SPECIFICATIONS:

- Input Voltage: AC220-240V 50/60Hz
- Emergency Duration: >3 Hours



- Operating Environmental Temperature: 0°c - 25°C
- Battery: LEMDWBAT-02


















ENSURE ELECTRICAL SUPPLY IS DISCONNECTED/ ISOLATED BEFORE COMMENCING INSTALLATION


NOTE - To comply with regulations, installation must be carried out by qualified electrician and in accordance with the current IEE Wiring Regulations (BS7671) and Building Regulations


State	Color	LED indication	Status	Comment		
•	Green	Permanent green	Charging Mode Fully Charged	AC mode		
*	Green	Fast flashing green (0.1 sec on, 0.1 sec off)	Function test underway			
*	Green	Slow flashing green (1 sec on, 1 sec off)	Duration test underway			
•	Red	Permanent red	Load failure	Open circuit/ Short circuit Led failure (emergency mode)		
*	Red	Slow flashing red (1 sec on, 1 sec off)	Battery failure	Battery failed the duration test or function test / No battery		
0		Green and red off	DC mode	Battery operation (emergency mode)		


OPERATION

The luminaire should be connected to the mains supply for a minimum of 24 hours before operating in emergency mode as the batteries need to be fully charged before they will provide their full rated duration.










UK - 0330 0249 279 Non UK - +44 (0)1952 238 100 Supplied by LUCECO


Stafford Park 1, Telford Shropshire, England, TF3 3BD Visit our website at www.luceco.com Servicio de asistencia telefónica UK - **0330 0249 279** Non UK - +34 93 829 55 74 (EU) Luceco SE C/Bobinadora 1-5 08302 Mataró Barcelona, Spain


Visite nuestra web en www.luceco.com





Installation & Operating Instructions

















1. The bezel and lens assembly rotate to lock

10

(11)

2. Mode change switch located on emergency module



Tech Help Line

UK - **0330 0249 279**

Non UK - +44 (0)1952 238 100 Supplied by LUCEC0 Stafford Park 1, Telford, Shropshire, England, TF3 3BD

Visit our website at $\boldsymbol{www.luceco.com}$

Servicio de asistencia telefónica UK - **0330 0249 279** Non UK - +34 93 829 55 74 (EU) Luceco SE C/Bobinadora 1-5 08302 Mataró Barcelona, Spain

Visite nuestra web en www.luceco.com



Installation & Operating Instructions

LEMDW Emergency Lighting

Recessed Downlight

RECOMMENDED ROUTINE PROCEDURE

The following test is designed to ensure the continued protection of your premises and occupants. Because of the possibility of a failure of the normal lighting supply occurring shortly after a period of testing, all tests should, whenever possible, be undertaken at times of least risk, e.g. during daylight hours.

ONCE A MONTH

Each unit should be energized from its battery for about 30 seconds by simulation of a failure of the normal lighting supply to ensure the lamp operates in the emergency condition.

ONCE A YEAR

Each unit should be energized from it's battery for a 3 hour discharge test.

ONCE A DAY

Visual inspection of battery charge LED.

ROUTINE TEST RECORD

Month	Test	First Year		Second Year		Third Year		Fourth Year		Fifth Year	
		Signed	Date	Signed	Date	Signed	Date	Signed	Date	Signed	Date
1	Function										
2	Function										
3	Function										
4	Function										
5	Function										
6	Function										
7	Function										
8	Function										
9	Function										
10	Function										
11	Function										
12	Function										

Tech Help Line

UK - 0330 0249 279 Non UK - +44 (0)1952 238 100 Supplied by LUCECO Stafford Park 1, Telford, Shropshire, England, TF3 3BD

Visit our website at www.luceco.com

Servicio de asistencia telefónica UK - 0330 0249 279 Non UK - +34 93 829 55 74 (EU) Luceco SE C/Bobinadora 1-5 08302 Mataró Barcelona, Spain

Visite nuestra web en www.luceco.com