



MONTAGEANLEITUNG – MA0088

SERVIERSTATION BARISTO CLASSIC


EN Assembly instruction Serving station Baristo Classic · FR Notice de montage Poste de service Baristo Classic
IT Istruzioni d'assemblaggio Stazione di servizio Baristo Classic · ES Indicaciones de montaje Estación de servicio Baristo Classic
NO Monteringsanvisning Serveringsstasjon Baristo Classic · DK Monteringsvejledning Serveringsstation Baristo Classic
SE Monteringsanvisning Serveringsstation Baristo Classic · NL Montage instructies Bedienend station Baristo Classic
PT Instruções de montagem Estação de serviço Baristo Classic · HR Upute za sastavljanje Stanica za posluživanje Baristo Classic

VEGA







A - 1x




B - 2x




C - 1x




D - 1x




E - 2x



F - 2x



G - 8x




H - 8x




I - 8x




J - 4x




M - 6x
M7x50




N - 12x
M5x40







O - 6x
M4x35







1x
















4







5




6





7





9



10

