



MONTAGEANLEITUNG – MA0203

STEHTISCHSÄULE JARO


EN Assembly instruction Bar Table column Jaro · FR Notice de montage Colonne du tableau haut Jaro · IT Istruzioni d'assemblaggio Colonna della tabella alto Jaro
ES Indicaciones de montaje Columna de la tabla alto Jaro · NO Monteringsanvisning Tabellkolonne Jaro · DK Monteringsvejledning Tabell kolonne Jaro
SE Monteringsanvisning Tabell kolumn Jaro · NL Montage instructies Tabel kolom Jaro · PT Instruções de montagem Coluna da tabela Jaro
HR Upute za sastavljanje Stupac tablice Jaro

VEGA





A - 1x



B - 1x
M12




C - 2x
M12




19 mm




D - 1x
M12




E - 2x
M12




F - 1x




G - 1x



H - 1x
M12



I - 1x



J - 8x
M5x22

