



## MONTAGEANLEITUNG – MA0201

### TISCHSÄULE JARO


EN Assembly instruction Table column Jaro · FR Notice de montage Colonne du tableau Jaro · IT Istruzioni d'assemblaggio Colonna della tabella Jaro  
ES Indicaciones de montaje Columna de la tabla Jaro · NO Monteringsanvisning Tabellkolonne Jaro · DK Monteringsvejledning Tabel kolonne Jaro  
SE Monteringsanvisning Tabell kolumn Jaro · NL Montage instructies Tabel kolom Jaro · PT Instruções de montagem Coluna da tabela Jaro  
HR Upute za sastavljanje Stupac tablice Jaro

**VEGA**





A - 1x



B - 1x  
M12




C - 2x  
M12




19 mm




D - 1x  
M12




E - 2x  
M12




F - 1x




G - 1x



H - 1x  
M12



I - 1x



J - 8x  
M5x22

