

TDS TEAK CLEANERS

"The Professional's Choice"



TEAKDECKING SYSTEMS offers two acid-free, environmentally safe products for cleaning teak decks. Both products have been formulated to be effective teak cleaners that do not damage the teak, the caulking, or any of the surrounding painted or gel coated surfaces unlike caustic 2-part cleaners.

TDS Teak Cleaner Powder (TCP) is a concentrated cleaner that can be either sprinkled directly on the teak for heavy duty dirt and grime removal or mixed with water for a more general purpose, regularly scheduled cleaning of teak. This product is particularly good at killing the mold and bacteria that may grow on teak in some environments. Mixed with water, for general teak cleaning, TCP is a more economical solution for cleaning teak decks.

TDS Teak Cleaner Liquid (TCL) is an alkaline based low-toxicity cleaner that has all of the cleaning power of our **TCP** (powdered cleaner) in an easy to use, pre-mixed formula. **TCL** is excellent for removing dirt and heavy stains,

particularly oil, soot-based stains and fish blood. Gentle enough to be poured directly on the teak, just scrub it and wash off. **TCL** is perfect for those quick, bucket-free clean-up jobs or, as part of a general wash down, when you just want to brighten or freshen up your teak without taking the time to mix a special teak-cleaning solution.

Neither one of these products contain acids, or caustic soda in concentrations that are considered to be hazardous to the user, the environment, or for transport and storage. Of course, common sense and reasonable care must be used, as with any chemical product. Rubber gloves and boots, as well as eye protection are always in order when working with any cleaning compound.

The key to getting the best results with these products is a combination of the right equipment and application process. Please read instructions on label.



TCP 100 Teakdecking TEAK CLEANER POWDER

"The Professional's Choice"



Teak Cleaner Powder is a specially-formulated cleaner that can be mixed at various concentrations to be effective for both light and heavy cleaning. Teak Cleaner Powder is designed to not harm your teak, caulking, hardware or paint. Teak Cleaner Powder contains no acid or caustic soda and is not hazardous to user or the environment. Teak Cleaner Powder represents the state-of-the-art in ready-to-use cleaning formulations to clean your teak or other surfaces.

Warranty: Teak Cleaner Powder will perform as specified when directions are followed. No other warranty is expressed or implied. Liability limited to purchase price only.

DIRECTIONS:

FOR LIGHT CLEANING:

- 1. Mix 1/4 to 1/2 cup Teak Cleaner Powder with 1 gallon of water (preferably hot).
- 2. Brush mixture onto surface, scrubbing across the grain.
- 3. Allow to remain on the surface for up to 15 minutes, but do NOT allow to dry
- 4. Hose surface with water.

FOR HEAVY CLEANING:

- 1. DO wet the deck first.
- 2. Do NOT dilute in water.
- 3. Scatter powder sparingly over the deck.
- 4. Scrub thoroughly across the grain with a white scrub pad or soft bristle brush.
- 5. Rinse thoroughly.
- 6. Squeegee off excess water

FIRST AID:

Keep out of the reach of children. In case of contact with eyes or skin, rinse immediately with plenty of water for 15 minutes and seek medical attention. If swallowed promptly drink a large quantity of water. Do NOT induce vomiting. Seek medical attention. See MSDS for further information.



TCL 200 TEAK CLEANER LIQUID

"The Professional's Choice"



Teak Cleaner Liquid is a specially-formulated cleaner that is effective for both light and heavy cleaning in a ready-to-use form. Teak Cleaner Liquid is designed to not harm your teak, caulking, hardware or paint. Teak Cleaner Liquid contains no acid and is not hazardous to the <u>user</u> or the <u>environment</u>. Teak Cleaner Liquid represents the state-of-the-art in ready-to-use cleaning formulations to clean your teak or other surfaces.

Warranty: Teak Cleaner Liquid will perform as specified when directions are followed. No other warranty is expressed or implied. Liability limited to purchase price only.

DIRECTIONS:

FOR LIGHT CLEANING:

- 1. Lightly wet down the areas to be cleaned with water
- 2. Apply cleaner full strength and scrub with white scrub pad or soft bristle brush. Allow to soak for 10 minutes.
- 3. Always scrub cross grain (not with the grain).
- 4. If surface starts to dry, apply more cleaner.
- 5. Rinse thoroughly with water.

FOR HEAVY CLEANING:

- 1. Do NOT wet the deck first
- 2. Follow directions 2-5 above

FIRST AID:

Keep out of reach of children. May cause skin irritation. Avoid contact with skin or eyes. Harmful if swallowed. Avoid contamination of food.

In case of contact with eyes or skin, rinse immediately with plenty of water for 15 minutes and seek medical attention. If swallowed, promptly drink a large quantity of water. **Do not induce vomiting.** Seek medical attention. See MSDS for further information.

TEAKDECK CLEANING MAINTENANCE

1. DAILY

Hose off with plain water

2. MONTHLY

Clean with TCP 100 Teak Cleaner Powder

3. QUARTERLY

(or when necessary to remove stubborn stains)

Clean with TCL 200 Teak Cleaner Liquid

NOTE: FOLLOW THE INSTRUCTIONS ON THE LABELS.

The TCP 100 Powder can also be used as a multi-purpose cleaner for, among other things, exterior furniture and painted surfaces.





