

Spare parts list of DPD-100 Post Driver

No.	Name	Qty.s	Price	No.	Name	Qty.s	Price
101	Hammer block			136	Upper support plate		
102	M8X55 Hexagon socket head screw			137	Bearing 6205		
103	ø8 spring washer			138	Gland 6205		
104	Metal head			139	Shaft Retainer		
107	Impact hammer			140	Big gear		
108	Large rubber band			141	Bearing 6202		
109	O ring (Shank adapter 23.6*5)			142	Center cover		
110	Shank adapter			143	Clutch drum		
111	Broken ring gum cover			144	Circlip 35		
112	Broken ring			145	Framework oil seal 25X19-3		
113	Small rubber band			146	M8X12 Hexagon socket head cap screws		
114	Air cylinder gasket (59*69-2)			147	Gland cover		
115	Air cylinder			148	Gear shaft		
116	Front placket			149	M5X12 Sunk screw		
117	M8x45 Hexagon socket head screw			150	Gear box		
118	Gasket for front placket			151	Handle		
119	M6x30 Hexagon socket head screw, srping washer assembly			152	Tube as handle		
120	Connection rod			153	Ø8 plain washers		
121	Impact Piston			154	Switch block		
122	Lip ring			155	Reduction spring		
123	Round pin 12x44			156	Spring pocket		
124	M5x16 Hexagon socket head screw			157	Under support plate		
125	Cover for gear box			158	M14 Flange gear nut		
126	Paper washer for gear box			159	M6X12 Hexagon socket head screw		
127	Flange hexagon screw M8x16LH			160	Retainer		
128	Pressing plate			161	60-78mm piling sleeve		
129	Quill bearing NK18/20			161-1	20-45mm piling sleeve		
130	Eccentric shaft			161-2	46-60mm piling sleeve		
131	Wick			162	102mm (4") adapter		
132	Oil leveler			163	ø5 spring washer		
133	Oil leveler leather collar			164	ø6 spring washer		
134	Handle			167	spacer		
135	M6X20 hexagon socket cap screws, washers			168	6x27 straight pin		

***Parts in Yellow fill color are recommended common parts for bulk order**

Additional spare parts			
/	BMC case		
/	Locker for BMC case		
/	Wheel for BMC case		

Exploded view of DPD-100 Post Driver

