


READY TO START THE REVOLUTION?

AVOURY ONE QUICKGUIDE

 Your Avoury One needs to be left at room temperature for one hour before it is ready-to-use.

Before the first use

- 01** Rinse the water tank and fill it with fresh tap water.
- 02** Place a collecting vessel under the outlet. Press the Start-Button and wait until it shows a continuous light.
- 03** Press both filling capacity buttons simultaneously for approx. 3 seconds to set the water hardness. If required, insert a water filter into the water tank.
- 04** Press both filling capacity buttons simultaneously for approx. 3 seconds to rinse brewing chamber.
- 05** Once the machine is ready-to-use, the Start-Button will show a continuous light.

Important

- > Before you start brewing, make sure the capsule compartment is closed and wait until the Start-Button shows a continuous light.
- > Do not forget to remove the lid foil from the capsule before you use it. Otherwise the Avoury One cannot scan the code in order to brew your tee.

FILL WATER TANK

EMPTY CAPSULE CONTAINER

CARRY OUT CLEANING

CARRY OUT DESCALING

START-BUTTON

CAPSULE COMPARTMENT

BREWING TIME

FILLING CAPACITY

EVERYTHING UNDER CONTROL.



Control your Avoury One via App.

- 01** Download the Avoury app from the app store on your smartphone.
- 02** Switch on your tea machine and wait until the Start-Button is continuously lit up.
- 03** Activate Bluetooth on your smartphone (mobile) and connect your tea machine via the Avoury app.
- 04** When the Start-Button flashes, confirm the connection by pressing the Start-Button.
- 05** Once the Start-Button is illuminated constantly, the machine is ready to use.

We show you how it works.

Our application videos explain step by step what you need to know about Avoury One.



Cleaning and descaling

In order to clean and descale your machine, you need to activate the care mode by pressing the filling capacity (-) and brewing time (+) buttons simultaneously for approx. 3 seconds.



Cancel and switch off

Press and hold the Start-Button for approx. 3 seconds to switch off the machine or to cancel the brewing.

Further information can be found in the operating instructions.



Avoury.com



00800 7000 6000



Join Avoury

6000432 | DE | 12/20

AVOURY
THE TEA