



FEATURE UNIT


TV Unit Fitting Guide

wren

FI.PK.BED.222.018 - FEATURE TV 1

Supplied in pack:

x16
30mm Screw



BETWEEN TWO ROBES

The TV feature unit Assembly is comprised of 5 units:


1. Robe, **2.** Chest, **3.** TV unit, **4.** Robe, **5.** Top box

Position, Level and install units 1, 2 and 4 using the fitting guides provided with those units.


Position unit 3 to sit in line with the frontals of the other units and secure in place with the 30mm screws provided, screw from the inside of units 1, 2 and 4 into unit 3.

Position unit 5 and install using the fitting guide provided with the unit.

Screw down into unit 3 using the 30mm screws provided. Cover all screw heads with the Stick on cover caps provided with the units.



Front View



Side View



FEATURE UNIT

TV Unit Fitting Guide

wren

FI.PK.BED.222.018 - FEATURE TV 1

Supplied in pack:

BETWEEN TWO DECORS / NEXT TO WALL

This TV Feature unit Assembly is comprised of 1 units:

1. Chest, **2.** TV unit, **3.** Top box

Position, Level and install unit 1 using the fitting guide provided with that unit.

Position unit 2 to sit in line with the frontals of the other units and secure in place with the 30mm screws provided, screw from the inside of unit 1 into unit 2.

Position unit 3 and install using the fitting guide provided with the unit.

Screw down into unit 2 using the 30mm screws provided. Cover all screw heads with the stick on cover caps provided with the units.

Measure and cut the decor panel(s) to size and secure to the TV Feature unit Assembly by screwing through units 1, 2 and 3 into the decor(s)

Next to wall specific: Screw through units 1, 2 and 3, through the filler into the wall to secure the unit.

