

# Drawer Adjustment

**Page 1-2** Vogue, Easy-Fit Soft Close, Infinity and Linea Drawer Adjustment


**Page 3-5** Infinity Plus and Milano Drawer Adjustment

**Page 6-7** Easy-Fit Drawer Adjustment

## VOGUE, EASY-FIT SOFT CLOSE, INFINITY AND LINEA


### Positioning the drawer

To be able to adjust the drawer frontal, the drawer has to be pulled out of the cabinet on the runners.



### Removing the drawer cover cap

To remove the drawer cover cap (found on the side of the drawer). Place a slotted screwdriver in the small groove above the 'R' in Wren and carefully twist. This will make the cover cap pop off. Keep the cap in a safe place until needed again.



## Adjusting the hinges


Adjust the hinges to suit. As shown in the image. A phillips screwdriver will be required.

**Point 1** - Will adjust the frontal left and right.

**Point 2a** - Will adjust the frontal up and down.


**Point 2b** - Will adjust the frontal tighten once in position.

**Point 3** - Will adjust the frontal releasing fixing clip. Screw while applying downward pressure to release.




## Re-fitting the drawer cover cap

To re-fit the drawer cover cap, position the cover cap over the mechanism, aligning the clips on the cap with the cut-out in the drawer side and apply pressure. The cover cap will then snap into place.




## Re-inserting the drawer

Once all of the required adjustments have been made, slide the drawer back into the cabinet. These steps can be repeated until all drawers are positioned as required.



## Positioning the drawer

To be able to adjust the drawer frontal, the drawer has to be pulled out of the cabinet on the runners.







## Adjusting the frontal horizontally

In order to adjust the drawer, you must use the fixing clips, these can be found underneath the drawer, attached to the frontal.

**Step 1** - Press and hold both fixing clips level with the runners on the underside of the drawer.

**Step 2** - Slide the drawer left or right to adjust to the desired position.

**Step 3** - When positioned correctly, lock the drawer in place by releasing the fastening clips back into position on both sides of the drawer.




## Adjusting the frontal height (Standard drawer)

To adjust the height of the frontal, use a phillips screwdriver as required at **points 1** and **2**.

**Step 1** - Loosen the screw at **point 1**.

**Step 2** - Turn the screw at **point 2** to adjust the frontal's height. For the frontal to move up, turn the screw right and for the frontal to move down, turn the screw left.

**Step 3** - Once in the desired position re-tighten the screw at **point 1**.




## Adjusting the frontal height (Deep drawer)

To adjust the height of the frontal, use a phillips screwdriver as required at **points 1** and **2**.

**Step 1** - Loosen both of the screws at **point 1**.


**Step 2** - Turn the screw at **point 2** to adjust the frontal's height. For the frontal to move up, turn the screw right and for the frontal to move down, turn the screw left.

**Step 3** - Once in the desired position re-tighten the screws at **point 1**.




### Adjusting the rear drawer

To adjust the rear elevation of the drawer, use a Phillips screwdriver to turn the screw located at the back of the drawer.




### Re-inserting the drawer

Once you have adjusted the drawer into the desired position, slide the drawer back into the cabinet and repeat as required to adjust all drawers.



## Positioning the drawer

To be able to adjust the drawer frontal, the drawer has to be pulled out of the cabinet on the runners.







## Adjusting the drawer frontal horizontally

**Step 1** - Loosen the frontal screws on both sides of the drawer box.

**Step 2** - Adjust the drawer frontal left or right.

**Step 3** - Re-Tighten the frontal screws on both sides when in position.




## Adjusting the drawer frontal height

To adjust the height of the frontal, use a screwdriver as required at **points 1** and **2**.

**Step 1** - Loosen both of the screws at **point 1**.

**Step 2** - Turn the screw at **point 2** to adjust the frontal's height.

**Step 3** - Once in the desired position re-tighten the screws at **point 1**.



## Re-inserting the drawer

Once you have adjusted the drawer into the desired position, slide the drawer back into the cabinet and repeat as required to adjust all drawers.

