


Page 1-2 Vogue, Easy-Fit Soft Close, Infinity, Infinity Plus, Linea, Milano
Door Hinge Adjustment

Page 3 Easy-Fit Door Hinge Adjustment

VOGUE, EASY-FIT SOFT CLOSE, INFINITY, INFINITY PLUS, LINEA AND MILANO

Removing the hinge cover cap

Use a flathead screwdriver to remove the hinge cover cap by inserting it into the slot of the cover cap and twisting.




Adjusting the hinge

To adjust the hinges, use a screwdriver as required at points 1 and 2.

Point 1 - Will adjust the frontals left and right.

Point 2 - Will adjust the frontals in and out.

To move the hinges up or down, loosen the screws A and B. Manoeuvre the door, then re-tighten the screws.




Altering the soft-close

Fit the hinge cover caps to the hinges by pressing down to secure.


Adjust the soft-close to suit (if required).

The soft-close is adjusted by turning the screw at the top of the hinge clockwise or anti-clockwise.



Removing the hinge cover cap

Use a flathead screwdriver to remove the hinge cover cap by inserting it into the slot of the cover cap and twisting.




Adjusting the hinge

To adjust the hinges, use a screwdriver as required at points 1 and 2.

Point 1 - Will adjust the frontals left and right.

Point 2 - Will adjust the frontals in and out.

Point 3 - Will adjust the height of the frontal. Re-tighten the screw.



Fitting the hinge cover cap

Fit the hinge cover caps to the hinges by pressing down to secure.

