



CHEST UNIT




wren


Feature Open Chest & Storage Unit Fitting Guide

FI.PK.BED.222.016 - FEATURE CHEST 1


Supplied in pack:



(K) x8
30mm
Screw




(L) x18
15mm
Screw



2x Corner Gusset Plate




Screws and fixings for attaching to walls and chest tops are not provided as these vary depending on materials, thickness and construction. Ensure appropriate fixings are used.



Step1.

Place the unit on its side.







Ensure the tabs on the legs are rotated towards the end panels. Secure each of the legs in place with 2 x 15mm screws (**L**) per leg. Attach bottom section of legs and set all legs to the same height.



CHEST UNIT



Feature Open Chest & Storage Unit Fitting Guide

	Step 2. Position the unit and level using an 8mm hex key from inside the unit.
	Step 3. Secure corner gusset plates to the top left and right side on the back of the unit, using 4 x 15mm screws (L) per plate. Drill a pilot hole through the centre of the corner gusset plate. 
 <i>Inside View</i>	Step 4. Secure the unit to the wall by screwing through the pilot hole and gusset from step 3 into the wall.
	Step 5. Screw into any side units using the 30mm screws (K) provided to secure to the unit. Screw at the top and bottom on both sides of the unit.
	Step 6. Screw up through the top fixed shelf into the chest top using 30mm screws (K) provided to secure it in place.