

# FITTING INSTRUCTIONS



PART NUMBER: **T2T131**

---

Toyota Hiace LWB 05/2005 on  
Towing Capacity 1250Kg / Ball Load 100Kg  
Lug # L233

1. Remove towing hooks.
2. Remove rear bolt from spare wheel brace one each side and discard.
3. Remove four plastic scrivets from bottom of bumper.
4. Remove two centre bumper mounts.
5. Lift tow bar up behind bumper and fit with 6 x M12 x 1.25 bolts and washers into captive nuts in chassis rail.
6. Tighten all bolts to torque listing.
7. Re fit two plastic scrivets.
8. Fit tongue with bolts supplied.
9. Fit door sticker supplied to door.

**RECOMMENDED ASSEMBLY  
TORQUE LISTING**

<b><u>Diameter</u></b>	<b><u>Grade 8.8 Bolt</u></b>
M6	9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8