

FITTING INSTRUCTIONS



PART NUMBER: **T4T536**

Toyota Rav 4 02/06 – on
Towing Capacity 1900 Kg / Ball Load 190 Kg
Lug # L4180

- 1) Remove towing hook.
- 2) Remove two plastic scrivets from bottom of bumper bar.
- 3) Feed tow bar over plastic tabs and behind bumper bar.
- 4) Fit 4 x M12 bolts and washers through tow bar and into captive nuts in chassis rail.
- 5) Remove floor cover from boot.
- 6) Remove rear trim and lift carpet.
- 7) Using tow bar as a guide drill 2 x 11mm holes through bottom of boot well.
- 8) Fit 2 x 10mm bolts with plates through floor and fit nuts and washers.
- 9) Tighten all bolts to torque listing below.
- 10) Refit plastic scrivets into bottom of bumper bar.
- 11) Fold down boot carpet and refit trim.
- 12) Replace floor cover in boot.
- 13) Fit ball mount with pin and clip supplied.
- 14) Fit door sticker supplied to door.

ECU MUST BE FITTED WITH THIS TOWBAR

ECU SOLD SEPARATELY

RECOMMENDED ASSEMBLY TORQUE LISTING

<u>Diameter</u>	<u>Grade 8.8 Bolt</u>
M6	Nm 9.5
M8	21.7
M10	43.4
M12	77.3
M16	189.8