

Toyota Rav 4 (02/2013- 12/2018) – T4T599


Max Towing Capacity: 1500kg	Towbar Weight: kg	
Max Ball Load: 150kg	Wiring Harness Part #: UNT282	



Tools Required:

Spanners, Sockets, Torque Wrench

Kit Contents					
Item No.	Description	Qty	Item No.	Description	Qty
1.	Towbar – T4T599	1	6.	M8 x 1.25 x 30 Bolt	2
2.	Ball Mount – L4120	1	7.	M8 Shakeproof washer	2
3.	M12 x 1.25 x 40 Bolt	4	8.	M8 Flat washer	2
4.	M12 Shake proof washer	4	9. Class 4 Pin		1
5.	M12 Flat Washer	4	10.	Complaince sticker	1



Warning:

- This product is for towing purposes only and must only be loaded as shown in your vehicle Owners Manual.
- This towbar is NOT to be drilled, cut, welded or modified in any way.
- Check behind chassis rail and body panels before drilling to ensure no hazards are present

General:

- Before fitting this towbar read fitting instructions and check installation hardware is correct.
- Check that the towbar is suitable for the vehicle and be wary of any changes to the vehicle design that may conflict with the fitting of this towbar.
- After drilling, blow any filings clear, remove any swarf and treat exposed metal with a rust inhibitor.
- If this vehicle requires a bumper cut out, please check to make sure that you measure twice and check twice before cutting any panels as some bumper profiles can change. If you are not sure, then please ask your towbar supplier

FITTING INSTRUCTIONS



Toyota Rav 4 (02/2013- 12/2018) – T4T599

Step 1	Remove Rear Bumper			
Instructions Tools Torque Spec				
10mm s b. Remove c. Remove d. Unplug mud fla e. Careful	e 4 x 8mm screw in wheel arch and 1 x screw under mud flap. e 2 x 10mm scrws behind tail gate. e 6 scrivets from under bumper bar. reverse sensor plug from behind LHS p. ly unclip bumper at the top of wheel d flex outwards to unclip from body.	Trim removal tool Sockets Screwdriver	N/A	

Step 2	Preparing for Fitment		
Instruction	ons	Tools	Torque Spec
a. Remo discar	ve impact beam via 6 x M10 bolts and d.	Spanners	N/A
b. Lowe of ext	exhaust and remove L bracket from top aust.		
c. Remo	ve shipping hook from LHS		

Step 3	Install Towbar		
Instruction	15	Tools	Torque Spec
of chass into cap b. Fit 2 x M banel. c. Tighten	bar up over exhaust and fit tp bottom sis rail using 4 x M12 bolts and washers otive nuts on bottom of chassis rail. A8 bolts and washers into rear beaver all bolts with a torque wrench ng to the troque spec.	Torque Wrench Sockets Spanners	M12-77.3Nm M8-21.7Nm

FITTING INSTRUCTIONS



Toyota Rav 4 (02/2013- 12/2018) – T4T599

Step 4	Cut Bumper Bar		
	Find centre of bottom of bumper & 100mm up from bottom of bum 100mm 90mm Bottom of	nper	
Instruction	15	Tools	Torque Spec
a. Find cer	ntre bottom of bumper and measure	Air saw	N/A
45mm e	either side and 100mm up from		
bottom	of bumper.		

St	ep 5 Finishing Up		
Ins	structions	Tools	Torque Spec
a.	Refit Exhaust.	N/A	N/A
b.	Refit Bumper.		
c.	Reconnect all reverse sensors.		
d.	Fit ball mount with pin and clip supplied	I	
e.	Fir door sticker supplied to door.		
	Note: ECU must be fitted with this tow	bar	
	and is sold separately		

FITTING INSTRUCTIONS



Toyota Rav 4 (02/2013- 12/2018) - T4T599



WARRANTY STATEMENT

The manufacturer of TAG branded products, warrants your TAG Towbar for its full product life under the following conditions:

- You can show proof of purchase.
- The towbar has been correctly installed by a suitably qualified installer.
- The towbar has not been modified or abused in any way and has only been used for the purpose intended.
- The towbar was not fitted second hand to your vehicle.

The extent of this warranty includes materials and workmanship used in the manufacture of the towbar and is to the equivalent value of current, full replacement cost.

Nothing stated or implied in this warranty limits in any way, the statutory rights that you may have.

To make a claim visit the original installer in the first instance or, if you are unable to or are not satisfied with their help, then contact us directly by email at warranty@tagtowing.com