

RED WING SIZING CHARTS

A right sized garment will last longer and wear more comfortably which is safer, as it won't get in the way of your work. Ensuring the right fit only takes a couple of minutes.



MEN'S COVERALLS SIZING



Stocked sizes will vary by location. Please contact your Red Wing representative for size availability in your region.

RED WING MEASURING GUIDE

Purpose-built for the work you do, our industrial workwear is designed to fit so well, so comfortably, that it may not even seem like personal protective equipment. Key measurements necessary to ensure the best possible fit include: **Height** and **Chest**. These sizing tables and measuring instructions are intended to guide you in selecting the right size(s) for each garment style. If you don't see the size you're looking for, please contact us for information about our make-to-measure option.

TIP: For best fit, measurements should be taken directly from the body. Room for movement is already calculated into garment dimensions.

UNLINED			
CHEST	EU/RU EQUIVALENT	INCH/CM E	QUIVALENT
32	42	30"-32"	76-82 cm
34	44	32"-34"	82-86 cm
36	46	34"-36"	86-92 cm
38	48	36"-38"	92-97 cm
40	50	38"-40"	97-102 cm
42	52	40"-42"	102-107 cm
44	54	42"-44"	107-112 cm
46	56	44"-46"	112-117 cm
48	58	46"-48"	117-122 cm
50	60	48"-50"	122-127 cm
52	62	50"-52"	127-132 cm
54	64	52"-54"	132-137 cm
56	66	54"-56"	137-142 cm
58	68	56"-58"	142-147 cm
60	70	58"-60"	147-152 cm
62	72	60"-62"	152-157 cm
64	74	62"-64"	157-163 cm
66	76	64"-66"	163-168 cm
68	78	66"-68"	168-173 cm
70	80	68"-70"	173-178 cm
HEIGHT	INCH/CM EQUIVALENT		
Short	up to 5' 9"	up to 175 cm	
Regular	up to 6' 1"	up to 185 cm	
Tall	up to 6' 4"	up to 193 cm	
Extra Tall	6' 4" and up	193 cm and up	

	INSULATED		
CHEST	INCH/CM E	QUIVALENT	
XS	34"-36"	86-92 cm	
S	36"-38"	92-97 cm	
М	38"-42"	97-107 cm	
L	42"-46"	107-117 cm	
XL	46"-50"	117-127 cm	
2XL	50"-54"	127-137 cm	
3XL	54"-58"	137-147 cm	
4XL	58"-62"	147-157 cm	
5XL	62"-66"	157-168 cm	
6XL	66"-70"	168-178 cm	
HEIGHT	INCH/CM EQUIVALENT		
Short	up to 5' 9"	up to 175 cm	
Regular	up to 6' 1"	up to 185 cm	
Tall*	up to 6' 4"	up to 193 cm	
Extra Tall*	6' 4" and up	193 cm and up	

* Tall and Extra Tall not available in XS chest size.



MEN'S SEPARATES (TOPS & BOTTOMS) SIZING



Stocked sizes will vary by location. Please contact your Red Wing representative for size availability in your region.

RED WING MEASURING GUIDE

Purpose-built for the work you do, our industrial workwear is designed to fit so well, so comfortably, that it may not even seem like personal protective equipment. Key measurements necessary to ensure the best possible fit include: Height, Chest, Waist and Inseam. These sizing tables and measuring instructions are intended to guide you in selecting the right size(s) for each garment style. If you don't see the size you're looking for, please contact us for information about our make-to-measure option.

TIP: For best fit, measurements should be taken directly from the body. Room for movement is already calculated into garment dimensions.

SHIRTS, JACKETS, PARKAS AND LAB COATS				
CHEST	INCH/CM EQUIVALENT			
XXS	32"-34"	82-86 cm		
XS	34"-36"	86-92 cm		
S	36"-38"	92-97 cm		
М	38"-42"	97-107 cm		
L	42"-46"	107-117 cm		
XL	46"-50"	117-127 cm		
2XL	50"-54"	127-137 cm		
3XL	54"-58"	137-147 cm		
4XL	58"-62"	147-157 cm		
5XL	62"-66"	157-168 cm		
6XL	66"-70"	168-178 cm		
HEIGHT	INCH/CM EQUIVALENT			
Regular	up to 6' 1"	up to 185 cm		
Tall*	up to 6' 4"	up to 193 cm		

* Shirts, jackets, lab/shop coats: tall not available in XXS chest size

* Parkas:

tall not available in XXS and XS chest size

TR	OUSERS AND JEA	NS	
WAIST	INCH/CM EQUIVALENT		
24	24"	61 cm	
26	26"	66 cm	
28	28"	71 cm	
30	30"	76 cm	
32	32"	82 cm	
34	34"	86 cm	
36	36"	92 cm	
38	38"	97 cm	
40	40"	102 cm	
42	42"	107 cm	
44	44"	112 cm	
46	46"	117 cm	
48	48"	122 cm	
50	50"	127 cm	
52	52"	132 cm	
54	54"	137 cm	
56	56"	142 cm	
58	58"	147 cm	
60	60"	152 cm	
INSEAM	CM EQUIVALENT		
28"	71 cm		
30"	76 cm		
32"	82 cm		
34"	87 cm		
0.01	00		

92 cm

36"



MEN'S BASE LAYER SIZING



RED WING MEASURING GUIDE

Purpose-built for the work you do, our industrial workwear is designed to fit so well, so comfortably, that it may not even seem like personal protective equipment. Key measurements necessary to ensure the best possible fit include: **Height, Chest** and **Waist**. These sizing tables and measuring instructions are intended to guide you in selecting the right size(s) for each garment style. If you don't see the size you're looking for, please contact us for information about our make-to-measure option.

TIP: For best fit, measurements should be taken directly from the body. Room for movement is already calculated into garment dimensions.

UNLINED TOPS			
CHEST	INCH/CM EQUIVALENT		
XS	34"-36"	86-92 cm	
S	36"-38"	92-97 cm	
М	38"-42"	97-107 cm	
L	42"-46"	107-117 cm	
XL	46"-50"	117-127 cm	
2XL	50"-54"	127-137 cm	
3XL	54"-58"	137-147 cm	
4XL	58"-62"	147-157 cm	

UNLINED BOTTOMS				
WAIST	INCH/CM EQUIVALENT			
XS	24"-28"	61-71 cm		
S	28"-32"	71-81 cm		
Μ	32"-36"	81-91 cm		
L	36"-40"	91-102 cm		
XL	40"-44"	102-112 cm		
2XL	44"-48"	112-122 cm		
3XL	48"-52"	122-132 cm		
HEIGHT	INCH/CM EQUIVALENT			
Regular	up to 6' 1"	up to 185 cm		

Stocked sizes will vary by location. Please contact your Red Wing representative for size availability in your region.



MEN'S BIB 'N' BRACES SIZING



Stocked sizes will vary by location. Please contact your Red Wing representative for size availability in your region.

RED WING MEASURING GUIDE

Purpose-built for the work you do, our industrial workwear is designed to fit so well, so comfortably, that it may not even seem like personal protective equipment. Key measurements necessary to ensure the best possible fit include: **Height, Waist** and **Inseam**. These sizing tables and measuring instructions are intended to guide you in selecting the right size(s) for each garment style. If you don't see the size you're looking for, please contact us for information about our make-to-measure option.

TIP: For best fit, measurements should be taken directly from the body. Room for movement is already calculated into garment dimensions.

UNLINED		
WAIST	CM EQUIVALENT	
24"	61 cm	
26"	66 cm	
28"	71 cm	
30"	76 cm	
32"	82 cm	
34"	86 cm	
36"	92 cm	
38"	97 cm	
40"	102 cm	
42"	107 cm	
44"	112 cm	
46"	117 cm	
48"	122 cm	
50"	127 cm	
52"	132 cm	
54"	137 cm	
56"	142 cm	
58"	147 cm	
60"	152 cm	

	INSULATED	
WAIST	INCH/CM E	QUIVALENT
XS	28"	71 cm
S	30"	76 cm
М	34"	86 cm
L	38"	97 cm
XL	42"	107 cm
2XL	46"	117 cm
3XL	50"	127 cm
4XL	52"	132 cm
5XL	56"	142 cm
6XL	60"	152 cm

HEIGHT	INCH/CM EQUIVALENT		INSEAM EQ	UIVALENT
Short	up to 5' 9"	up to 175 cm	30"	76 cm
Regular	up to 6' 1"	up to 185 cm	32"	82 cm
Tall*	6' 1" and up	185 cm and up	36"	92 cm

* Insulated bib 'n' brace: tall not available in XS chest size



RAINWEAR SIZING



RED WING MEASURING GUIDE

Purpose-built for the work you do, our industrial workwear is designed to fit so well, so comfortably, that it may not even seem like personal protective equipment. Key measurements necessary to ensure the best possible fit include: **Chest** and **Waist**. These sizing tables and measuring instructions are intended to guide you in selecting the right size(s) for each garment style. If you don't see the size you're looking for, please contact us for information about our make-to-measure option.

TIP: For best fit, measurements should be taken directly from the body. Room for movement is already calculated into garment dimensions.

COVERALL, PARKA, JACKET, VEST			
INCH/CM EQUIVALENT			
34"-36"	86-92 cm		
36"-38"	92-97 cm		
38"-42"	97-107 cm		
42"-46"	107-117 cm		
46"-50"	117-127 cm		
50"-54"	127-137 cm		
54"-58"	137-147 cm		
58"-62"	147-157 cm		
	INCH/CM E 34"-36" 36"-38" 38"-42" 42"-46" 46"-50" 50"-54" 54"-58"		

	BIB 'N' BRACE	
WAIST	INCH/CM EQUIVALENT	
XS	29"-30"	74-77 cm
S	30"-31"	77-80 cm
Μ	31"-32"	80-83 cm
L	33"-34"	83-86 cm
XL	34"-35"	86-89 cm
2XL	35"-36"	89-92 cm
3XL	36"-37"	92-95 cm
4XL	37"-38"	95-98 cm

Stocked sizes will vary by location.
Please contact your Red Wing
representative for size availability
in your region.

UNLINED BOTTOMS				
WAIST	INCH/CM EQUIVALENT			
XS	28"-29"	72-74 cm		
S	29"-30"	74-77 cm		
М	30"-31"	77-80 cm		
L	31"-32"	80-83 cm		
XL	33"-34"	83-86 cm		
2XL	34"-35"	86-89 cm		
3XL	35"-36"	89-92 cm		
4XL	36"-37"	92-95 cm		



WOMEN'S COVERALLS SIZING



Stocked sizes will vary by location. Please contact your Red Wing representative for size availability in your region.

RED WING MEASURING GUIDE

Purpose-built for the work you do, our industrial workwear is designed to fit so well, so comfortably, that it may not even seem like personal protective equipment. Key measurements necessary to ensure the best possible fit include: Height and Chest. These sizing tables and measuring instructions are intended to guide you in selecting the right size(s) for each garment style. If you don't see the size you're looking for, please contact us for information about our make-to-measure option.

TIP: For best fit, measurements should be taken directly from the body. Room for movement is already calculated into garment dimensions.

UNLINED					
US WOMEN'S	EU/RU EQUIVALENT	CHEST INCH/CM EQUIVALENT			
4	32	32"	81 cm		
6	34	34"	86 cm		
8	36	36"	92 cm		
10	38	38"	97 cm		
12	40	40"	102 cm		
14	42	42"	107 cm		
16	44	44"	112 cm		
18	46	46"	117 cm		
20	48	48"	122 cm		
22	50	50"	127 cm		
24	52	52"	132 cm		
26	54	54"	137 cm		
HEIGHT	INCH/CM E				
Short	up to 5' 3"	up to 160 cm			
Regular	up to 5' 7"	up to 170 cm			
Tall	5' 8" and up	171 cm and up			



WOMEN'S SEPARATES (TOPS & BOTTOMS) SIZING



RED WING MEASURING GUIDE

Purpose-built for the work you do, our industrial workwear is designed to fit so well, so comfortably, that it may not even seem like personal protective equipment. Key measurements necessary to ensure the best possible fit include: Height, Chest, Waist, Hip and Inseam. These sizing tables and measuring instructions are intended to guide you in selecting the right size(s) for each garment style. If you don't see the size you're looking for, please contact us for information about our make-to-measure option.

TIP: For best fit, measurements should be taken directly from the body. Room for movement is already calculated into garment dimensions.

SHIRTS AND JACKETS				
US WOMEN'S	CHEST INCH/CM EQUIVALENT			
XS	30"-32"	76-82 cm		
S	32"-36"	82-92 cm		
Μ	36"-40"	92-102 cm		
L	40"-44"	102-112 cm		
XL	44"-48"	112-122 cm		
2XL	48"-52" 122-132			
HEIGHT	INCH/CM EQUIVALENT			
Regular	up to 5' 7"	up to 170 cm		
Tall	5' 8" and up	171 cm and up		

Stocked sizes will vary by location. Please contact your Red Wing representative for size availability in your region.

PANTS				
US WOMEN'S	WAIST INCH/CM EQUIVALENT			
4	26"	66 cm		
6	27"	68 cm		
8	28"	72 cm		
10	30"	76 cm		
12	32"	82 cm		
14	33"	84 cm		
16	35"	89 cm		
18	37"	94 cm		
20	38"	97 cm		
22	40"	102 cm		
24	42"	107 cm		
26	44"	112 cm		
HEIGHT	INCH/CM EQUIVALENT			
Short	up to 5' 3"	up to 161 cm		
Regular	up to 5' 7"	up to 170 cm		
Tall	5' 8" and up	171 cm and up		

WOMEN'S JACKETS 69037 AND 69036						
US WOMEN'S	CHEST INCH/CM EQUIVALENT		WAIST INCH/CM EQUIVALENT		HIP INCH/CM EQUIVALENT	
XS	31"-34"	80-86 cm	29"-31"	74-80 cm	32"-35"	82-88 cm
S	34"-36"	86-92 cm	31"-34"	80-86 cm	35"-37"	88-94 cm
М	36"-39"	92-98 cm	34"-36"	86-92 cm	37"-39"	94-100 cm
L	39"-41"	98-104 cm	36"-39"	92-98 cm	39"-42"	100-106 cm
XL	41"-43"	104-110 cm	39"-41"	98-104 cm	42"-44"	106-112 cm
2XL	43"-47"	110-116 cm	41"-43"	104-110 cm	44"-47"	112-118 cm
3XL	47"-48"	116-122 cm	43"-47"	110-116 cm	47"-49"	118-124 cm
4XL	48"-50"	122-128 cm	47"-48"	116-122 cm	49"-51"	124-130 cm

Measure your chest, waist and hips. Use the largest size to determine which size jacket to order. Example: If your measurements fall into 'medium' for chest and waist, but your hip measurement falls into the 'large' range, order a large.

20	44			
HEIGHT	INCH/CM EQUIVALENT		INSEAM E	UIVALENT
Short	up to 5' 3"	up to 161 cm	30"	76 cm
Regular	up to 5' 7"	up to 170 cm	32"	82 cm
Tall	5' 8" and up	171 cm and up	34"	86 cm

