



INSTRUCTIONS



Add any desired cleaning solution. Fill bucket with water to MAX WATER FILL line. DO NOT OVERFILL.



Dip mop head in water and soak thoroughly.



Place mop in the wringer basket, making sure to get all yarn strands inside.



Release locking lever and push handle down to wring.



Extend handle and snap locking lever back into place. You are ready to mop!

USE & CARE: Machine or hand wash mop head in warm, sudsy water and lay flat to dry. Do not use bleach or fabric softener.