

SPARE PARTS LIST FOR PT-85 & P-25 BLOBACK PISTOLS

25/07/14

MAR01-PT85	SLIDE ASSEMBLY FOR PT-85
MAR01-P25	SLIDE ASSEMBLY FOR P-25
MAR02	RECOIL SPRING
MAR03	OUTER BARREL
MAR03-TAC	OUTER BARREL FOR TACTICAL
MAR04	INNER BARREL ASSEMBLY
MAR04- TAC	INNER BARREL ASSEMBLY FOR TACTICAL
MAR23	TRIGGER BAR SPRING
MAR24	SAFETY
MAR25	SAFETY LOCK
MAR26	SAFETY LOCK SPRING
MAR37	HAND LEVER SPRING
MAR41-P25	FRAME FOR P25
MAR41-P85	FRAME FOR PT-85
MAR42	SLIDE BLOCK PIN
MAR43	MECHANISM FRAME PIN
MAR45	MAGAZINE CATCH SCREW
MAR50	VALVE ASSEMBLY
MAR51	PUNCTURE FRAME LEFT
MAR52	PUNCTURE FRAME RIGHT
MAR58	MAGAZINE RELEASE
MAR59	MAGAZINE RELEASE SPRING
MAR60	PUNCTURE FRAME SCREW
MAR61	SILENCER ASSEMBLY
MAR62	MOUNT ASSEMBLY LEFT
MAR63	MOUNT ASSEMBLY RIGHT
MAR64	MOUNT SCREW (S)
MAR65	MOUNT SCREW (L)
MAR66	MOUNT SCREW NUT
MAR44-PT85	MAGAZINE CATCH FOR PT-85
MAR44-P25	MAGAZINE CATCH FOR PT-25
MAR46-PT85	MAGAZINE CATCH BUTTON FOR PT-85
MAR46-P25	MAGAZINE CATCH BUTTON FOR P-25
MAR47-PT85	MAGAZINE CATCH SPRING FOR PT-85
MAR47-P25	MAGAZINE CATCH SPRING FOR P-25
MAR33	PAWL
MAR04-TAC	INNER BARREL ASSEMBLY FOR TACTICAL
MAR50-2J	VALVE ASSEMBLY FOR 2J