



|  |                                  |
|--|----------------------------------|
|  | 29 V...                          |
|  | 10 mA                            |
|  | 50/60Hz                          |
|  | 2x2,5 mm <sup>2</sup>            |
|  | x = 10                           |
|  | 4 x (Ø 0,6 mm < 8 mm < Ø 0,8 mm) |
|  | -5°C → +45°C                     |

|         |         |         |
|---------|---------|---------|
|         |         |         |
|         |         |         |
| 4000 VA | 17 A    | 4000 VA |
| 17 A    | 4000 VA | 17 A    |
| 4000 VA | 17 A    | 4000 VA |
| 17 A    | 4000 VA | 17 A    |

• Programming Button using for assigning a physical address and download application  
 • Bouton de programmation pour affectation d'une adresse physique et téléchargement d'applications  
 • Pulsante di programmazione per assegnare un indirizzo fisico e scaricare l'applicazione

• Switching Output  
 • Sorties ON/OFF  
 • Uscite di commutazione

• Channel Selection Buttons  
 • Boutons de sélection des voies  
 • Pulsanti di selezione canali

• Manual Operation Button  
 • Bouton Mode manuel  
 • Pulsante di funzionamento manuale

• 1-10V Dimming Outputs  
 • Sorties variation 1-10 V  
 • Uscite dimmerabili 1-10V

• ON/OFF, UP/DOWN Buttons  
 • Boutons ON/OFF, Montée/Descente  
 • Pulsanti ON/OFF, SU/GIÙ

• Programming LED  
 • Témoin de programmation  
 • LED programmazione

• Channel Switch Status LEDs  
 • Témoin d'état de commutation des voies  
 • LED stato commutazione di canale

