


Installation guide - Spare parts and accessories





## Solenoid valve - Manual override unit

Type EV220B 15 - EV220B 50

032R9311

032R9311



<p>A</p>  <p>Total no. = 4</p>	<p>B</p>  <p>Total no. = 2</p>	<p>C</p>  <p>Total no. = 1</p>	<p>D</p>  <p>Total no. = 1</p>
--	---	--	---

