




Original instructions

PA3XT

PA4XT




PA3XT/PA4XT




	A [mm]	B [mm]	C [mm]
PA3XT10	1025	72	111
PA3XT15	1535	72	111
PA3XT20	2025	72	111
PA3XT25	2535	72	111
PA4XT10	1025	80	121
PA4XT15	1535	80	121
PA4XT20	2025	80	121
PA4XT25	2535	80	121


1




2




3




4




5




6



7



8



Main office

Frico AB
Industrivägen 41
SE-433 61 Sävedalen
Sweden

Tel: +46 31 336 86 00
mailbox@frico.se
www.frico.net

**For latest updated information and information
about your local contact: www.frico.net**