



Indicator light

Indicator light

2 position key selector switch

Illuminated button spring-return

Illuminated button spring-return

Emergency push button

	Contacts	Diagram
Device 1	/	A2 — A3 EB
Device 2	/	A6 — A3 EB
Device 3	1NO	A1 — A7 A12 — A3 EB
Device 4	1NO	B1 — B4 B2 — B3 EB
Device 5	1NO	B1 — B5 B6 — B3 EB
Device 6	2NC	B8 — B9 B10 — B11 FD

