



Installation guide  
Solenoid valve  
Type EV220A

032R9271


032R9271




1




2




3



4



5



6

