

PRODUCT-DETAILS

6109/03-803-500

6109/03-803-500 Coverplate f. RTC



### Informations générales

Extension du type de produit	6109/03-803-500
Code de produit	2CKA006155A0066
EAN	4011395209271
Description courte	6109/03-803-500 Coverplate f. RTC
Description longue	As cover for room temperature controller with/without CO2/moisture sensor (6109/18 and 6109/28).

### Installation

Instructions et manuels	No document needed
-------------------------	--------------------

### Technique

Fiche produit, informations techniques	No document needed
Compatible Bus Systems	KNX (TP)
Product Range	KNX
Design Range	63x63 Busch-axcent Busch-axcent pur solo
Type de montage	Flush Mounted

Type of Fastening	Clamp
Finition de surface	Lacquered Glossy Glossy Lacquered
Matériau	Thermoplastic
Couleur	grey metallic
Poids de la batterie	0 g
Application Function	Blind / Shutter / Shading Control Electrical Load and Light Control Room Climate Control

## Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E4730
REACH Declaration	2CKA309999E9999
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

## Dimensions

Produit Largeur Net	63 mm
Produit Hauteur Net	63 mm
Produit Longueur Net	10.4 mm
Poids net	12.4 g

## Commande

ID du produit remplacé	6155-0-0066
------------------------	-------------

## Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E4730
--------------------------------	-----------------

## Classifications

ETIM 8	EC000018 - Insert/cover for communication technology
ETIM 9	EC000018 - Insert/cover for communication technology
Catégorie DEEE	Product Not in WEEE Scope
WEEE B2C / B2B	Business To Consumer
CN8	9032 90 00
eClass	V11.0 : 27144049

## Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
2CKA001754A4240	Cover Frame 1gang anthracite - future linear	1721-181K	1	piece

2CKA001754A4168	Cover Frame 1gang ivory white - future	1721-182	1	piece
2CKA001754A4506	Cover Frame 1gang ivory white - future linear	1721-182K-500	1	piece
2CKA001754A4529	Cover Frame 1gang aluminium silver - future linear	1721-183K-500	1	piece
2CKA001754A4173	Cover Frame 1gang studio white - future	1721-184	1	piece
2CKA001754A4527	Cover Frame 1gang studio white - future linear	1721-184 NSK-500	1	piece
2CKA001754A4504	Cover Frame 1gang studio white - future	1721-184-500	1	piece
2CKA001754A4498	Cover Frame 1gang studio white - future linear	1721-184K-500	1	piece
2CKA001754A4775	Cover Frame 1gang glass purple - Busch-axcent pur	1721-223	1	piece
2CKA001754A4760	Cover Frame 1gang glass sun - Busch-axcent pur	1721-225	1	piece
2CKA001754A4770	Cover Frame 1gang glass avocado - Busch-axcent pur	1721-226	1	piece
2CKA001754A4765	Cover Frame 1gang glass coral - Busch-axcent pur	1721-227	1	piece
2CKA001754A4755	Cover Frame 1gang glass ocean - Busch-axcent pur	1721-228	1	piece
2CKA001754A4780	Cover Frame 1gang glass oyster - Busch-axcent pur	1721-229	1	piece
2CKA001754A4790	Cover Frame 1gang paper brown - Busch-axcent pur	1721-243	1	piece
2CKA001754A4800	Cover Frame 1gang glass black - Busch-axcent pur	1721-245	1	piece
2CKA001754A4785	Cover Frame 1gang paper blue - Busch-axcent pur	1721-248	1	piece
2CKA001754A4688	Cover Frame 1gang platinum - Busch-axcent pur	1721-270-500	1	piece
2CKA001754A4708	Cover Frame 1gang black matt - Busch-axcent pur	1721-275-500	1	piece
2CKA001754A4698	Cover Frame 1gang titanium - Busch-axcent pur	1721-276-500	1	piece
2CKA001754A4437	Cover Frame 1gang white glass - Busch-axcent pur	1721-280	1	piece
2CKA001754A4409	Cover Frame 1gang black - Busch-axcent	1721-281	1	piece
2CKA001753A4126	Cover Frame 1gang black - Busch-axcent flat	1721-281/11	1	piece
2CKA001754A4543	Cover Frame 1gang brown glass - Busch-axcent pur	1721-283	1	piece
2CKA001754A4331	Cover Frame 1gang studio white - Busch-axcent	1721-284	1	piece
2CKA001753A4121	Cover Frame 1gang studio white - Busch-axcent flat	1721-284/11	1	piece
2CKA001754A4334	Cover Frame 1gang yellow - Busch-axcent	1721-285	1	piece
2CKA001754A4337	Cover Frame 1gang green - Busch-axcent	1721-286	1	piece
2CKA001754A4340	Cover Frame 1gang red - Busch-axcent	1721-287	1	piece
2CKA001754A4343	Cover Frame 1gang blue - Busch-axcent	1721-288	1	piece
2CKA001754A4805	Cover Frame 1gang slate grey - Busch-axcent pur	1721-290	1	piece
2CKA001754A4471	Cover Frame 1gang entrée grey - Busch-axcent	1721-291-500	1	piece
2CKA001754A4491	Cover Frame 1gang château-black - Busch-axcent	1721-295-500	1	piece
2CKA001754A4795	Cover Frame 1gang concrete grey - Busch-axcent pur	1721-298	1	piece
2CKA001754A4481	Cover Frame 1gang maison-beige - Busch-axcent	1721-299-500	1	piece
2CKA001754A4535	Cover Frame 1gang chrome - solo	1721-80-500	1	piece
2CKA001754A4538	Cover Frame 1gang chrome gloss - solo	1721-80G-500	1	piece
2CKA001754A4442	Cover Frame 1gang white glass - carat	1721-811	1	piece
2CKA001754A4820	Cover Frame 1gang porcelain anthracite - carat	1721-815	1	piece
2CKA001754A4258	Cover Frame 1gang bronze - carat	1721-821	1	piece
2CKA001754A4356	Cover Frame 1gang gold - carat	1721-823-101	1	piece
2CKA001754A4322	Cover Frame 1gang glass black - carat	1721-825	1	piece

2CKA001754A4360	Cover Frame 1gang chrome - carat	1721-826-101	1	piece
2CKA001754A4605	Cover Frame 1gang anthracite - Busch-Dynasty	1721-831-500	1	piece
2CKA001754A4600	Cover Frame 1gang ivory white - Busch-Dynasty	1721-832-500	1	piece
2CKA001754A4575	Cover Frame 1gang polished brass decor anthracite - Busch-Dynasty	1721-833-500	1	piece
2CKA001754A4565	Cover Frame 1gang polished brass anthracite - Busch-Dynasty	1721-835-500	1	piece
2CKA001754A4570	Cover Frame 1gang polished brass decor ivory white - Busch-Dynasty	1721-836-500	1	piece
2CKA001754A4560	Cover Frame 1gang polished brass ivory white - Busch-Dynasty	1721-838-500	1	piece
2CKA001754A4595	Cover Frame 1gang antique brass decor anthracite - Busch-Dynasty	1721-843-500	1	piece
2CKA001754A4536	Cover Frame 1gang studio white - solo	1721-84-500	1	piece
2CKA001754A4585	Cover Frame 1gang antique brass anthracite - Busch-Dynasty	1721-845-500	1	piece
2CKA001754A4590	Cover Frame 1gang antique brass decor ivory white - Busch-Dynasty	1721-846-500	1	piece
2CKA001754A4580	Cover Frame 1gang antique brass ivory white - Busch-Dynasty	1721-848-500	1	piece
2CKA001754A4254	Cover Frame 1gang stainless steel - carat	1721-860	1	piece
2CKA001754A4500	Cover Frame 1gang stainless steel - Pure Stainless Steel	1721-866K-500	1	piece
2CKA001754A4531	Cover Frame 1gang studio white matt - future linear	1721-884K-500	1	piece
2CKA001754A4532	Cover Frame 1gang black matt - future linear	1721-885K-500	1	piece
2CKA001754A4714	Cover Frame 2gang red - future linear	1722-12-182K-101	1	piece
2CKA001754A4241	Cover Frame 2gang anthracite - future linear	1722-181K	1	piece
2CKA001754A4169	Cover Frame 2gang ivory white - future	1722-182	1	piece
2CKA001754A4231	Cover Frame 2gang ivory white - future linear	1722-182K	1	piece
2CKA001754A4530	Cover Frame 2gang aluminium silver - future linear	1722-183K-500	1	piece
2CKA001754A4174	Cover Frame 2gang studio white - future	1722-184	1	piece
2CKA001754A4508	Cover Frame 2gang studio white - future	1722-184-500	1	piece
2CKA001754A4499	Cover Frame 2gang studio white - future linear	1722-184K-500	1	piece
2CKA001754A4776	Cover Frame 2gang glass purple - Busch-axcent pur	1722-223	1	piece
2CKA001754A4761	Cover Frame 2gang glass sun - Busch-axcent pur	1722-225	1	piece
2CKA001754A4771	Cover Frame 2gang glass avocado - Busch-axcent pur	1722-226	1	piece
2CKA001754A4766	Cover Frame 2gang glass coral - Busch-axcent pur	1722-227	1	piece
2CKA001754A4756	Cover Frame 2gang glass ocean - Busch-axcent pur	1722-228	1	piece
2CKA001754A4781	Cover Frame 2gang glass oyster - Busch-axcent pur	1722-229	1	piece
2CKA001754A4791	Cover Frame 2gang paper brown - Busch-axcent pur	1722-243	1	piece
2CKA001754A4801	Cover Frame 2gang glass black - Busch-axcent pur	1722-245	1	piece
2CKA001754A4786	Cover Frame 2gang paper blue - Busch-axcent pur	1722-248	1	piece
2CKA001754A4689	Cover Frame 2gang platinum - Busch-axcent pur	1722-270-500	1	piece
2CKA001754A4709	Cover Frame 2gang black matt - Busch-axcent pur	1722-275-500	1	piece
2CKA001754A4699	Cover Frame 2gang titanium - Busch-axcent pur	1722-276-500	1	piece
2CKA001754A4438	Cover Frame 2gang white glass - Busch-axcent pur	1722-280	1	piece

2CKA001754A4410	Cover Frame 2gang black - Busch-axcent	1722-281	1	piece
2CKA001753A4127	Cover Frame 2gang black - Busch-axcent flat	1722-281/11	1	piece
2CKA001754A4544	Cover Frame 2gang brown glass - Busch-axcent pur	1722-283	1	piece
2CKA001754A4332	Cover Frame 2gang studio white - Busch-axcent	1722-284	1	piece
2CKA001753A4122	Cover Frame 2gang studio white - Busch-axcent flat	1722-284/11	1	piece
2CKA001754A4335	Cover Frame 2gang yellow - Busch-axcent	1722-285	1	piece
2CKA001754A4338	Cover Frame 2gang green - Busch-axcent	1722-286	1	piece
2CKA001754A4341	Cover Frame 2gang red - Busch-axcent	1722-287	1	piece
2CKA001754A4344	Cover Frame 2gang blue - Busch-axcent	1722-288	1	piece
2CKA001754A4806	Cover Frame 2gang slate grey - Busch-axcent pur	1722-290	1	piece
2CKA001754A4472	Cover Frame 2gang entrée grey - Busch-axcent	1722-291-500	1	piece
2CKA001754A4492	Cover Frame 2gang château-black - Busch-axcent	1722-295-500	1	piece
2CKA001754A4796	Cover Frame 2gang concrete grey - Busch-axcent pur	1722-298	1	piece
2CKA001754A4482	Cover Frame 2gang maison-beige - Busch-axcent	1722-299-500	1	piece
2CKA001754A4537	Cover Frame 2gang chrome - solo	1722-80-500	1	piece
2CKA001754A4327	Cover Frame 2gang chrome gloss - solo	1722-80G	1	piece
2CKA001754A4443	Cover Frame 2gang white glass - carat	1722-811	1	piece
2CKA001754A4821	Cover Frame 2gang porcelain anthracite - carat	1722-815	1	piece
2CKA001754A4259	Cover Frame 2gang bronze - carat	1722-821	1	piece
2CKA001754A4357	Cover Frame 2gang gold - carat	1722-823-101	1	piece
2CKA001754A4323	Cover Frame 2gang glass black - carat	1722-825	1	piece
2CKA001754A4361	Cover Frame 2gang chrome - carat	1722-826-101	1	piece
2CKA001754A4606	Cover Frame 2gang anthracite - Busch-Dynasty	1722-831-500	1	piece
2CKA001754A4601	Cover Frame 2gang ivory white - Busch-Dynasty	1722-832-500	1	piece
2CKA001754A4576	Cover Frame 2gang polished brass decor anthracite - Busch-Dynasty	1722-833-500	1	piece
2CKA001754A4566	Cover Frame 2gang polished brass anthracite - Busch-Dynasty	1722-835-500	1	piece
2CKA001754A4571	Cover Frame 2gang polished brass decor ivory white - Busch-Dynasty	1722-836-500	1	piece
2CKA001754A4561	Cover Frame 2gang polished brass ivory white - Busch-Dynasty	1722-838-500	1	piece
2CKA001754A4596	Cover Frame 2gang antique brass decor anthracite - Busch-Dynasty	1722-843-500	1	piece
2CKA001754A4539	Cover Frame 2gang studio white - solo	1722-84-500	1	piece
2CKA001754A4586	Cover Frame 2gang antique brass anthracite - Busch-Dynasty	1722-845-500	1	piece
2CKA001754A4591	Cover Frame 2gang antique brass decor ivory white - Busch-Dynasty	1722-846-500	1	piece
2CKA001754A4581	Cover Frame 2gang antique brass ivory white - Busch-Dynasty	1722-848-500	1	piece
2CKA001754A4255	Cover Frame 2gang stainless steel - carat	1722-860	1	piece
2CKA001754A4501	Cover Frame 2gang stainless steel - Pure Stainless Steel	1722-866K-500	1	piece
2CKA001754A4415	Cover Frame 2gang studio white matt - future linear	1722-884K	1	piece
2CKA001754A4534	Cover Frame 2gang black matt - future linear	1722-885K-500	1	piece
2CKA001754A4242	Cover Frame 3gang anthracite - future linear	1723-181K	1	piece
2CKA001754A4170	Cover Frame 3gang ivory white - future	1723-182	1	piece
2CKA001754A4232	Cover Frame 3gang ivory white - future linear	1723-182K	1	piece
2CKA001754A4533	Cover Frame 3gang aluminium silver - future linear	1723-183K-500	1	piece
2CKA001754A4175	Cover Frame 3gang studio white - future	1723-184	1	piece

2CKA001754A4366	Cover Frame 3gang studio white - future linear	1723-184 NSK	1	piece
2CKA001754A4502	Cover Frame 3gang studio white - future linear	1723-184K-500	1	piece
2CKA001754A4777	Cover Frame 3gang glass purple - Busch-axcent pur	1723-223	1	piece
2CKA001754A4762	Cover Frame 3gang glass sun - Busch-axcent pur	1723-225	1	piece
2CKA001754A4772	Cover Frame 3gang glass avocado - Busch- axcent pur	1723-226	1	piece
2CKA001754A4767	Cover Frame 3gang glass coral - Busch-axcent pur	1723-227	1	piece
2CKA001754A4757	Cover Frame 3gang glass ocean - Busch-axcent pur	1723-228	1	piece
2CKA001754A4792	Cover Frame 3gang paper brown - Busch-axcent pur	1723-243	1	piece
2CKA001754A4802	Cover Frame 3gang glass black - Busch-axcent pur	1723-245	1	piece
2CKA001754A4787	Cover Frame 3gang paper blue - Busch-axcent pur	1723-248	1	piece
2CKA001754A4690	Cover Frame 3gang platinum - Busch-axcent pur	1723-270-500	1	piece
2CKA001754A4710	Cover Frame 3gang black matt - Busch-axcent pur	1723-275-500	1	piece
2CKA001754A4700	Cover Frame 3gang titanium - Busch-axcent pur	1723-276-500	1	piece
2CKA001754A4439	Cover Frame 3gang white glass - Busch-axcent pur	1723-280	1	piece
2CKA001754A4411	Cover Frame 3gang black - Busch-axcent	1723-281	1	piece
2CKA001754A4128	Cover Frame 3gang black - Busch-axcent flat	1723-281/11	1	piece
2CKA001754A4545	Cover Frame 3gang brown glass - Busch-axcent pur	1723-283	1	piece
2CKA001754A4333	Cover Frame 3gang studio white - Busch-axcent	1723-284	1	piece
2CKA001754A4123	Cover Frame 3gang studio white - Busch-axcent flat	1723-284/11	1	piece
2CKA001754A4336	Cover Frame 3gang yellow - Busch-axcent	1723-285	1	piece
2CKA001754A4339	Cover Frame 3gang green - Busch-axcent	1723-286	1	piece
2CKA001754A4342	Cover Frame 3gang red - Busch-axcent	1723-287	1	piece
2CKA001754A4345	Cover Frame 3gang blue - Busch-axcent	1723-288	1	piece
2CKA001754A4807	Cover Frame 3gang slate grey - Busch-axcent pur	1723-290	1	piece
2CKA001754A4473	Cover Frame 3gang entrée grey - Busch-axcent	1723-291-500	1	piece
2CKA001754A4493	Cover Frame 3gang château-black - Busch- axcent	1723-295-500	1	piece
2CKA001754A4797	Cover Frame 3gang concrete grey - Busch-axcent pur	1723-298	1	piece
2CKA001754A4483	Cover Frame 3gang maison-beige - Busch-axcent	1723-299-500	1	piece
2CKA001754A4540	Cover Frame 3gang chrome - solo	1723-80-500	1	piece
2CKA001754A4328	Cover Frame 3gang chrome gloss - solo	1723-80G	1	piece
2CKA001754A4444	Cover Frame 3gang white glass - carat	1723-811	1	piece
2CKA001754A4260	Cover Frame 3gang bronze - carat	1723-821	1	piece
2CKA001754A4358	Cover Frame 3gang gold - carat	1723-823-101	1	piece
2CKA001754A4324	Cover Frame 3gang glass black - carat	1723-825	1	piece
2CKA001754A4362	Cover Frame 3gang chrome - carat	1723-826-101	1	piece
2CKA001754A4607	Cover Frame 3gang anthracite - Busch-Dynasty	1723-831-500	1	piece
2CKA001754A4602	Cover Frame 3gang ivory white - Busch-Dynasty	1723-832-500	1	piece
2CKA001754A4577	Cover Frame 3gang polished brass decor anthracite - Busch-Dynasty	1723-833-500	1	piece
2CKA001754A4567	Cover Frame 3gang polished brass anthracite - Busch-Dynasty	1723-835-500	1	piece
2CKA001754A4572	Cover Frame 3gang polished brass decor ivory white - Busch-Dynasty	1723-836-500	1	piece

2CKA001754A4562	Cover Frame 3gang polished brass ivory white - Busch-Dynasty	1723-838-500	1	piece
2CKA001754A4597	Cover Frame 3gang antique brass decor anthracite - Busch-Dynasty	1723-843-500	1	piece
2CKA001754A4541	Cover Frame 3gang studio white - solo	1723-84-500	1	piece
2CKA001754A4587	Cover Frame 3gang antique brass anthracite - Busch-Dynasty	1723-845-500	1	piece
2CKA001754A4592	Cover Frame 3gang antique brass decor ivory white - Busch-Dynasty	1723-846-500	1	piece
2CKA001754A4582	Cover Frame 3gang antique brass ivory white - Busch-Dynasty	1723-848-500	1	piece
2CKA001754A4256	Cover Frame 3gang stainless steel - carat	1723-860	1	piece
2CKA001754A4319	Cover Frame 3gang stainless steel - Pure Stainless Steel	1723-866K	1	piece
2CKA001754A4416	Cover Frame 3gang studio white matt - future linear	1723-884K	1	piece
2CKA001754A4421	Cover Frame 3gang black matt - future linear	1723-885K	1	piece
2CKA001754A4243	Cover Frame 4gang anthracite - future linear	1724-181K	1	piece
2CKA001754A4171	Cover Frame 4gang ivory white - future	1724-182	1	piece
2CKA001754A4233	Cover Frame 4gang ivory white - future linear	1724-182K	1	piece
2CKA001754A4309	Cover Frame 4gang aluminium silver - future linear	1724-183K	1	piece
2CKA001754A4176	Cover Frame 4gang studio white - future	1724-184	1	piece
2CKA001754A4367	Cover Frame 4gang studio white - future linear	1724-184 NSK	1	piece
2CKA001754A4238	Cover Frame 4gang studio white - future linear	1724-184K	1	piece
2CKA001754A4778	Cover Frame 4gang glass purple - Busch-axcent pur	1724-223	1	piece
2CKA001754A4763	Cover Frame 4gang glass sun - Busch-axcent pur	1724-225	1	piece
2CKA001754A4768	Cover Frame 4gang glass coral - Busch-axcent pur	1724-227	1	piece
2CKA001754A4793	Cover Frame 4gang paper brown - Busch-axcent pur	1724-243	1	piece
2CKA001754A4803	Cover Frame 4gang glass black - Busch-axcent pur	1724-245	1	piece
2CKA001754A4788	Cover Frame 4gang paper blue - Busch-axcent pur	1724-248	1	piece
2CKA001754A4691	Cover Frame 4gang platinum - Busch-axcent pur	1724-270-500	1	piece
2CKA001754A4711	Cover Frame 4gang black matt - Busch-axcent pur	1724-275-500	1	piece
2CKA001754A4701	Cover Frame 4gang titanium - Busch-axcent pur	1724-276-500	1	piece
2CKA001754A4440	Cover Frame 4gang white glass - Busch-axcent pur	1724-280	1	piece
2CKA001754A4412	Cover Frame 4gang black - Busch-axcent	1724-281	1	piece
2CKA001753A4129	Cover Frame 4gang black - Busch-axcent flat	1724-281/11	1	piece
2CKA001754A4546	Cover Frame 4gang brown glass - Busch-axcent pur	1724-283	1	piece
2CKA001754A4346	Cover Frame 4gang studio white - Busch-axcent	1724-284	1	piece
2CKA001753A4124	Cover Frame 4gang studio white - Busch-axcent flat	1724-284/11	1	piece
2CKA001754A4348	Cover Frame 4gang yellow - Busch-axcent	1724-285	1	piece
2CKA001754A4350	Cover Frame 4gang green - Busch-axcent	1724-286	1	piece
2CKA001754A4352	Cover Frame 4gang red - Busch-axcent	1724-287	1	piece
2CKA001754A4354	Cover Frame 4gang blue - Busch-axcent	1724-288	1	piece
2CKA001754A4808	Cover Frame 4gang slate grey - Busch-axcent pur	1724-290	1	piece
2CKA001754A4474	Cover Frame 4gang entrée grey - Busch-axcent	1724-291-500	1	piece
2CKA001754A4494	Cover Frame 4gang château-black - Busch-axcent	1724-295-500	1	piece

2CKA001754A4798	Cover Frame 4gang concrete grey - Busch-axcent pur	1724-298	1	piece
2CKA001754A4484	Cover Frame 4gang maison-beige - Busch-axcent	1724-299-500	1	piece
2CKA001754A4107	Cover Frame 4gang chrome - solo	1724-80	1	piece
2CKA001754A4329	Cover Frame 4gang chrome gloss - solo	1724-80G	1	piece
2CKA001754A4445	Cover Frame 4gang white glass - carat	1724-811	1	piece
2CKA001754A4261	Cover Frame 4gang bronze - carat	1724-821	1	piece
2CKA001754A4359	Cover Frame 4gang gold - carat	1724-823-101	1	piece
2CKA001754A4325	Cover Frame 4gang glass black - carat	1724-825	1	piece
2CKA001754A4363	Cover Frame 4gang chrome - carat	1724-826-101	1	piece
2CKA001754A4608	Cover Frame 4gang anthracite - Busch-Dynasty	1724-831-500	1	piece
2CKA001754A4603	Cover Frame 4gang ivory white - Busch-Dynasty	1724-832-500	1	piece
2CKA001754A4578	Cover Frame 4gang polished brass decor anthracite - Busch-Dynasty	1724-833-500	1	piece
2CKA001754A4568	Cover Frame 4gang polished brass anthracite - Busch-Dynasty	1724-835-500	1	piece
2CKA001754A4573	Cover Frame 4gang polished brass decor ivory white - Busch-Dynasty	1724-836-500	1	piece
2CKA001754A4563	Cover Frame 4gang polished brass ivory white - Busch-Dynasty	1724-838-500	1	piece
2CKA001754A4112	Cover Frame 4gang studio white - solo	1724-84	1	piece
2CKA001754A4598	Cover Frame 4gang antique brass decor anthracite - Busch-Dynasty	1724-843-500	1	piece
2CKA001754A4588	Cover Frame 4gang antique brass anthracite - Busch-Dynasty	1724-845-500	1	piece
2CKA001754A4593	Cover Frame 4gang antique brass decor ivory white - Busch-Dynasty	1724-846-500	1	piece
2CKA001754A4583	Cover Frame 4gang antique brass ivory white - Busch-Dynasty	1724-848-500	1	piece
2CKA001754A4257	Cover Frame 4gang stainless steel - carat	1724-860	1	piece
2CKA001754A4320	Cover Frame 4gang stainless steel - Pure Stainless Steel	1724-866K	1	piece
2CKA001754A4417	Cover Frame 4gang studio white matt - future linear	1724-884K	1	piece
2CKA001754A4422	Cover Frame 4gang black matt - future linear	1724-885K	1	piece
2CKA001754A4244	Cover Frame 5gang anthracite - future linear	1725-181K	1	piece
2CKA001754A4172	Cover Frame 5gang ivory white - future	1725-182	1	piece
2CKA001754A4234	Cover Frame 5gang ivory white - future linear	1725-182K	1	piece
2CKA001754A4310	Cover Frame 5gang aluminium silver - future linear	1725-183K	1	piece
2CKA001754A4177	Cover Frame 5gang studio white - future	1725-184	1	piece
2CKA001754A4517	Cover Frame 5gang studio white - future linear	1725-184K-500	1	piece
2CKA001754A4794	Cover Frame 5gang paper brown - Busch-axcent pur	1725-243	1	piece
2CKA001754A4804	Cover Frame 5gang glass black - Busch-axcent pur	1725-245	1	piece
2CKA001754A4692	Cover Frame 5gang platinum - Busch-axcent pur	1725-270-500	1	piece
2CKA001754A4712	Cover Frame 5gang black matt - Busch-axcent pur	1725-275-500	1	piece
2CKA001754A4702	Cover Frame 5gang titanium - Busch-axcent pur	1725-276-500	1	piece
2CKA001754A4441	Cover Frame 5gang white glass - Busch-axcent pur	1725-280	1	piece
2CKA001754A4413	Cover Frame 5gang black - Busch-axcent	1725-281	1	piece
2CKA001753A4130	Cover Frame 5gang black - Busch-axcent flat	1725-281/11	1	piece
2CKA001754A4547	Cover Frame 5gang brown glass - Busch-axcent pur	1725-283	1	piece
2CKA001754A4347	Cover Frame 5gang studio white - Busch-axcent	1725-284	1	piece



2CKA001753A4125	Cover Frame 5gang studio white - Busch-axcent flat	1725-284/11	1	piece
2CKA001754A4349	Cover Frame 5gang yellow - Busch-axcent	1725-285	1	piece
2CKA001754A4351	Cover Frame 5gang green - Busch-axcent	1725-286	1	piece
2CKA001754A4353	Cover Frame 5gang red - Busch-axcent	1725-287	1	piece
2CKA001754A4355	Cover Frame 5gang blue - Busch-axcent	1725-288	1	piece
2CKA001754A4809	Cover Frame 5gang slate grey - Busch-axcent pur	1725-290	1	piece
2CKA001754A4475	Cover Frame 5gang entrée grey - Busch-axcent	1725-291-500	1	piece
2CKA001754A4495	Cover Frame 5gang château-black - Busch-axcent	1725-295-500	1	piece
2CKA001754A4799	Cover Frame 5gang concrete grey - Busch-axcent pur	1725-298	1	piece
2CKA001754A4485	Cover Frame 5gang maison-beige - Busch-axcent	1725-299-500	1	piece
2CKA001754A4108	Cover Frame 5gang chrome - solo	1725-80	1	piece
2CKA001754A4330	Cover Frame 5gang chrome gloss - solo	1725-80G	1	piece
2CKA001754A4609	Cover Frame 5gang anthracite - Busch-Dynasty	1725-831-500	1	piece
2CKA001754A4604	Cover Frame 5gang ivory white - Busch-Dynasty	1725-832-500	1	piece
2CKA001754A4579	Cover Frame 5gang polished brass decor anthracite - Busch-Dynasty	1725-833-500	1	piece
2CKA001754A4569	Cover Frame 5gang polished brass anthracite - Busch-Dynasty	1725-835-500	1	piece
2CKA001754A4574	Cover Frame 5gang polished brass decor ivory white - Busch-Dynasty	1725-836-500	1	piece
2CKA001754A4564	Cover Frame 5gang polished brass ivory white - Busch-Dynasty	1725-838-500	1	piece
2CKA001754A4113	Cover Frame 5gang studio white - solo	1725-84	1	piece
2CKA001754A4599	Cover Frame 5gang antique brass decor anthracite - Busch-Dynasty	1725-843-500	1	piece
2CKA001754A4589	Cover Frame 5gang antique brass anthracite - Busch-Dynasty	1725-845-500	1	piece
2CKA001754A4594	Cover Frame 5gang antique brass decor ivory white - Busch-Dynasty	1725-846-500	1	piece
2CKA001754A4584	Cover Frame 5gang antique brass ivory white - Busch-Dynasty	1725-848-500	1	piece
2CKA001754A4321	Cover Frame 5gang stainless steel - Pure Stainless Steel	1725-866K	1	piece
2CKA001754A4418	Cover Frame 5gang studio white matt - future linear	1725-884K	1	piece
2CKA001754A4423	Cover Frame 5gang black matt - future linear	1725-885K	1	piece
2CKA001754A4368	Cover Frame 2gang studio white - future linear	1732-184 NSK	1	piece
2CKA001754A4369	Cover Frame 3gang studio white - future linear	1733-184 NSK	1	piece
2CKA001754A4370	Cover Frame 4gang studio white - future linear	1734-184 NSK	1	piece

## Catégories

Produits basse tension → Home and Building Automation → KNX → User Operation → Solo / Alpha for Push Button Coupling Units → Environmental Sensor Cover Plates

