






7.





8.



9.



10.



❄ = 5°C

13658 000 00 Manual Installation WRT Dial 230 F86 OW

ENGINEERING  
TOMORROW



Installation & User Guide

# Danfoss *Icon*™ Dial Room Thermostat

VICUY10F/088N3653

[www.icon.danfoss.com](http://www.icon.danfoss.com)