

PRODUCT-DETAILS

1722-866K

Cover Frame 2gang stainless steel - Pure Stainless Steel



Informations générales

Extension du type de produit	1722-866K
Code de produit	2CKA001754A4318
EAN	4011395088340
Description courte	Cover Frame 2gang stainless steel - Pure Stainless Steel
Description longue	For vertical or horizontal installation. Material stainless steel. Anti fingerprint.

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	No document needed
Number of Gangs	2
Design Range	Pure Stainless Steel
Type de montage	Flush Mounted
Type of Fastening	Clamp
Sens de montage	Horizontal Vertical
Finition de surface	Untreated

	Matt
Matériau	Stainless steel
Label Space Provided	No
Couleur	stainless steel

Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E2667
REACH Declaration	2CKA309999E9999
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Produit Largeur Net	80 mm
Produit Hauteur Net	151 mm
Produit Longueur Net	11 mm
Poids net	64 g

Commande

ID du produit remplacé	1754-0-4318
------------------------	-------------

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	No Declaration needed
--------------------------------	-----------------------

Classifications

ETIM 8	EC000007 - Cover frame for domestic switching devices
ETIM 9	EC000007 - Cover frame for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144001

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
2CKA001731A1954	Rocker for Switch, Pull cord stainless steel - Pure Stainless Steel	1720-866	1	piece
2CKA001710A3812	Cover plate with legend Level switch Turn button stainless steel - Pure Stainless Steel	1740 DR/03-866	1	piece
2CKA001710A3771	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	1740 DRL-866-503	1	piece
2CKA001710A3748	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button stainless steel - Pure Stainless Steel	1740-866	1	piece

2CKA001710A3751	Cover Plate Blind cap 1 gang with Mounting plate stainless steel - Pure Stainless Steel	1742-866	1	piece
2CKA001724A4369	Cover Plate SAT 4 gang stainless steel - Pure Stainless Steel	1743/10-04-866	1	piece
2CKA001724A4378	Cover Plate SAT 4 gang stainless steel - Pure Stainless Steel	1743-04-866	1	piece
2CKA001724A4271	Cover Plate SAT 3 gang stainless steel - Pure Stainless Steel	1743-866	1	piece
2CKA001710A3766	Cover Plate telephone connector boxes (VDo) stainless steel - Pure Stainless Steel	1745-866	1	piece
2CKA001710A3768	Cover Plate Telecommunication inserts 50 x 50 mm stainless steel - Pure Stainless Steel	1746/10-866	1	piece
2CKA001710A3769	Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang stainless steel - Pure Stainless Steel	1746-866	1	piece
2CKA001710A4097	Intermediate Ring For cover plates Busch-Balance® SI stainless steel - Pure Stainless Steel	1747 BSI-866	1	piece
2CKA001710A3760	Cover Plate Data connection 2 gang stainless steel - Pure Stainless Steel	1748-866	1	piece
2CKA001710A3752	Cover Plate Cable outlet with Mounting plate stainless steel - Pure Stainless Steel	1749-866	1	piece
2CKA001710A3770	Cover Plate BNC/TNC 2 gang stainless steel - Pure Stainless Steel	1750-866	1	piece
2CKA001723A0255	Cover Plate Loudspeaker 2 gang stainless steel - Pure Stainless Steel	1751-866	1	piece
2CKA001710A3749	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key stainless steel - Pure Stainless Steel	1755 SL/PZ-866-101	1	piece
2CKA001753A0093	Cover Plate Busch-Infolicht® stainless steel - Pure Stainless Steel	1756-866	1	piece
2CKA001724A4272	Cover plate with labelling field For data connection housing 2 gang stainless steel - Pure Stainless Steel	1758-866	1	piece
2CKA001731A4003	Rocker with labelling field Symbol "bell" for Switch/push button, Single push button stainless steel - Pure Stainless Steel	1764 NLI/KI-866	1	piece
2CKA001731A1953	Rocker with labelling field for Switch/push button, Single push button stainless steel - Pure Stainless Steel	1764 NLI-866	1	piece
2CKA001710A3765	Cover Plate TAE 1 gang stainless steel - Pure Stainless Steel	1766-866	1	piece
2CKA001753A0259	Cover Plate Symbol "1" for Time switch, Toggle stainless steel - Pure Stainless Steel	1770-866-103	1	piece
2CKA001753A0302	Cover Plate Symbol "0" for Time switch, Toggle stainless steel - Pure Stainless Steel	1771-866-103	1	piece
2CKA001751A2964	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker stainless steel - Pure Stainless Steel	1785 JA-866	1	piece
2CKA001751A2996	Rocker with legend DND, MUR for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel	1785/11-866	1	piece
2CKA001751A3087	Mechanical Controls Without imprint for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel	1785-866-500	1	piece
2CKA001751A3002	Rocker DND for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786/11-866	1	piece
2CKA001751A3077	Mechanical Controls Without imprint for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786-866-500	1	piece
2CKA001751A2961	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1788-866	1	piece
2CKA001751A2963	Rocker with legend Heizung for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 H-866	1	piece
2CKA001751A2959	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 KI-866	1	piece

2CKA001751A2958	Rocker with legend Symbol "light" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 LI-866	1	piece
2CKA001751A3152	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 N-866	1	piece
2CKA001751A3162	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 ST-866	1	piece
2CKA001751A2960	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 TR-866	1	piece
2CKA001751A2957	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789-866	1	piece
2CKA001710A3757	Cover plate with legend Card for Switch/push button, Hotel card Hotel card stainless steel - Pure Stainless Steel	1792-866	1	piece
2CKA001710A3761	Cover plate with legend for Thermostat Turn button stainless steel - Pure Stainless Steel	1794 TA-866	1	piece
2CKA001710A3755	Cover plate with legend for Thermostat stainless steel - Pure Stainless Steel	1794-866	1	piece
2CKA001710A4018	Cover plate with legend for Thermostat Turn button stainless steel - Pure Stainless Steel	1795 HK-866	1	piece
2CKA001710A4050	Cover plate with legend for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 HKEA-866	1	piece
2CKA001710A3762	Cover plate with legend for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 TA-866	1	piece
2CKA001710A3756	Cover plate with legend for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795-866	1	piece
2CKA001753A0312	Cover Plate Pull cord stainless steel - Pure Stainless Steel	1796-866	1	piece
2CKA001710A3767	Cover plate with labelling field Modular Jack 2 gang stainless steel - Pure Stainless Steel	1800-866	1	piece
2CKA001710A3764	Cover plate with labelling field UAE/IAE (ISDN) 2 gang stainless steel - Pure Stainless Steel	1803-02-866	1	piece
2CKA001710A3763	Cover plate with labelling field UAE/IAE (ISDN) 1 gang stainless steel - Pure Stainless Steel	1803-866	1	piece
2CKA002013A5408	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	20 EUAB-866	1	piece
2CKA002011A6212	Socket Outlets stainless steel - Pure Stainless Steel	20 EUC-866-500	1	piece
2CKA002013A5419	Busch-Service-Socket SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	20 EUCBDR-866	1	piece
2CKA002013A5289	SCHUKO® socket insert Safety Shutter withControl light; LED /Green stainless steel - Pure Stainless Steel	20 EUCBL-866	1	piece
2CKA002013A5460	Busch-stepflight SCHUKO® socket insert Safety Shutter withNight light; LED /White stainless steel - Pure Stainless Steel	20 EUCBLI-866	1	piece
2CKA002013A5277	SCHUKO® Socket insert with print Safety Shutter stainless steel - Pure Stainless Steel	20 EUCKS/DV-866	1	piece
2CKA002013A5374	Socket Outlets Safety Shutter stainless steel - Pure Stainless Steel	20 EUCKS-866-500	1	piece
2CKA002013A5432	SCHUKO® Socket insert with labelling field Safety Shutter stainless steel - Pure Stainless Steel	20 EUCNB-866	1	piece
2CKA002013A5442	SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	20 EUCRB-866	1	piece
2CKA002018A1490	SCHUKO® socket insert with Hinged Lid stainless steel - Pure Stainless Steel	20 EUK-866	1	piece
2CKA002018A1521	SCHUKO® socket insert Safety Shutter with Hinged Lid stainless steel - Pure Stainless Steel	20 EUKB-866	1	piece
2CKA002011A3851	SCHUKO® Socket insert with labelling field stainless steel - Pure Stainless Steel	20 EUN-866	1	piece

2CKA002017A0900	Socket insert Safety Shutter French norm NF stainless steel - Pure Stainless Steel	20 MUCKS-866-500	1	piece
2CKA001751A3171	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button Push button 1 pole, 1NO stainless steel - Pure Stainless Steel	2029 UC-866	1	piece
2CKA002495A0090	Socket insert Equipotential compensation Socket outlet 2-position stainless steel - Pure Stainless Steel	2095 UC-866	1	piece
2CKA002190A0217	Socket Outlets British Standard stainless steel - Pure Stainless Steel	2190 EUC-866	1	piece
2CKA002013A5478	SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	23 EUCEB-866	1	piece
2CKA002013A5452	SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	2300 EUCEB-866	1	piece
2CKA002011A3853	Busch-Protector® SCHUKO® socket insert stainless steel - Pure Stainless Steel	2310 EUGLVA-866-11	1	piece
2CKA002130A0293	Socket Outlets stainless steel - Pure Stainless Steel	2332 UJBS-866	1	piece
2CKA002099A0243	Socket Safety Shutter stainless steel - Pure Stainless Steel	2399 UCKS-866	1	piece
2CKA001719A0221	Intermediate Ring with Hinged Lid For cover plates Busch-Balance® SI 1 gang with Sealing Ring stainless steel - Pure Stainless Steel	2518-WD-866	1	piece
2CKA001751A3181	Rocker with legend Symbol "bell" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 KI-866	1	piece
2CKA001751A3191	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 LI-866	1	piece
2CKA001751A3200	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 TR-866	1	piece
2CKA001724A4270	Cover Plate Bore hole 1 gang stainless steel - Pure Stainless Steel	2533-866	1	piece
2CKA001710A3758	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	2542 DR/01-866	1	piece
2CKA001710A3759	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	2542 DR/02-866	1	piece
2CKA001724A4403	Cover Plate XLR 1 gang stainless steel - Pure Stainless Steel	2553-866	1	piece
2CKA001753A0395	Cover Plate Modular Jack 2 gang stainless steel - Pure Stainless Steel	2561-02-866	1	piece
2CKA001753A0404	Cover Plate Modular Jack 1 gang stainless steel - Pure Stainless Steel	2561-866	1	piece
2CKA003116A0669	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA stainless steel - Pure Stainless Steel	3120 EUCEB-866	1	piece
2CKA003117A0011	Buschmat RCD - Insert RCD 30 mA stainless steel - Pure Stainless Steel	3151 UC-866	1	piece
2CKA006115A0492	6108/61-866-500 Coverplate f. CE	6108/61-866-500	1	piece
2CKA006155A0069	6109/03-866-500 Coverplate f. RTC	6109/03-866-500	1	piece
2CKA006132A0385	6122/10-866-500 BW standard	6122/10-866-500	1	piece
2CKA006115A0211	6125/01-866-500 Control element 1g w. BAU	6125/01-866-500	1	piece
2CKA006115A0223	6125/02-866-500 Control element 1/2gang	6125/02-866-500	1	piece
2CKA006116A0201	6126/01-866-500 Control element 2g w. BAU	6126/01-866-500	1	piece
2CKA006116A0213	6126/02-866-500 Control element 2/4gang	6126/02-866-500	1	piece
2CKA006117A0227	6127/01-866-500 Control element 4g w. BAU	6127/01-866-500	1	piece

2CKA006117A0239	6127/02-866-500 Control element 4/8gang	6127/02-866-500	1	piece
2CKA006134A0335	6128/28-866-500 RTC Control element 2/4g	6128/28-866-500	1	piece
2CKA006135A0162	6129/01-866-500 Control element 3/6g w. IR	6129/01-866-500	1	piece
2CKA006310A0106	6340-866-101-500 Control element 1-gang	6340-866-101-500	1	piece
2CKA006310A0114	6341-866-101-500 Rotary control element 1-gang	6341-866-101-500	1	piece
2CKA006310A0122	6342-866-101-500 Control element 3-gang	6342-866-101-500	1	piece
2CKA006310A0078	6345-866-101-500 Motion sensor	6345-866-101-500	1	piece
2CKA006430A0343	Control Element for Venetian blind stainless steel - Pure Stainless Steel	6430-866-102	1	piece
2CKA006430A0344	Cover plate with legend for Time switch Central cover plate stainless steel - Pure Stainless Steel	6435-866	1	piece
2CKA006470A0009	Cover Plate for Proximity switch stainless steel - Pure Stainless Steel	6476-866	1	piece
2CKA006400A0064	Cover Plate PowerDock 1 gang stainless steel - Pure Stainless Steel	6477-866	1	piece
2CKA006599A2959	Cover Plate for Dimmer Turn button with Neon lamp stainless steel - Pure Stainless Steel	6540-866-102	1	piece
2CKA006599A2924	Cover Plate for Cooling Central cover plate stainless steel - Pure Stainless Steel	6541-866	1	piece
2CKA006599A2926	Control Element for Switch/dimmer Single push button stainless steel - Pure Stainless Steel	6543-866-101	1	piece
2CKA006599A2927	Control Element for Dimmer Two-part button with Neon lamp stainless steel - Pure Stainless Steel	6545-866	1	piece
2CKA006730A0041	WaveLine Electronic Controls 1 channel Radio Control stainless steel - Pure Stainless Steel	6731-866-500	1	piece
2CKA006730A0042	Wall sensor 2 channel Radio Control stainless steel - Pure Stainless Steel	6732-866-500	1	piece
2CKA006730A0043	Electronic Controls 4 channel Radio Control stainless steel - Pure Stainless Steel	6733-866-500	1	piece
2CKA006730A0139	Control Element for Dimmer Two-part button stainless steel - Pure Stainless Steel	6736 FoH-866	1	piece
2CKA006800A2843	Electronic Controls stainless steel - Pure Stainless Steel	6815-866-101-500	1	piece
2CKA008200A0087	Cover Plate Loudspeaker stainless steel - Pure Stainless Steel	8253-866	1	piece
2CKA006220A0549	CP-FCC-866 C-plate Fan Coil	CP-FCC-866	1	piece
2CKA006220A0546	CP-RTC-866 C-plate RT sensor unit	CP-RTC-866	1	piece
2CKA006220A0547	MD-F-1.0.1-866 Movement detector	MD-F-1.0.1-866	1	piece
2CKA006220A0548	MSA-F-1.1.1-866 Mov. detector/actuator 1g	MSA-F-1.1.1-866	1	piece
2CKA006200A0096	MSA-F-1.1.1-866-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-866-WL	1	piece
2CKA006220A0533	Electronic Controls free@home stainless steel - solo	SR-1-866	1	piece
2CKA006220A0538	Electronic Controls free@home stainless steel - solo	SR-2-866	1	piece
2CKA006220A0535	Electronic Controls free@home stainless steel - solo	SRB-1-866	1	piece
2CKA006220A0540	Electronic Controls free@home stainless steel - solo	SRB-2-866	1	piece
2CKA006220A0537	Electronic Controls free@home stainless steel - solo	SRD-1-866	1	piece
2CKA006220A0542	Electronic Controls free@home stainless steel - solo	SRD-2-L-866	1	piece

2CKA006220A0543	Electronic Controls free@home stainless steel - solo	SRD-2-R-866	1	piece
2CKA006220A0534	Electronic Controls free@home stainless steel - solo	SRL-1-866	1	piece
2CKA006220A0539	Electronic Controls free@home stainless steel - solo	SRL-2-L-866	1	piece
2CKA006220A0544	Electronic Controls free@home stainless steel - solo	SRL-2-R-866	1	piece
2CKA006220A0536	Electronic Controls free@home stainless steel - solo	SRS-1-866	1	piece
2CKA006220A0541	Electronic Controls free@home stainless steel - solo	SRS-2-L-866	1	piece
2CKA006220A0545	Electronic Controls free@home stainless steel - solo	SRS-2-R-866	1	piece

Catégories

Produits basse tension → Wiring Accessories - Light Switch Ranges → Frames

