




1001818 ...19	1002264	230V ~50Hz	16A max.	60 x 8,5 x 4,7 cm	1,08 kg
1001820 ...21	1002265			120 x 8,5 x 4,7 cm	2,06 kg



- DE** BETRIEBSANLEITUNG TEIL A  
Deckenrosette
- EN** INSTRUCTION MANUAL PART A  
Ceiling canopy
- FR** MODE D'EMPLOI PARTIE A  
Patère
- ES** MANUAL DE INSTRUCCIONES PARTE A  
Base para techo
- IT** ISTRUZIONI PER L'USO PARTE A  
Rosone a plafone
- NL** GEBRUIKSAANWIJZING DEEL A  
Plafondrozet
- DA** DRIFTSVEJLEDNING PART A  
Loftrosette
- PL** INSTRUKCJA OBSŁUGI CZĘŚĆ A  
Rozeta sufitowa
- RU** ИНСТРУКЦИЯ ПО ЭКСПЛУАТАЦИИ ЧАСТЬ А  
Потолочное основание
- SV** BRUKSANVISNING DEL A  
Takbox
- TR** KULLANMA KILAVUZU BÖLÜM A  
Tavan motifi
- HU** HASZNÁLATI UTASÍTÁS, A. RÉSZ  
Takaróelem



1001818 ...19 ...20 ...21  
1002264 ...65