# Energy Management Energy Meter Type EM21 72R "Retro-Fit"





- Including 3 miniature split-core current sensors
- 10mm (90A), 16mm (150A) and 24mm (250A) diameter holes

- Class A (kWh) according to EN50470-3
- Class 2 (kWh) according to EN62053-21
- Accuracy ±0.5% RDG (voltage), ±1% RDG (current)
- Energy meter
- Instantaneous variables readout: 3 DGT
- Energies readout: 6+1 DGT
- System variables: W, var, PF, Hz, Phase-sequence.
- Single phase variables: V<sub>LL</sub>, V<sub>LN</sub>, A, PF
- · Energy measurements: total kWh and kvarh
- TRMS measurements of distorted sine waves (voltages/currents)
- Self power supply
- Dimensions: 4-DIN modules and 72x72mm
- Protection degree (front): IP40
- Application adaptable display and programming procedure (Easyprog function)
- Easy connections management
- Detachable display
- Multi-use housing: for both DIN-rail and panel mounting applications

## **Product Description**

Three-phase energy meter with removable front LCD display unit. The same unit can be used either as a DIN-rail mounting or a panel mounting energy meter. This general purpose threephase energy meter is suitable for both active and reactive energy metering for cost allocation but also for main electrical parameter measurement and retransmission (transducer function). Housing for DINrail mounting with IP40

(front) protection degree. Current measurements carried out by means of external miniature split-core current sensors (included) and voltage measurements carried out either by means of direct connection or by means of potential transformers. EM21-72R is provided, as standard, with a pulsating output for active energy retransmission. In addition a 2-wire RS485 communication port available as an option.

## How to order EM21 72R VV5 3 X O X X

Model —	
Range code ——	
System —	
Power supply	
Output 1	
Output 2	
Option —	

## Type Selection

**S** (\*\*): RS485 port

Range codes System		Power supply	Output 1
VV2 (*): 400V <sub>LL</sub> AC, 90A (by current sensor) VV3 (**): 400V <sub>LL</sub> AC, 150A (by current sensor) VV5 (**): 400V <sub>LL</sub> AC, 250A (by current sensor)	3 (*): balanced and unbalanced load: 3-phase, 4-wire; 3-phase, 3-wire; 2-phase, 3-wire; 1-phase, 2-wire	X (*): Self power supply from 18V to 260VAC VLN, 45 to 65 Hz (connection VL1-N)	O (*): Single static output (opto-mosfet)
Output 2  X (*): None	Options X (*): None	(*) as standard. (**) on request.	

Dawer aumahi

Custom



# Input specifications

System type: 3 Not isolated (by CT). Note: the external current trans- formers can be connected to earth individually.	Overload status	EEE indication when the value being measured is exceeding the "Continuous inputs overload" (maximum measurement capacity)
VV2: 90A VV3: 150A VV5: 250A	Max. and Min. indication	Max. instantaneous variables: 999; energies: 999 999.9 or 9 999 999. Min. instantaneous vari-
		ables: 0; energies 0.0.
Iref: see below; Un: see below  Un: 160 to 260VLN (277 to 450VLL).  Iref: 15A, Imax: 90A Iref: 20A, Imax: 150A Iref: 20A, Imax: 250A From 0,05Iref to 0,1Iref: ± (1% RDG + 3DGT) From 0,1Iref to Imax: ± (1% RDG + 1DGT) In the range Un: ±(0.5% RDG +1DGT). In the range Un:	LEDs  Max frequency	Red LED (Energy consumption) 0.01 kWh by pulse if VT ratio is <4 (VV2) or <2 (VV3 or VV5) 0.1 kWh by pulse if VT ratio is <40 (VV2) or <23 (VV3 or VV5) 1kWh by pulse if VT ratio is >40 (VV2) or >23 (VV3 or VV5) 16Hz, according to EN50470-3 Green LED (on the terminal blocks side) for power on (steady) and communica- tion status: RX-TX (in case of RS485 option only)
±(1% RDG +1DGT).		blinking.
	Measurements	See "List of the variables
±(2%RDG +2DGT). ±[0.001+2%(1.000 - "PF RDG")].	Method Coupling type	that can be connected to:" TRMS measurements of distorted wave forms. By means of external CT's.
		≤3 (VV2: 230A max. peak)
EN50470-3; class 2 according to EN62053-21. VV2: 75mA.	Current Overloads Continuous	Without valid measurement VV2: 120A VV3: 300A VV5: 360A
		1.2 Un
S200ppm/ C @ PF=1 Phase error: ≤0.05/°C	For 500ms	2 Un
1600 samples/s @ 50Hz, 1900 samples/s @ 60Hz	Voltage input impedance Self-power supply	Power consumption: <2VA.
1 second	Frequency	45 to 65 Hz.
2 lines 1st line: 7-DGT, 2nd line: 3-DGT or 1st line: 3-DGT + 3-DGT, 2nd line: 3-DGT. LCD, h 7mm. 3-DGT. Imported Total: 6+1DGT or 7DGT	Key-pad	Two push buttons for variable selection and programming of the instrument working parameters.
	Not isolated (by CT). Note: the external current transformers can be connected to earth individually.  VV2: 90A VV3: 150A VV5: 250A VV5: 250A VVX: 400VLL  Iref: see below; Un: see below  Un: 160 to 260VLN (277 to 450VLL).  Iref: 15A, Imax: 90A Iref: 20A, Imax: 150A Iref: 20A, Imax: 250A From 0,05Iref to 0,1Iref: ± (1% RDG + 3DGT) From 0,1Iref to Imax: ± (1% RDG + 1DGT) In the range Un: ± (1% RDG +1DGT). In the range Un: ± (1% RDG +2DGT). Range: 45 to 65Hz; resolution: ±1Hz ± (2%RDG +2DGT). ± (2%RDG +2DGT). ± (3%RDG +2DGT). class A according to EN50470-3; class 2 according to EN62053-21. VV2: 75mA. VV3, VV5: 100mA  ≤200ppm/°C @ PF=1 Phase error: ≤0.05/°C  1600 samples/s @ 50Hz, 1900 samples/s @ 60Hz 1 second 2 lines 1st line: 3-DGT or 1st line: 3-DGT or 1st line: 3-DGT or 1st line: 3-DGT or 1st line: 3-DGT. LCD, h 7mm. 3-DGT. Imported Total: 6+1DGT or	Not isolated (by CT). Note: the external current transformers can be connected to earth individually.  VV2: 90A VV3: 150A VV5: 250A VV5: 250A VV5: 400VLL  Iref: see below; Un: see below  Un: 160 to 260VLN (277 to 450VLL).  Iref: 15A, Imax: 90A Iref: 20A, Imax: 150A Iref: 20A, Imax: 250A From 0,05lref to 0,1lref: ± (1% RDG + 1DGT) In the range Un: ±(0.5% RDG +1DGT). In the range Un: ±(1% RDG +1DGT). In the range Un: ±(2%RDG +2DGT). ±(2.5% RDG +2DGT). ±(2.5%RDG +2DGT). ±(2.001+2%(1.000 - "PF RDG")].  dass A according to EN50470-3; class 2 according to EN50470-3; class 3 according to EN50470-3; class 3 according to EN50470-3; class 4 according to EN50470-3; class 5 according to EN50470-3; class 6 according to EN50470-3; class 7 according to EN50470-3; class 8 according to EN50470-3; class 9 according to EN50470-3; class



# **Output specifications**

Pulse output Number of outputs Type	1 Programmable from 0.01 to 9.99 kWh per pulses. Output connectable to the	Addresses  Protocol Data (bidirectional) Dynamic (reading only)	247, selectable by means of the front keypad MODBUS/JBUS (RTU)  System and phase vari-
Pulse duration	energy meters (kWh) ≥100ms < 120ms (ON), ≥120ms (OFF), according to EN62052-31.	Static (reading and writing)	ables: see table "List of variables" All the configuration parameters.
Output	Static: opto-mosfet.	Data format	1 start bit, 8 data bit, no
Load	V <sub>ON</sub> 2.5 VAC/DC max. 70 mA,		parity,1 stop bit.
Insulation	V <sub>OFF</sub> 260 VAC/DC max. By means of optocouplers, 4000 VRMS output to mea- suring inputs.	Baud-rate Driver input capability	9600 bits/s. 1/5 unit load. Maximum 160 transceiver on the same bus.
RS485		Insulation	By means of optocouplers,
Type Connections	Multidrop, bidirectional (static and dynamic variables) 2-wire. Max. distance 1000m, termination directly on the instrument.		4000 VRMS output to measuring input.

# **Software functions**

Password	Numeric code of max. 3 digits;	System 2-Ph System 1-Ph	2-phase (3-wire) 1-phase (2-wire)
1st level 2nd level Programming lock	2 protection levels of the programming data: Password "0", no protection; Password from 1 to 999, all data are protected By means of potentiometer (back-side of the display module) it is possible to lock the access to all the configuration parameters.	Transformer ratio VT (PT) CT	1.0 to 99.9 / 100 to 999 / 1.00k to 6.00k Fixed primary: 90, 150 or 250A. The maximum power being measured cannot exceed 210 MW calculated as maximum input voltage and current, (see the "Accuracy" paragraph).
System selection System 3-Ph.n unbalanced load System 3-Ph.1 balanced load	3-phase (4-wire) 3-phase (3-wire) one current and 3-phase to phase voltage measurements. Note: the phase to phase voltage is calculated multiplying by 1.73 the virtual phase to neutral voltage. • 3-phase (4-wire) one current and 3-phase to neutral voltage measurements. Note: the phase to phase voltage is calculated multiplying by 1.73 the virtual phase to neutral voltage. • 3-phase (2-wire) one current and 1-phase (L1) to neutral voltage measurement.	Reset  Easy connection function	Up to 3 variables per page. See « Display pages » , 3 different set of variables available (see « Display pages ») according to the metering function being selected.  By means of the front key- pad: total energies (kWh, kvarh).  Wrong phase detection and displaying. For all the display selections, both energy measurements are dependent from the current direction, both power mea- surements are independent from the current direction. The power measurements are always positive.



# **General specifications**

Operating temperature	-20°C to +50°C (-13°F to 131°F) (R.H. from 0 to 90% non-condensing @ 40°C)	Standard compliance Safety	IEC60664, IEC61010-1 EN60664, EN61010-1	
Storage temperature	-30°C to +70°C (-22°F to 158°F) (R.H. < 90% non-condensing @ 40°C)	Metrology	EN62052-11 EN62053-21, EN62053-23, EN50470-3	
Installation category	Cat. III (IEC60664, EN60664).	Pulse output Approvals	DIN43864, IEC62053-31 CE	
Insulation (for 1 minute)	4000 VRMS between measuring inputs and digital output.	Connections Cable cross-section area	Screw-type 2.4 x 3.5 mm Min./Max. screws tightening torque: 0.4 Nm / 0.8	
Dielectric strength	4000 VRMS for 1 minute.		Nm	
Noise rejection CMRR	100 dB, 48 to 62 Hz.	Housing		
EMC Electrostatic discharges Immunity to irradiated Electromagnetic fields Burst Immunity to conducted disturbances Surge	According to EN62052-11 15kV air discharge; Test with current: 10V/m from 80 to 2000MHz; Test without any current: 30V/m from 80 to 2000MHz; On current and voltage measuring inputs circuit: 4kV  10V/m from 150KHz to 80MHz On current and voltage measuring inputs circuit:	Dimensions (WxHxD) Material  Mounting  Protection degree Front Screw terminals  Weight	72 x 72 x 65 mm Noryl PA66, self-extinguishing: UL 94 V-0 Panel and DIN-rail  IP40 IP20  Approx. 400 g (packing included)	
Radio frequency suppression	6kV; According to CISPR 22			

# **Power supply specifications**

Self power supply	18 to 260VAC (48-62Hz). Across input "VL1" and "N"	Power consumption	≤2VA/1W



## Insulation between inputs and outputs

	Measuring Inputs	Opto-Mosfet output	Communication port	Self power supply
Measuring Inputs	-	4kV	4kV	0kV
Opto-Mosfet output	4kV	-	-	4kV
Communication port	4kV	-	-	4kV
Self power supply	0kV	4kV	4kV	-

NOTE: all the models have, mandatorily, to be connected to external current transformers.

## **Used calculation formulas**

#### Phase variables

Instantaneous effective voltage

$$V_{1N} = \sqrt{\frac{1}{n} \cdot \sum_{1}^{n} (V_{1N})_{i}^{2}}$$
 Instantaneous active power

$$W_1 = \frac{1}{n} \cdot \sum_{i=1}^{n} (V_{1N})_i \cdot (A_1)_i$$

Instantaneous power factor

$$\cos \varphi_1 = \frac{W_1}{VA_1}$$

Instantaneous effective current

$$A_1 = \sqrt{\frac{1}{n} \cdot \sum_{i=1}^{n} (A_1)_i^2}$$

Instantaneous apparent power

$$V\!A_1 = V_{1N} \cdot A_1$$

Instantaneous reactive power

$$var_1 = \sqrt{(VA_1)^2 - (W_1)^2}$$

#### System variables

Equivalent three-phase voltage

$$V_{\Sigma} = \frac{V_1 + V_2 + V_3}{3} \cdot \sqrt{3}$$

Voltage asymmetry

$$ASY_{LL} = \frac{(V_{LL\,\mathrm{max}} - V_{LL\,\mathrm{min}})}{V_{LL}\,\Sigma}$$

$$ASY_{LN} = \frac{(V_{LN\,\mathrm{max}} - V_{LN\,\mathrm{min}})}{V_{LN}\,\Sigma}$$

Three-phase active power

$$VA_{\Sigma} = \sqrt{W_{\Sigma}^2 + \text{var}_{\Sigma}^2}$$

Three-phase apparent power

$$W_{\Sigma} = W_1 + W_2 + W_3$$

Three-phase power factor

$$\cos \varphi_{\Sigma} = \frac{W_{\Sigma}}{VA_{\Sigma}}$$
 (TPF)

## **Energy metering**

$$k \operatorname{var} hi = \int_{t_1}^{t_2} Qi(t) dt \cong \Delta t \sum_{t_1}^{n_2} Qnj$$

$$kWhi = \int_{t1}^{t2} Pi(t)dt \cong \Delta t \sum_{t=1}^{n2} Pnj$$

of consumption recording; n= time unit; **t**= time interval between two successive power consumptions;  $\mathbf{n_1}$ ,  $\mathbf{n_2}$  = starting and ending discrete time points of consumption recording



## List of the variables that can be connected to:

- RS485 communication port
- Pulse outputs (only "energies")

No	Variable	1-ph. sys.	2-ph. sys.	3-ph. 4-wire balanced system	3-ph. 3-wir balanced system	3-ph. 4-wire unbalanced system	3-ph. 3-wir unbalanced system	Notes
1	kWh	Х	Х	Х	Х	X	Х	Total
2	kvarh	Х	Х	Х	Х	Х	Х	Total
3	V L-N sys (1)	0	Х	Х	Х	Х	Х	sys=system (∑)
4	V L1	Х	Х	X	X	X	Х	
5	V L2	0	Х	X	X	X	X	
6	V L3	0	0	X	Х	Х	Х	
7	V L-L sys (1)	0	Х	X	X	X	Х	sys=system (∑)
8	V L1-2	0	Х	X	X	X	Х	
9	V L2-3	0	0	X	X	X	X	
10	V L3-1	0	0	X	X	X	X	
11	A L1	Х	Х	X	X	X	X	
12	A L2	0	Х	X	X	X	X	
13	A L3	0	0	X	X	X	X	
14	VA sys (1)	Х	Х	X	X	X	X	sys=system (∑)
15	VA L1 (1)	Х	Х	X	X	X	X	
16	VA L2 (1)	0	Х	X	X	X	X	
17	VA L3 (1)	0	0	X	X	X	X	
18	var sys	Х	Х	X	X	X	X	sys=system (∑)
19	var L1 (1)	Х	Х	X	X	X	X	
20	var L2 (1)	0	Х	X	X	X	X	
21	var L3 (1)	0	0	X	X	X	X	
22	W sys	Х	Х	X	X	X	Х	sys=system (∑)
23	W L1 (1)	Х	Х	X	X	X	X	
24	W L2 (1)	0	Х	X	Х	X	Х	
25	W L3 (1)	0	0	X	X	X	X	
26	PF sys	Х	Х	X	X	X	Х	sys=system (∑)
27	PF L1	Х	Х	Х	Х	X	Х	
28	PF L2	0	Х	X	Х	X	Х	
29	PF L3	0	0	Х	Х	Х	Х	
30	Hz	Х	Х	Х	Х	Х	Х	
31	Phase sequence	0	0	Х	Х	X	Х	

- (x) = available
- (o) = not available (zero indication on the display)
- (1) = Variable available only through the serial communication port RS485

# **Display pages**

No	1st variable	2nd variable	3rd variable	Note	App	licati	ons
NO	(1st half-line)	(2 <sup>nd</sup> half-line)	(2nd line)	Note	Α	В	С
		Phase sequence		The phase sequence triangle appears in any page only if there is a phase reverse	х	х	х
1	Total kWh		W sys		Х	Х	х
2	Total	kvarh	kvar sys			Х	х
3		PF sys	Hz	Indication of C, -C, L, -L depending on the quadrant	х	х	х
4	PF L1	PF L2	PF L3	Indication of C, -C, L, -L depending on the quadrant			х
5	A L1	A L2	A L3				х
6	V L1-2	V L2-3	V L3-1				х
7	V L1	V L2	V L3				х




# Additional available information on the display

Туре	1st line	2nd line	note
Meter information 1	Y. 2007	r.A0	Year of production and firmware release
Meter information 2	value	LEd (kWh)	KWh per pulse of the LED
Meter information 3	SYS [3P.n]	value	System type and connection type
Meter information 4	Ct Prin	value	Primary current transformer value
Meter information 5	Ut rAt.	value	Voltage transformer ratio
Meter information 6	PuLSE (kWh)	value	Pulse output: kWh per pulse
Meter information 7	Add	value	Serial communication address


# List of selectable applications

	Description	Notes
Α	Active energy meter	Active energy measurement with some minor parameters
В	Active and reactive energy meter	Active and reactive energy measurement with some minor parameters
С	Full set of variables	Full set of available variables can be displayed

# One instrument with double mounting capability




By means of the patented detachable display it is possible to configure the same instrument either as a panel mounting meter or...




... as DIN-rail mounting meter.


# CARLO GAVAZZI

## Wiring diagrams





#### Self power supply, system type selection: 3P.n






#### System type selection: 3P.n








Self power supply, system type selection: 3P.1



### System type selection: 2P








(\*) NOTE: For a correct power supply of the instrument, the neutral must always be connected.




## Wiring diagrams


#### System type selection: 1P




#### System type selection: 1P




## **CT** connections




# Secondary wiring diagram



## Static output wiring diagram




## RS485 port wiring diagram



**RS485 NOTE:** additional devices provided with RS485 are connected as per the picture above. The termination of the serial output is carried out only on the last instrument of the network, by means of a jumper between (B+) and (T).



## Front panel description



#### 1. Keypad

To program the configuration parameters and scroll the variables on the display.

#### 2. Pulse output LED

Red LED blinking proportional to the energy being measured.

#### 3. Display

LCD-type with alphanumeric indications to display all the measured variables.


#### 4. Connections

Screw terminal blocks for instrument wiring.


#### 5. Green LED

Lit when power supply is available

# **Dimensions (DIN configuration)**




# Dimensions and panel cut out (72x72 panel mounting configuration)






## **90A CT Dimensions**



# **150A CT Dimensions**



# **250A CT Dimensions**

