

FIBERRUNNER TO FIBERRUNNER REDUCER FITTINGS

Part Number(s): FRRF4FD2**, FRRF4FD2L**, FRRF6FR4**, FRRF6FR4SC**, FRRF6FR4L**, FRRF6FR4SCL**, FRT12X4W4**, FRTSC12W4**, FRT12X4W4L**, FRTSC12W4L**, FRFWC12X4W4**, FWCS12W4**, FRFRFWC12X4W4L**, FWCS12W4L**, FRRF126**, FRRF126SC**, FRRF126LS**, FRRF126SCL**, FRT12X4W6**, FRTSC12W6**, FRT12X4W6L**, FRTSC12W6L**, FRFWC12X4W6**, FRFWCS12W6**, FRFWC12X4W6L**, FRFWCS12W6L**, FRY126**, FRY126SC**, FRY126L**, FRY126SCL**, FRRF126LL**, FRRF126LSCL**, FRRF126R**, FRRF126RSC**, FRRF126RL**, FRRF126RSCL**, FRRF2412**, FRRF2412CV**, FRRF2412L**, FRRF2412CVL**, FRT24X4W12**, FRTCV24W12**, FRT24X4W12L**, FRTCV24W12L**, FRFWC24X4W12**, FRFWCCV24W12**, FRFWC24X4W12L**, FRFWCCV24W12L**





© Panduit Corp. 2020



INSTALLATION INSTRUCTIONS

RW138



FIBERRUNNER 4x4 to FIBERRUNNER 2x2 Reducer





FIBERRUNNER 6x4 to FIBERRUNNER 4x4 Reducer



FIBERRUNNER 12x4 Horizontal Tee with 4" Exit





FIBERRUNNER 12x4 Four-Way Cross with 4" Exits





For Technical Support: www.panduit.com/resources/install_maintain.asp



FIBERRUNNER 12x4 to FIBERRUNNER 6x4 Reducer





FIBERRUNNER 12x4 Horizontal Tee with 6" Exit





FIBERRUNNER 12x4 Four-Way Cross with 6" Exits





FIBERRUNNER 12x4 "Y" Transition with 6" Exits





FIBERRUNNER 12x4 Transition Left with 6" Exit





FIBERRUNNER 12x4 Transition Right with 6" Exit





FIBERRUNNER 24x4 to FIBERRUNNER 12x4 Reducer




FIBERRUNNER 24x4 Horizontal Tee with 12" Exit




FIBERRUNNER 24x4 Four-Way Cross with 12" Exit







FRRF6FR4SC
(split cover for FRRF6FR4)




FRTSC12W4
(split cover for FRT12X4W4)




FRFWCSC12W4
(split cover for FRFWC12X4W4)




FRTSC12W6
(split cover for FRT12X4W6)




FRFWCSC12W6
(split cover for FRFWC12X4W6)




FRRF126SC
(split cover for FRRF126)




FRRF126LSC
(split cover for FRRF126L)




FRRF126RSC
(split cover for FRRF126R)




FRY126SC
(split cover for FRY126)



FRRF2412CV
(cover for FRRF2412)



FRTCVCV24W12
(cover for FRT24X4W12)



FRFWCCV24W12
(cover for FRFWC24X4W12)

For Instructions in Local Languages
and Technical Support:
www.panduit.com/resources/install_maintain.asp

PANDUIT
www.panduit.com

E-mail:
techsupport@panduit.com
Fax:
866-405-6654