






















40016611

- DE** Montageanleitung
- ES** Instrucciones de montaje
- FR** Instructions de montage
- GB** Assembly Instructions
- IT** Istruzione di montaggio
- NL** Montagehandleiding
- PL** Instrukcja montażu

	L (mm)	H (mm)	A (mm)	B (mm)	C (mm)
750 W	800	440	400	150	250
1000 W	800	590	400	150	250
	1100	440	400	200	200
1250 W	1100	590	400	200	200
1500 W	1300	590	800	400	400
	1500	440	800	400	400
2000 W	1500	590	800	400	400





40016611

- DE** Montageanleitung
- ES** Instrucciones de montaje
- FR** Instructions de montage
- GB** Assembly Instructions
- IT** Istruzione di montaggio
- NL** Montagehandleiding
- PL** Instrukcja montażu

	L (mm)	H (mm)	A (mm)	B (mm)	C (mm)	
500 W	588	500	160	43	117	C50
	514	700	160	6	154	C51
750 W	884	500	400	185	215	C50
	588	700	160	43	117	C51
1000 W	1180	500	800	326	474	C50
	810	700	400	147	253	C51
1250 W	1476	500	800	400	400	C50
	958	700	400	220	180	C51
1500 W	1180	700	800	326	474	C51
1750 W	1402	700	800	363	437	C51

