


PRODUCT-DETAILS

6108/07-AP-500

6108/07-AP-500 Push-button coupler 4g AP



Informations générales

Extension du type de produit	6108/07-AP-500
Code de produit	2CKA006133A0227
EAN	4011395210987
Description courte	6108/07-AP-500 Push-button coupler 4g AP
Description longue	For contacting conventional 2gang rocker switches. With middle position. For inserting in the ocean surface-mounted housing. Enclosed mounting plate for the following ranges: Busch-Duro 2000® SI/SI Linear, Reflex SI/SI Linear, future® linear, alpha, solo®, Busch-axcent®, carat® and pure stainless steel. The bus can be connected via enclosed terminal block.

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	2CKA001373B8908
Tension nominale (U_r)	24 V
Auxiliary Voltage AC/DC	24 V AC/DC
Compatible Bus Systems	KNX (TP)
Product Range	KNX

Design Range	ocean 63x63 Pure Stainless Steel alpha Busch-balance SI Reflex SI/SI Linear Busch-Duro 2000
Type de montage	Flush Mounted
Nombre de batteries	0

Environnement

Température de l'air ambiant	Operation -25 ... +45 °C
Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E4588
REACH Declaration	2CKA309999E9999
SCIP	e376460c-cd29-4d59-bfba-ad99c6e3048c Germany (DE)
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Produit Largeur Net	71 mm
Produit Hauteur Net	71 mm
Produit Longueur Net	47 mm
Poids net	91 g
Profondeur d'encastrement (t ₂)	33 mm

Commande

ID du produit remplacé	6133-0-0227
------------------------	-------------

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA100000E1126
--------------------------------	-----------------

Classifications

ETIM 8	EC002466 - Touch sensor connector for bus system
ETIM 9	EC002466 - Touch sensor connector for bus system
Catégorie DEEE	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer
CN8	8536 50 80

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
-------------	-------------	------	----------	-----------------

2CKA001751A1682	Rocker for Switch/push button, Two-part rocker platinum - alpha	1785-20	1	piece
2CKA001751A1773	Rocker for Switch/push button, Two-part rocker bronze - alpha	1785-21	1	piece
2CKA001751A2706	Mechanical Controls Without imprint for Switch/push button, Two-part rocker bronze - alpha	1785-21-101	1	piece
2CKA001751A2565	Rocker for Switch/push button, Two-part rocker ivory - alpha	1785-22G	1	piece
2CKA001751A2110	Rocker for Switch/push button, Two-part rocker studio white - alpha	1785-24G	1	piece
2CKA001751A2827	Rocker for Switch/push button, Two-part rocker palladium - alpha	1785-260	1	piece
2CKA001751A3082	Mechanical Controls Without imprint for Switch/push button, Two-part rocker palladium - alpha	1785-260-500	1	piece
2CKA001751A2838	Rocker for Switch/push button, Two-part rocker titanium - alpha	1785-266	1	piece
2CKA001753A0064	Cover Plate for Switch/push button, Two-part rocker ivory - impuls	1785-72	1	piece
2CKA001753A4856	Cover Plate for Switch/push button, Two-part rocker alpine white - impuls	1785-74	1	piece
2CKA001753A0181	Cover Plate for Switch/push button, Two-part rocker studio white matt - impuls	1785-774	1	piece
2CKA001753A0152	Cover Plate for Switch/push button, Two-part rocker black matt - impuls	1785-775	1	piece
2CKA001753A0065	Cover Plate for Switch/push button, Two-part rocker aluminium silver - impuls	1785-783	1	piece
2CKA001753A5333	Cover Plate for Switch/push button, Two-part rocker champagne metallic - impuls	1785-79	1	piece
2CKA001751A3018	Rocker for Switch/push button, Two-part rocker grey metallic - 63x63	1785-803	1	piece
2CKA001751A2930	Rocker for Switch/push button, Two-part rocker anthracite - 63x63	1785-81	1	piece
2CKA001751A2744	Rocker for Switch/push button, Two-part rocker ivory white - 63x63	1785-82	1	piece
2CKA001751A2942	Rocker for Switch/push button, Two-part rocker aluminium silver - 63x63	1785-83	1	piece
2CKA001751A3092	Mechanical Controls Without imprint for Switch/push button, Two-part rocker aluminium silver - 63x63	1785-83-500	1	piece
2CKA001751A3117	Mechanical Controls Without imprint for Switch/push button, Two-part rocker antique brass - 63x63	1785-840-500	1	piece
2CKA001751A3076	Mechanical Controls Without imprint for Switch/push button, Two-part rocker studio white - 63x63	1785-84-500	1	piece
2CKA001751A3087	Mechanical Controls Without imprint for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel	1785-866-500	1	piece
2CKA001751A3024	Rocker for Switch/push button, Two-part rocker studio white matt - 63x63	1785-884	1	piece
2CKA001751A3038	Rocker for Switch/push button, Two-part rocker black matt - 63x63	1785-885	1	piece
2CKA001731A0363	Mechanical Controls Without imprint for Switch/push button, Two-part rocker white - Busch-Duro 2000	2505-212-500	1	piece
2CKA001731A1890	Mechanical Controls Without imprint for Switch/push button, Two-part rocker white - Busch-Duro 2000	2505-212-507	1	piece
2CKA001731A1993	Mechanical Controls Without imprint for Switch/push button, Single rocker alpine white - Reflex SI/SI Linear	2505-214-500	1	piece
2CKA001754A4373	Cover Frame 1gang platinum - alpha exclusive	1721 KA-20	1	piece
2CKA001754A4382	Cover Frame 1gang bronze - alpha exclusive	1721 KA-21	1	piece

2CKA001754A3831	Cover Frame 1gang ivory - alpha exclusive	1721 KA-22G	1	piece
2CKA001754A2965	Cover Frame 1gang studio white - alpha exclusive	1721 KA-24G	1	piece
2CKA001754A4520	Cover Frame 1gang palladium - alpha exclusive	1721 KA-260-500	1	piece
2CKA001754A4509	Cover Frame 1gang titanium - alpha exclusive	1721 KA-266-500	1	piece
2CKA001754A4516	Cover Frame 1gang white - Busch-Duro 2000	1721 NS-212-500	1	piece
2CKA001754A4496	Cover Frame 1gang alpine white - Reflex SI	1721 NS-214-500	1	piece
2CKA001754A4093	Cover Frame 1gang white - Busch-Duro 2000 SI Linear	1721 NSKA-212	1	piece
2CKA001754A4497	Cover Frame 1gang alpine white - Reflex SI Linear	1721 NSKA-214-500	1	piece
2CKA001754A4065	Cover Frame 1gang studio white - alpha exclusive	1721 NSKA-24G	1	piece
2CKA001754A4713	Cover Frame 1gang red - future linear	1721-12-182K-101	1	piece
2CKA001754A4240	Cover Frame 1gang anthracite - future linear	1721-181K	1	piece
2CKA001754A4168	Cover Frame 1gang ivory white - future	1721-182	1	piece
2CKA001754A4506	Cover Frame 1gang ivory white - future linear	1721-182K-500	1	piece
2CKA001754A4529	Cover Frame 1gang aluminium silver - future linear	1721-183K-500	1	piece
2CKA001754A4173	Cover Frame 1gang studio white - future	1721-184	1	piece
2CKA001754A4527	Cover Frame 1gang studio white - future linear	1721-184 NSK-500	1	piece
2CKA001754A4504	Cover Frame 1gang studio white - future	1721-184-500	1	piece
2CKA001754A4498	Cover Frame 1gang studio white - future linear	1721-184K-500	1	piece
2CKA001754A4521	Cover Frame 1gang platinum - alpha nea	1721-20-500	1	piece
2CKA001754A4522	Cover Frame 1gang bronze - alpha nea	1721-21-500	1	piece
2CKA001754A4775	Cover Frame 1gang glass purple - Busch-axcent pur	1721-223	1	piece
2CKA001754A4760	Cover Frame 1gang glass sun - Busch-axcent pur	1721-225	1	piece
2CKA001754A4770	Cover Frame 1gang glass avocado - Busch-axcent pur	1721-226	1	piece
2CKA001754A4765	Cover Frame 1gang glass coral - Busch-axcent pur	1721-227	1	piece
2CKA001754A4755	Cover Frame 1gang glass ocean - Busch-axcent pur	1721-228	1	piece
2CKA001754A4780	Cover Frame 1gang glass oyster - Busch-axcent pur	1721-229	1	piece
2CKA001754A4512	Cover Frame 1gang ivory - alpha nea	1721-22G-500	1	piece
2CKA001754A4790	Cover Frame 1gang paper brown - Busch-axcent pur	1721-243	1	piece
2CKA001754A4800	Cover Frame 1gang glass black - Busch-axcent pur	1721-245	1	piece
2CKA001754A4785	Cover Frame 1gang paper blue - Busch-axcent pur	1721-248	1	piece
2CKA001754A4503	Cover Frame 1gang studio white - alpha nea	1721-24G-500	1	piece
2CKA001754A4400	Cover Frame 1gang palladium - alpha nea	1721-260	1	piece
2CKA001754A4391	Cover Frame 1gang titanium - alpha nea	1721-266	1	piece
2CKA001754A4688	Cover Frame 1gang platinum - Busch-axcent pur	1721-270-500	1	piece
2CKA001754A4708	Cover Frame 1gang black matt - Busch-axcent pur	1721-275-500	1	piece
2CKA001754A4698	Cover Frame 1gang titanium - Busch-axcent pur	1721-276-500	1	piece
2CKA001754A4437	Cover Frame 1gang white glass - Busch-axcent pur	1721-280	1	piece
2CKA001754A4409	Cover Frame 1gang black - Busch-axcent	1721-281	1	piece
2CKA001753A4126	Cover Frame 1gang black - Busch-axcent flat	1721-281/11	1	piece

2CKA001754A4543	Cover Frame 1gang brown glass - Busch-axcent pur	1721-283	1	piece
2CKA001754A4331	Cover Frame 1gang studio white - Busch-axcent	1721-284	1	piece
2CKA001753A4121	Cover Frame 1gang studio white - Busch-axcent flat	1721-284/11	1	piece
2CKA001754A4334	Cover Frame 1gang yellow - Busch-axcent	1721-285	1	piece
2CKA001754A4337	Cover Frame 1gang green - Busch-axcent	1721-286	1	piece
2CKA001754A4340	Cover Frame 1gang red - Busch-axcent	1721-287	1	piece
2CKA001754A4343	Cover Frame 1gang blue - Busch-axcent	1721-288	1	piece
2CKA001754A4805	Cover Frame 1gang slate grey - Busch-axcent pur	1721-290	1	piece
2CKA001754A4471	Cover Frame 1gang entrée grey - Busch-axcent	1721-291-500	1	piece
2CKA001754A4491	Cover Frame 1gang château-black - Busch-axcent	1721-295-500	1	piece
2CKA001754A4795	Cover Frame 1gang concrete grey - Busch-axcent pur	1721-298	1	piece
2CKA001754A4481	Cover Frame 1gang maison-beige - Busch-axcent	1721-299-500	1	piece
2CKA001754A4505	Cover Frame 1gang ivory - impuls	1721-72-500	1	piece
2CKA001754A4514	Cover Frame 1gang chrome - impuls	1721-726-500	1	piece
2CKA001754A4507	Cover Frame 1gang solar gold - impuls	1721-73-500	1	piece
2CKA001754A4513	Cover Frame 1gang alpine white - impuls	1721-74-500	1	piece
2CKA001754A4222	Cover Frame 1gang alpine white - impuls	1721-74-507	1	piece
2CKA001754A4429	Cover Frame 1gang studio white matt - impuls	1721-774	1	piece
2CKA001754A4430	Cover Frame 1gang studio white matt - impuls	1721-774-507	1	piece
2CKA001754A4424	Cover Frame 1gang black matt - impuls	1721-775	1	piece
2CKA001754A4510	Cover Frame 1gang champagne metallic - impuls	1721-79-500	1	piece
2CKA001754A4225	Cover Frame 1gang champagne metallic - impuls	1721-79-507	1	piece
2CKA001754A4535	Cover Frame 1gang chrome - solo	1721-80-500	1	piece
2CKA001754A4538	Cover Frame 1gang chrome gloss - solo	1721-80G-500	1	piece
2CKA001754A4442	Cover Frame 1gang white glass - carat	1721-811	1	piece
2CKA001754A4820	Cover Frame 1gang porcelain anthracite - carat	1721-815	1	piece
2CKA001754A4258	Cover Frame 1gang bronze - carat	1721-821	1	piece
2CKA001754A4356	Cover Frame 1gang gold - carat	1721-823-101	1	piece
2CKA001754A4322	Cover Frame 1gang glass black - carat	1721-825	1	piece
2CKA001754A4360	Cover Frame 1gang chrome - carat	1721-826-101	1	piece
2CKA001754A4605	Cover Frame 1gang anthracite - Busch-Dynasty	1721-831-500	1	piece
2CKA001754A4600	Cover Frame 1gang ivory white - Busch-Dynasty	1721-832-500	1	piece
2CKA001754A4575	Cover Frame 1gang polished brass decor anthracite - Busch-Dynasty	1721-833-500	1	piece
2CKA001754A4565	Cover Frame 1gang polished brass anthracite - Busch-Dynasty	1721-835-500	1	piece
2CKA001754A4570	Cover Frame 1gang polished brass decor ivory white - Busch-Dynasty	1721-836-500	1	piece
2CKA001754A4560	Cover Frame 1gang polished brass ivory white - Busch-Dynasty	1721-838-500	1	piece
2CKA001754A4595	Cover Frame 1gang antique brass decor anthracite - Busch-Dynasty	1721-843-500	1	piece
2CKA001754A4536	Cover Frame 1gang studio white - solo	1721-84-500	1	piece
2CKA001754A4585	Cover Frame 1gang antique brass anthracite - Busch-Dynasty	1721-845-500	1	piece
2CKA001754A4590	Cover Frame 1gang antique brass decor ivory white - Busch-Dynasty	1721-846-500	1	piece
2CKA001754A4580	Cover Frame 1gang antique brass ivory white - Busch-Dynasty	1721-848-500	1	piece
2CKA001754A4254	Cover Frame 1gang stainless steel - carat	1721-860	1	piece
2CKA001754A4500	Cover Frame 1gang stainless steel - Pure Stainless Steel	1721-866K-500	1	piece

2CKA001754A4531	Cover Frame 1gang studio white matt - future linear	1721-884K-500	1	piece
2CKA001754A4532	Cover Frame 1gang black matt - future linear	1721-885K-500	1	piece
2CKA001754A4374	Cover Frame 2gang platinum - alpha exclusive	1722 KA-20	1	piece
2CKA001754A4383	Cover Frame 2gang bronze - alpha exclusive	1722 KA-21	1	piece
2CKA001754A3849	Cover Frame 2gang ivory - alpha exclusive	1722 KA-22G	1	piece
2CKA001754A2999	Cover Frame 2gang studio white - alpha exclusive	1722 KA-24G	1	piece
2CKA001754A4116	Cover Frame 2gang palladium - alpha exclusive	1722 KA-260	1	piece
2CKA001754A4523	Cover Frame 2gang titanium - alpha exclusive	1722 KA-266-500	1	piece
2CKA001754A2239	Cover Frame 2gang white - Busch-Duro 2000	1722 NS-212	1	piece
2CKA001754A2163	Cover Frame 2gang alpine white - Reflex SI	1722 NS-214	1	piece
2CKA001754A4094	Cover Frame 2gang white - Busch-Duro 2000 SI Linear	1722 NSKA-212	1	piece
2CKA001754A4059	Cover Frame 2gang alpine white - Reflex SI Linear	1722 NSKA-214	1	piece
2CKA001754A4066	Cover Frame 2gang studio white - alpha exclusive	1722 NSKA-24G	1	piece
2CKA001754A4714	Cover Frame 2gang red - future linear	1722-12-182K-101	1	piece
2CKA001754A4241	Cover Frame 2gang anthracite - future linear	1722-181K	1	piece
2CKA001754A4169	Cover Frame 2gang ivory white - future	1722-182	1	piece
2CKA001754A4231	Cover Frame 2gang ivory white - future linear	1722-182K	1	piece
2CKA001754A4530	Cover Frame 2gang aluminium silver - future linear	1722-183K-500	1	piece
2CKA001754A4174	Cover Frame 2gang studio white - future	1722-184	1	piece
2CKA001754A4508	Cover Frame 2gang studio white - future	1722-184-500	1	piece
2CKA001754A4499	Cover Frame 2gang studio white - future linear	1722-184K-500	1	piece
2CKA001754A4524	Cover Frame 2gang platinum - alpha nea	1722-20-500	1	piece
2CKA001754A1710	Cover Frame 2gang bronze - alpha nea	1722-21	1	piece
2CKA001754A4776	Cover Frame 2gang glass purple - Busch-axcent pur	1722-223	1	piece
2CKA001754A4761	Cover Frame 2gang glass sun - Busch-axcent pur	1722-225	1	piece
2CKA001754A4771	Cover Frame 2gang glass avocado - Busch-axcent pur	1722-226	1	piece
2CKA001754A4766	Cover Frame 2gang glass coral - Busch-axcent pur	1722-227	1	piece
2CKA001754A4756	Cover Frame 2gang glass ocean - Busch-axcent pur	1722-228	1	piece
2CKA001754A4781	Cover Frame 2gang glass oyster - Busch-axcent pur	1722-229	1	piece
2CKA001754A3799	Cover Frame 2gang ivory - alpha nea	1722-22G	1	piece
2CKA001754A4791	Cover Frame 2gang paper brown - Busch-axcent pur	1722-243	1	piece
2CKA001754A4801	Cover Frame 2gang glass black - Busch-axcent pur	1722-245	1	piece
2CKA001754A4786	Cover Frame 2gang paper blue - Busch-axcent pur	1722-248	1	piece
2CKA001754A4511	Cover Frame 2gang studio white - alpha nea	1722-24G-500	1	piece
2CKA001754A4401	Cover Frame 2gang palladium - alpha nea	1722-260	1	piece
2CKA001754A4392	Cover Frame 2gang titanium - alpha nea	1722-266	1	piece
2CKA001754A4689	Cover Frame 2gang platinum - Busch-axcent pur	1722-270-500	1	piece
2CKA001754A4709	Cover Frame 2gang black matt - Busch-axcent pur	1722-275-500	1	piece
2CKA001754A4699	Cover Frame 2gang titanium - Busch-axcent pur	1722-276-500	1	piece
2CKA001754A4438	Cover Frame 2gang white glass - Busch-axcent pur	1722-280	1	piece

2CKA001754A4410	Cover Frame 2gang black - Busch-axcent	1722-281	1	piece
2CKA001753A4127	Cover Frame 2gang black - Busch-axcent flat	1722-281/11	1	piece
2CKA001754A4544	Cover Frame 2gang brown glass - Busch-axcent pur	1722-283	1	piece
2CKA001754A4332	Cover Frame 2gang studio white - Busch-axcent	1722-284	1	piece
2CKA001753A4122	Cover Frame 2gang studio white - Busch-axcent flat	1722-284/11	1	piece
2CKA001754A4335	Cover Frame 2gang yellow - Busch-axcent	1722-285	1	piece
2CKA001754A4338	Cover Frame 2gang green - Busch-axcent	1722-286	1	piece
2CKA001754A4341	Cover Frame 2gang red - Busch-axcent	1722-287	1	piece
2CKA001754A4344	Cover Frame 2gang blue - Busch-axcent	1722-288	1	piece
2CKA001754A4806	Cover Frame 2gang slate grey - Busch-axcent pur	1722-290	1	piece
2CKA001754A4472	Cover Frame 2gang entrée grey - Busch-axcent	1722-291-500	1	piece
2CKA001754A4492	Cover Frame 2gang château-black - Busch-axcent	1722-295-500	1	piece
2CKA001754A4796	Cover Frame 2gang concrete grey - Busch-axcent pur	1722-298	1	piece
2CKA001754A4482	Cover Frame 2gang maison-beige - Busch-axcent	1722-299-500	1	piece
2CKA001754A4313	Cover Frame 2gang ivory - impuls	1722-72	1	piece
2CKA001754A4134	Cover Frame 2gang chrome - impuls	1722-726	1	piece
2CKA001754A3542	Cover Frame 2gang solar gold - impuls	1722-73	1	piece
2CKA001754A4525	Cover Frame 2gang alpine white - impuls	1722-74-500	1	piece
2CKA001754A4226	Cover Frame 2gang alpine white - impuls	1722-74-507	1	piece
2CKA001754A4431	Cover Frame 2gang studio white matt - impuls	1722-774	1	piece
2CKA001754A4432	Cover Frame 2gang studio white matt - impuls	1722-774-507	1	piece
2CKA001754A4425	Cover Frame 2gang black matt - impuls	1722-775	1	piece
2CKA001754A2528	Cover Frame 2gang champagne metallic - impuls	1722-79	1	piece
2CKA001754A4537	Cover Frame 2gang chrome - solo	1722-80-500	1	piece
2CKA001754A4327	Cover Frame 2gang chrome gloss - solo	1722-80G	1	piece
2CKA001754A4443	Cover Frame 2gang white glass - carat	1722-811	1	piece
2CKA001754A4821	Cover Frame 2gang porcelain anthracite - carat	1722-815	1	piece
2CKA001754A4259	Cover Frame 2gang bronze - carat	1722-821	1	piece
2CKA001754A4357	Cover Frame 2gang gold - carat	1722-823-101	1	piece
2CKA001754A4323	Cover Frame 2gang glass black - carat	1722-825	1	piece
2CKA001754A4361	Cover Frame 2gang chrome - carat	1722-826-101	1	piece
2CKA001754A4606	Cover Frame 2gang anthracite - Busch-Dynasty	1722-831-500	1	piece
2CKA001754A4601	Cover Frame 2gang ivory white - Busch-Dynasty	1722-832-500	1	piece
2CKA001754A4576	Cover Frame 2gang polished brass decor anthracite - Busch-Dynasty	1722-833-500	1	piece
2CKA001754A4566	Cover Frame 2gang polished brass anthracite - Busch-Dynasty	1722-835-500	1	piece
2CKA001754A4571	Cover Frame 2gang polished brass decor ivory white - Busch-Dynasty	1722-836-500	1	piece
2CKA001754A4561	Cover Frame 2gang polished brass ivory white - Busch-Dynasty	1722-838-500	1	piece
2CKA001754A4596	Cover Frame 2gang antique brass decor anthracite - Busch-Dynasty	1722-843-500	1	piece
2CKA001754A4539	Cover Frame 2gang studio white - solo	1722-84-500	1	piece
2CKA001754A4586	Cover Frame 2gang antique brass anthracite - Busch-Dynasty	1722-845-500	1	piece
2CKA001754A4591	Cover Frame 2gang antique brass decor ivory white - Busch-Dynasty	1722-846-500	1	piece
2CKA001754A4581	Cover Frame 2gang antique brass ivory white - Busch-Dynasty	1722-848-500	1	piece
2CKA001754A4255	Cover Frame 2gang stainless steel - carat	1722-860	1	piece

2CKA001754A4501	Cover Frame 2gang stainless steel - Pure Stainless Steel	1722-866K-500	1	piece
2CKA001754A4415	Cover Frame 2gang studio white matt - future linear	1722-884K	1	piece
2CKA001754A4534	Cover Frame 2gang black matt - future linear	1722-885K-500	1	piece
2CKA001754A4376	Cover Frame 3gang platinum - alpha exclusive	1723 KA-20	1	piece
2CKA001754A4385	Cover Frame 3gang bronze - alpha exclusive	1723 KA-21	1	piece
2CKA001754A3856	Cover Frame 3gang ivory - alpha exclusive	1723 KA-22G	1	piece
2CKA001754A3021	Cover Frame 3gang studio white - alpha exclusive	1723 KA-24G	1	piece
2CKA001754A4118	Cover Frame 3gang palladium - alpha exclusive	1723 KA-260	1	piece
2CKA001754A4127	Cover Frame 3gang titanium - alpha exclusive	1723 KA-266	1	piece
2CKA001754A3708	Cover Frame 3gang white - Busch-Duro 2000	1723 NS-212	1	piece
2CKA001754A3724	Cover Frame 3gang alpine white - Reflex SI	1723 NS-214	1	piece
2CKA001754A4096	Cover Frame 3gang white - Busch-Duro 2000 SI Linear	1723 NSKA- 212	1	piece
2CKA001754A4061	Cover Frame 3gang alpine white - Reflex SI Linear	1723 NSKA- 214	1	piece
2CKA001754A4068	Cover Frame 3gang studio white - alpha exclusive	1723 NSKA- 24G	1	piece
2CKA001754A4242	Cover Frame 3gang anthracite - future linear	1723-181K	1	piece
2CKA001754A4170	Cover Frame 3gang ivory white - future	1723-182	1	piece
2CKA001754A4232	Cover Frame 3gang ivory white - future linear	1723-182K	1	piece
2CKA001754A4533	Cover Frame 3gang aluminium silver - future linear	1723-183K-500	1	piece
2CKA001754A4175	Cover Frame 3gang studio white - future	1723-184	1	piece
2CKA001754A4366	Cover Frame 3gang studio white - future linear	1723-184 NSK	1	piece
2CKA001754A4502	Cover Frame 3gang studio white - future linear	1723-184K-500	1	piece
2CKA001754A1637	Cover Frame 3gang platinum - alpha nea	1723-20	1	piece
2CKA001754A1728	Cover Frame 3gang bronze - alpha nea	1723-21	1	piece
2CKA001754A4777	Cover Frame 3gang glass purple - Busch-axcent pur	1723-223	1	piece
2CKA001754A4762	Cover Frame 3gang glass sun - Busch-axcent pur	1723-225	1	piece
2CKA001754A4772	Cover Frame 3gang glass avocado - Busch- axcent pur	1723-226	1	piece
2CKA001754A4767	Cover Frame 3gang glass coral - Busch-axcent pur	1723-227	1	piece
2CKA001754A4757	Cover Frame 3gang glass ocean - Busch-axcent pur	1723-228	1	piece
2CKA001754A3807	Cover Frame 3gang ivory - alpha nea	1723-22G	1	piece
2CKA001754A4792	Cover Frame 3gang paper brown - Busch-axcent pur	1723-243	1	piece
2CKA001754A4802	Cover Frame 3gang glass black - Busch-axcent pur	1723-245	1	piece
2CKA001754A4787	Cover Frame 3gang paper blue - Busch-axcent pur	1723-248	1	piece
2CKA001754A4518	Cover Frame 3gang studio white - alpha nea	1723-24G-500	1	piece
2CKA001754A4403	Cover Frame 3gang palladium - alpha nea	1723-260	1	piece
2CKA001754A4394	Cover Frame 3gang titanium - alpha nea	1723-266	1	piece
2CKA001754A4690	Cover Frame 3gang platinum - Busch-axcent pur	1723-270-500	1	piece
2CKA001754A4710	Cover Frame 3gang black matt - Busch-axcent pur	1723-275-500	1	piece
2CKA001754A4700	Cover Frame 3gang titanium - Busch-axcent pur	1723-276-500	1	piece
2CKA001754A4439	Cover Frame 3gang white glass - Busch-axcent pur	1723-280	1	piece
2CKA001754A4411	Cover Frame 3gang black - Busch-axcent	1723-281	1	piece
2CKA001753A4128	Cover Frame 3gang black - Busch-axcent flat	1723-281/11	1	piece

2CKA001754A4545	Cover Frame 3gang brown glass - Busch-axcent pur	1723-283	1	piece
2CKA001754A4333	Cover Frame 3gang studio white - Busch-axcent	1723-284	1	piece
2CKA001753A4123	Cover Frame 3gang studio white - Busch-axcent flat	1723-284/11	1	piece
2CKA001754A4336	Cover Frame 3gang yellow - Busch-axcent	1723-285	1	piece
2CKA001754A4339	Cover Frame 3gang green - Busch-axcent	1723-286	1	piece
2CKA001754A4342	Cover Frame 3gang red - Busch-axcent	1723-287	1	piece
2CKA001754A4345	Cover Frame 3gang blue - Busch-axcent	1723-288	1	piece
2CKA001754A4807	Cover Frame 3gang slate grey - Busch-axcent pur	1723-290	1	piece
2CKA001754A4473	Cover Frame 3gang entrée grey - Busch-axcent	1723-291-500	1	piece
2CKA001754A4493	Cover Frame 3gang château-black - Busch-axcent	1723-295-500	1	piece
2CKA001754A4797	Cover Frame 3gang concrete grey - Busch-axcent pur	1723-298	1	piece
2CKA001754A4483	Cover Frame 3gang maison-beige - Busch-axcent	1723-299-500	1	piece
2CKA001754A4314	Cover Frame 3gang ivory - impuls	1723-72	1	piece
2CKA001754A4135	Cover Frame 3gang chrome - impuls	1723-726	1	piece
2CKA001754A3591	Cover Frame 3gang solar gold - impuls	1723-73	1	piece
2CKA001754A2437	Cover Frame 3gang alpine white - impuls	1723-74	1	piece
2CKA001754A4433	Cover Frame 3gang studio white matt - impuls	1723-774	1	piece
2CKA001754A4426	Cover Frame 3gang black matt - impuls	1723-775	1	piece
2CKA001754A2536	Cover Frame 3gang champagne metallic - impuls	1723-79	1	piece
2CKA001754A4540	Cover Frame 3gang chrome - solo	1723-80-500	1	piece
2CKA001754A4328	Cover Frame 3gang chrome gloss - solo	1723-80G	1	piece
2CKA001754A4444	Cover Frame 3gang white glass - carat	1723-811	1	piece
2CKA001754A4260	Cover Frame 3gang bronze - carat	1723-821	1	piece
2CKA001754A4358	Cover Frame 3gang gold - carat	1723-823-101	1	piece
2CKA001754A4324	Cover Frame 3gang glass black - carat	1723-825	1	piece
2CKA001754A4362	Cover Frame 3gang chrome - carat	1723-826-101	1	piece
2CKA001754A4607	Cover Frame 3gang anthracite - Busch-Dynasty	1723-831-500	1	piece
2CKA001754A4602	Cover Frame 3gang ivory white - Busch-Dynasty	1723-832-500	1	piece
2CKA001754A4577	Cover Frame 3gang polished brass decor anthracite - Busch-Dynasty	1723-833-500	1	piece
2CKA001754A4567	Cover Frame 3gang polished brass anthracite - Busch-Dynasty	1723-835-500	1	piece
2CKA001754A4572	Cover Frame 3gang polished brass decor ivory white - Busch-Dynasty	1723-836-500	1	piece
2CKA001754A4562	Cover Frame 3gang polished brass ivory white - Busch-Dynasty	1723-838-500	1	piece
2CKA001754A4597	Cover Frame 3gang antique brass decor anthracite - Busch-Dynasty	1723-843-500	1	piece
2CKA001754A4541	Cover Frame 3gang studio white - solo	1723-84-500	1	piece
2CKA001754A4587	Cover Frame 3gang antique brass anthracite - Busch-Dynasty	1723-845-500	1	piece
2CKA001754A4592	Cover Frame 3gang antique brass decor ivory white - Busch-Dynasty	1723-846-500	1	piece
2CKA001754A4582	Cover Frame 3gang antique brass ivory white - Busch-Dynasty	1723-848-500	1	piece
2CKA001754A4256	Cover Frame 3gang stainless steel - carat	1723-860	1	piece
2CKA001754A4319	Cover Frame 3gang stainless steel - Pure Stainless Steel	1723-866K	1	piece
2CKA001754A4416	Cover Frame 3gang studio white matt - future linear	1723-884K	1	piece
2CKA001754A4421	Cover Frame 3gang black matt - future linear	1723-885K	1	piece
2CKA001754A4378	Cover Frame 4gang platinum - alpha exclusive	1724 KA-20	1	piece

2CKA001754A4387	Cover Frame 4gang bronze - alpha exclusive	1724 KA-21	1	piece
2CKA001754A4151	Cover Frame 4gang ivory - alpha exclusive	1724 KA-22G	1	piece
2CKA001754A4155	Cover Frame 4gang studio white - alpha exclusive	1724 KA-24G	1	piece
2CKA001754A4120	Cover Frame 4gang palladium - alpha exclusive	1724 KA-260	1	piece
2CKA001754A4129	Cover Frame 4gang titanium - alpha exclusive	1724 KA-266	1	piece
2CKA001754A4183	Cover Frame 4gang alpine white - Reflex SI/SI Linear	1724 NS-214 MU	1	piece
2CKA001754A4098	Cover Frame 4gang white - Busch-Duro 2000 SI Linear	1724 NSKA- 212	1	piece
2CKA001754A4063	Cover Frame 4gang alpine white - Reflex SI Linear	1724 NSKA- 214	1	piece
2CKA001754A4243	Cover Frame 4gang anthracite - future linear	1724-181K	1	piece
2CKA001754A4171	Cover Frame 4gang ivory white - future	1724-182	1	piece
2CKA001754A4233	Cover Frame 4gang ivory white - future linear	1724-182K	1	piece
2CKA001754A4309	Cover Frame 4gang aluminium silver - future linear	1724-183K	1	piece
2CKA001754A4176	Cover Frame 4gang studio white - future	1724-184	1	piece
2CKA001754A4367	Cover Frame 4gang studio white - future linear	1724-184 NSK	1	piece
2CKA001754A4238	Cover Frame 4gang studio white - future linear	1724-184K	1	piece
2CKA001754A1645	Cover Frame 4gang platinum - alpha nea	1724-20	1	piece
2CKA001754A1736	Cover Frame 4gang bronze - alpha nea	1724-21	1	piece
2CKA001754A4778	Cover Frame 4gang glass purple - Busch-axcent pur	1724-223	1	piece
2CKA001754A4763	Cover Frame 4gang glass sun - Busch-axcent pur	1724-225	1	piece
2CKA001754A4768	Cover Frame 4gang glass coral - Busch-axcent pur	1724-227	1	piece
2CKA001754A3815	Cover Frame 4gang ivory - alpha nea	1724-22G	1	piece
2CKA001754A4793	Cover Frame 4gang paper brown - Busch-axcent pur	1724-243	1	piece
2CKA001754A4803	Cover Frame 4gang glass black - Busch-axcent pur	1724-245	1	piece
2CKA001754A4788	Cover Frame 4gang paper blue - Busch-axcent pur	1724-248	1	piece
2CKA001754A2908	Cover Frame 4gang studio white - alpha nea	1724-24G	1	piece
2CKA001754A4405	Cover Frame 4gang palladium - alpha nea	1724-260	1	piece
2CKA001754A4396	Cover Frame 4gang titanium - alpha nea	1724-266	1	piece
2CKA001754A4691	Cover Frame 4gang platinum - Busch-axcent pur	1724-270-500	1	piece
2CKA001754A4711	Cover Frame 4gang black matt - Busch-axcent pur	1724-275-500	1	piece
2CKA001754A4701	Cover Frame 4gang titanium - Busch-axcent pur	1724-276-500	1	piece
2CKA001754A4440	Cover Frame 4gang white glass - Busch-axcent pur	1724-280	1	piece
2CKA001754A4412	Cover Frame 4gang black - Busch-axcent	1724-281	1	piece
2CKA001753A4129	Cover Frame 4gang black - Busch-axcent flat	1724-281/11	1	piece
2CKA001754A4546	Cover Frame 4gang brown glass - Busch-axcent pur	1724-283	1	piece
2CKA001754A4346	Cover Frame 4gang studio white - Busch-axcent	1724-284	1	piece
2CKA001753A4124	Cover Frame 4gang studio white - Busch-axcent flat	1724-284/11	1	piece
2CKA001754A4348	Cover Frame 4gang yellow - Busch-axcent	1724-285	1	piece
2CKA001754A4350	Cover Frame 4gang green - Busch-axcent	1724-286	1	piece
2CKA001754A4352	Cover Frame 4gang red - Busch-axcent	1724-287	1	piece
2CKA001754A4354	Cover Frame 4gang blue - Busch-axcent	1724-288	1	piece
2CKA001754A4808	Cover Frame 4gang slate grey - Busch-axcent pur	1724-290	1	piece
2CKA001754A4474	Cover Frame 4gang entrée grey - Busch-axcent	1724-291-500	1	piece

2CKA001754A4494	Cover Frame 4gang château-black - Busch-axcent	1724-295-500	1	piece
2CKA001754A4798	Cover Frame 4gang concrete grey - Busch-axcent pur	1724-298	1	piece
2CKA001754A4484	Cover Frame 4gang maison-beige - Busch-axcent	1724-299-500	1	piece
2CKA001754A4315	Cover Frame 4gang ivory - impuls	1724-72	1	piece
2CKA001754A4136	Cover Frame 4gang chrome - impuls	1724-726	1	piece
2CKA001754A3641	Cover Frame 4gang solar gold - impuls	1724-73	1	piece
2CKA001754A2445	Cover Frame 4gang alpine white - impuls	1724-74	1	piece
2CKA001754A4224	Cover Frame 4gang alpine white - impuls	1724-74-507	1	piece
2CKA001754A4434	Cover Frame 4gang studio white matt - impuls	1724-774	1	piece
2CKA001754A4435	Cover Frame 4gang studio white matt - impuls	1724-774-507	1	piece
2CKA001754A4427	Cover Frame 4gang black matt - impuls	1724-775	1	piece
2CKA001754A2544	Cover Frame 4gang champagne metallic - impuls	1724-79	1	piece
2CKA001754A4223	Cover Frame 4gang champagne metallic - impuls	1724-79-507	1	piece
2CKA001754A4107	Cover Frame 4gang chrome - solo	1724-80	1	piece
2CKA001754A4329	Cover Frame 4gang chrome gloss - solo	1724-80G	1	piece
2CKA001754A4445	Cover Frame 4gang white glass - carat	1724-811	1	piece
2CKA001754A4261	Cover Frame 4gang bronze - carat	1724-821	1	piece
2CKA001754A4359	Cover Frame 4gang gold - carat	1724-823-101	1	piece
2CKA001754A4325	Cover Frame 4gang glass black - carat	1724-825	1	piece
2CKA001754A4363	Cover Frame 4gang chrome - carat	1724-826-101	1	piece
2CKA001754A4608	Cover Frame 4gang anthracite - Busch-Dynasty	1724-831-500	1	piece
2CKA001754A4603	Cover Frame 4gang ivory white - Busch-Dynasty	1724-832-500	1	piece
2CKA001754A4578	Cover Frame 4gang polished brass decor anthracite - Busch-Dynasty	1724-833-500	1	piece
2CKA001754A4568	Cover Frame 4gang polished brass anthracite - Busch-Dynasty	1724-835-500	1	piece
2CKA001754A4573	Cover Frame 4gang polished brass decor ivory white - Busch-Dynasty	1724-836-500	1	piece
2CKA001754A4563	Cover Frame 4gang polished brass ivory white - Busch-Dynasty	1724-838-500	1	piece
2CKA001754A4112	Cover Frame 4gang studio white - solo	1724-84	1	piece
2CKA001754A4598	Cover Frame 4gang antique brass decor anthracite - Busch-Dynasty	1724-843-500	1	piece
2CKA001754A4588	Cover Frame 4gang antique brass anthracite - Busch-Dynasty	1724-845-500	1	piece
2CKA001754A4593	Cover Frame 4gang antique brass decor ivory white - Busch-Dynasty	1724-846-500	1	piece
2CKA001754A4583	Cover Frame 4gang antique brass ivory white - Busch-Dynasty	1724-848-500	1	piece
2CKA001754A4257	Cover Frame 4gang stainless steel - carat	1724-860	1	piece
2CKA001754A4320	Cover Frame 4gang stainless steel - Pure Stainless Steel	1724-866K	1	piece
2CKA001754A4417	Cover Frame 4gang studio white matt - future linear	1724-884K	1	piece
2CKA001754A4422	Cover Frame 4gang black matt - future linear	1724-885K	1	piece
2CKA001754A4380	Cover Frame 5gang platinum - alpha exclusive	1725 KA-20	1	piece
2CKA001754A4389	Cover Frame 5gang bronze - alpha exclusive	1725 KA-21	1	piece
2CKA001754A4153	Cover Frame 5gang ivory - alpha exclusive	1725 KA-22G	1	piece
2CKA001754A4157	Cover Frame 5gang studio white - alpha exclusive	1725 KA-24G	1	piece
2CKA001754A4122	Cover Frame 5gang palladium - alpha exclusive	1725 KA-260	1	piece
2CKA001754A4131	Cover Frame 5gang titanium - alpha exclusive	1725 KA-266	1	piece
2CKA001754A4244	Cover Frame 5gang anthracite - future linear	1725-181K	1	piece
2CKA001754A4172	Cover Frame 5gang ivory white - future	1725-182	1	piece

2CKA001754A4234	Cover Frame 5gang ivory white - future linear	1725-182K	1	piece
2CKA001754A4310	Cover Frame 5gang aluminium silver - future linear	1725-183K	1	piece
2CKA001754A4177	Cover Frame 5gang studio white - future	1725-184	1	piece
2CKA001754A4517	Cover Frame 5gang studio white - future linear	1725-184K-500	1	piece
2CKA001754A1652	Cover Frame 5gang platinum - alpha nea	1725-20	1	piece
2CKA001754A1744	Cover Frame 5gang bronze - alpha nea	1725-21	1	piece
2CKA001754A3823	Cover Frame 5gang ivory - alpha nea	1725-22G	1	piece
2CKA001754A4794	Cover Frame 5gang paper brown - Busch-axcent pur	1725-243	1	piece
2CKA001754A4804	Cover Frame 5gang glass black - Busch-axcent pur	1725-245	1	piece
2CKA001754A2932	Cover Frame 5gang studio white - alpha nea	1725-24G	1	piece
2CKA001754A4407	Cover Frame 5gang palladium - alpha nea	1725-260	1	piece
2CKA001754A4398	Cover Frame 5gang titanium - alpha nea	1725-266	1	piece
2CKA001754A4692	Cover Frame 5gang platinum - Busch-axcent pur	1725-270-500	1	piece
2CKA001754A4712	Cover Frame 5gang black matt - Busch-axcent pur	1725-275-500	1	piece
2CKA001754A4702	Cover Frame 5gang titanium - Busch-axcent pur	1725-276-500	1	piece
2CKA001754A4441	Cover Frame 5gang white glass - Busch-axcent pur	1725-280	1	piece
2CKA001754A4413	Cover Frame 5gang black - Busch-axcent	1725-281	1	piece
2CKA001753A4130	Cover Frame 5gang black - Busch-axcent flat	1725-281/11	1	piece
2CKA001754A4547	Cover Frame 5gang brown glass - Busch-axcent pur	1725-283	1	piece
2CKA001754A4347	Cover Frame 5gang studio white - Busch-axcent	1725-284	1	piece
2CKA001753A4125	Cover Frame 5gang studio white - Busch-axcent flat	1725-284/11	1	piece
2CKA001754A4349	Cover Frame 5gang yellow - Busch-axcent	1725-285	1	piece
2CKA001754A4351	Cover Frame 5gang green - Busch-axcent	1725-286	1	piece
2CKA001754A4353	Cover Frame 5gang red - Busch-axcent	1725-287	1	piece
2CKA001754A4355	Cover Frame 5gang blue - Busch-axcent	1725-288	1	piece
2CKA001754A4809	Cover Frame 5gang slate grey - Busch-axcent pur	1725-290	1	piece
2CKA001754A4475	Cover Frame 5gang entrée grey - Busch-axcent	1725-291-500	1	piece
2CKA001754A4495	Cover Frame 5gang château-black - Busch-axcent	1725-295-500	1	piece
2CKA001754A4799	Cover Frame 5gang concrete grey - Busch-axcent pur	1725-298	1	piece
2CKA001754A4485	Cover Frame 5gang maison-beige - Busch-axcent	1725-299-500	1	piece
2CKA001754A4316	Cover Frame 5gang ivory - impuls	1725-72	1	piece
2CKA001754A4137	Cover Frame 5gang chrome - impuls	1725-726	1	piece
2CKA001754A3690	Cover Frame 5gang solar gold - impuls	1725-73	1	piece
2CKA001754A2452	Cover Frame 5gang alpine white - impuls	1725-74	1	piece
2CKA001754A4436	Cover Frame 5gang studio white matt - impuls	1725-774	1	piece
2CKA001754A4428	Cover Frame 5gang black matt - impuls	1725-775	1	piece
2CKA001754A2551	Cover Frame 5gang champagne metallic - impuls	1725-79	1	piece
2CKA001754A4108	Cover Frame 5gang chrome - solo	1725-80	1	piece
2CKA001754A4330	Cover Frame 5gang chrome gloss - solo	1725-80G	1	piece
2CKA001754A4609	Cover Frame 5gang anthracite - Busch-Dynasty	1725-831-500	1	piece
2CKA001754A4604	Cover Frame 5gang ivory white - Busch-Dynasty	1725-832-500	1	piece
2CKA001754A4579	Cover Frame 5gang polished brass decor anthracite - Busch-Dynasty	1725-833-500	1	piece
2CKA001754A4569	Cover Frame 5gang polished brass anthracite - Busch-Dynasty	1725-835-500	1	piece

2CKA001754A4574	Cover Frame 5gang polished brass decor ivory white - Busch-Dynasty	1725-836-500	1	piece
2CKA001754A4564	Cover Frame 5gang polished brass ivory white - Busch-Dynasty	1725-838-500	1	piece
2CKA001754A4113	Cover Frame 5gang studio white - solo	1725-84	1	piece
2CKA001754A4599	Cover Frame 5gang antique brass decor anthracite - Busch-Dynasty	1725-843-500	1	piece
2CKA001754A4589	Cover Frame 5gang antique brass anthracite - Busch-Dynasty	1725-845-500	1	piece
2CKA001754A4594	Cover Frame 5gang antique brass decor ivory white - Busch-Dynasty	1725-846-500	1	piece
2CKA001754A4584	Cover Frame 5gang antique brass ivory white - Busch-Dynasty	1725-848-500	1	piece
2CKA001754A4321	Cover Frame 5gang stainless steel - Pure Stainless Steel	1725-866K	1	piece
2CKA001754A4418	Cover Frame 5gang studio white matt - future linear	1725-884K	1	piece
2CKA001754A4423	Cover Frame 5gang black matt - future linear	1725-885K	1	piece
2CKA001754A4375	Cover Frame 2gang platinum - alpha exclusive	1732 KA-20	1	piece
2CKA001754A4384	Cover Frame 2gang bronze - alpha exclusive	1732 KA-21	1	piece
2CKA001754A3864	Cover Frame 2gang ivory - alpha exclusive	1732 KA-22G	1	piece
2CKA001754A3054	Cover Frame 2gang studio white - alpha exclusive	1732 KA-24G	1	piece
2CKA001754A4117	Cover Frame 2gang palladium - alpha exclusive	1732 KA-260	1	piece
2CKA001754A4126	Cover Frame 2gang titanium - alpha exclusive	1732 KA-266	1	piece
2CKA001754A2213	Cover Frame 2gang white - Busch-Duro 2000	1732 NS-212	1	piece
2CKA001754A2171	Cover Frame 2gang alpine white - Reflex SI	1732 NS-214	1	piece
2CKA001754A4095	Cover Frame 2gang white - Busch-Duro 2000 SI Linear	1732 NSKA-212	1	piece
2CKA001754A4060	Cover Frame 2gang alpine white - Reflex SI Linear	1732 NSKA-214	1	piece
2CKA001754A4067	Cover Frame 2gang studio white - alpha exclusive	1732 NSKA-24G	1	piece
2CKA001754A4368	Cover Frame 2gang studio white - future linear	1732-184 NSK	1	piece
2CKA001754A1660	Cover Frame 2gang platinum - alpha nea	1732-20	1	piece
2CKA001754A1751	Cover Frame 2gang bronze - alpha nea	1732-21	1	piece
2CKA001754A3757	Cover Frame 2gang ivory - alpha nea	1732-22G	1	piece
2CKA001754A4528	Cover Frame 2gang studio white - alpha nea	1732-24G-500	1	piece
2CKA001754A4402	Cover Frame 2gang palladium - alpha nea	1732-260	1	piece
2CKA001754A4393	Cover Frame 2gang titanium - alpha nea	1732-266	1	piece
2CKA001754A4377	Cover Frame 3gang platinum - alpha exclusive	1733 KA-20	1	piece
2CKA001754A4386	Cover Frame 3gang bronze - alpha exclusive	1733 KA-21	1	piece
2CKA001754A3872	Cover Frame 3gang ivory - alpha exclusive	1733 KA-22G	1	piece
2CKA001754A3088	Cover Frame 3gang studio white - alpha exclusive	1733 KA-24G	1	piece
2CKA001754A4119	Cover Frame 3gang palladium - alpha exclusive	1733 KA-260	1	piece
2CKA001754A4128	Cover Frame 3gang titanium - alpha exclusive	1733 KA-266	1	piece
2CKA001754A3716	Cover Frame 3gang white - Busch-Duro 2000	1733 NS-212	1	piece
2CKA001754A3732	Cover Frame 3gang alpine white - Reflex SI	1733 NS-214	1	piece
2CKA001754A4097	Cover Frame 3gang white - Busch-Duro 2000 SI Linear	1733 NSKA-212	1	piece
2CKA001754A4062	Cover Frame 3gang alpine white - Reflex SI Linear	1733 NSKA-214	1	piece
2CKA001754A4069	Cover Frame 3gang studio white - alpha exclusive	1733 NSKA-24G	1	piece
2CKA001754A4369	Cover Frame 3gang studio white - future linear	1733-184 NSK	1	piece
2CKA001754A1678	Cover Frame 3gang platinum - alpha nea	1733-20	1	piece
2CKA001754A1769	Cover Frame 3gang bronze - alpha nea	1733-21	1	piece

2CKA001754A3765	Cover Frame 3gang ivory - alpha nea	1733-22G	1	piece
2CKA001754A2734	Cover Frame 3gang studio white - alpha nea	1733-24G	1	piece
2CKA001754A4404	Cover Frame 3gang palladium - alpha nea	1733-260	1	piece
2CKA001754A4395	Cover Frame 3gang titanium - alpha nea	1733-266	1	piece
2CKA001754A4379	Cover Frame 4gang platinum - alpha exclusive	1734 KA-20	1	piece
2CKA001754A4388	Cover Frame 4gang bronze - alpha exclusive	1734 KA-21	1	piece
2CKA001754A4152	Cover Frame 4gang ivory - alpha exclusive	1734 KA-22G	1	piece
2CKA001754A4156	Cover Frame 4gang studio white - alpha exclusive	1734 KA-24G	1	piece
2CKA001754A4121	Cover Frame 4gang palladium - alpha exclusive	1734 KA-260	1	piece
2CKA001754A4130	Cover Frame 4gang titanium - alpha exclusive	1734 KA-266	1	piece
2CKA001754A4101	Cover Frame 4gang alpine white - Reflex SI/SI Linear	1734 NS-214 MU	1	piece
2CKA001754A4099	Cover Frame 4gang white - Busch-Duro 2000 SI Linear	1734 NSKA- 212	1	piece
2CKA001754A4064	Cover Frame 4gang alpine white - Reflex SI Linear	1734 NSKA- 214	1	piece
2CKA001754A4370	Cover Frame 4gang studio white - future linear	1734-184 NSK	1	piece
2CKA001754A1686	Cover Frame 4gang platinum - alpha nea	1734-20	1	piece
2CKA001754A1777	Cover Frame 4gang bronze - alpha nea	1734-21	1	piece
2CKA001754A3773	Cover Frame 4gang ivory - alpha nea	1734-22G	1	piece
2CKA001754A2809	Cover Frame 4gang studio white - alpha nea	1734-24G	1	piece
2CKA001754A4406	Cover Frame 4gang palladium - alpha nea	1734-260	1	piece
2CKA001754A4397	Cover Frame 4gang titanium - alpha nea	1734-266	1	piece
2CKA001754A4381	Cover Frame 5gang platinum - alpha exclusive	1735 KA-20	1	piece
2CKA001754A4390	Cover Frame 5gang bronze - alpha exclusive	1735 KA-21	1	piece
2CKA001754A4154	Cover Frame 5gang ivory - alpha exclusive	1735 KA-22G	1	piece
2CKA001754A4158	Cover Frame 5gang studio white - alpha exclusive	1735 KA-24G	1	piece
2CKA001754A4123	Cover Frame 5gang palladium - alpha exclusive	1735 KA-260	1	piece
2CKA001754A4132	Cover Frame 5gang titanium - alpha exclusive	1735 KA-266	1	piece
2CKA001754A1694	Cover Frame 5gang platinum - alpha nea	1735-20	1	piece
2CKA001754A1785	Cover Frame 5gang bronze - alpha nea	1735-21	1	piece
2CKA001754A3781	Cover Frame 5gang ivory - alpha nea	1735-22G	1	piece
2CKA001754A2833	Cover Frame 5gang studio white - alpha nea	1735-24G	1	piece
2CKA001754A4408	Cover Frame 5gang palladium - alpha nea	1735-260	1	piece
2CKA001754A4399	Cover Frame 5gang titanium - alpha nea	1735-266	1	piece
2CKA001799A0162	Label Holder clear transparent - Reflex SI	1760	1	piece
2CKA001799A0154	Label Holder Without imprint clear transparent - Reflex SI	1761	1	piece
2CKA001730A0275	Cover Frame 1gang brown - Allwetter 44 (IP 44)	2101-31	1	piece
2CKA001730A0258	Cover Frame 1gang white - Allwetter 44 (IP 44)	2101-32	1	piece
2CKA001730A0282	Cover Frame 1gang white - Allwetter 44 (IP 44)	2101-32-500	1	piece
2CKA001730A0276	Cover Frame 1gang aluminium silver - Allwetter 44 (IP 44)	2101-33	1	piece
2CKA001730A0191	Cover Frame 1gang alpine white - Allwetter 44 (IP 44)	2101-34	1	piece
2CKA001730A0281	Cover Frame 1gang alpine white - Allwetter 44 (IP 44)	2101-34-500	1	piece
2CKA001730A0225	Cover Frame 1gang anthracite - Allwetter 44 (IP 44)	2101-35	1	piece
2CKA001730A0277	Cover Frame 2gang brown - Allwetter 44 (IP 44)	2102-31	1	piece
2CKA001730A0266	Cover Frame 2gang white - Allwetter 44 (IP 44)	2102-32	1	piece
2CKA001730A0284	Cover Frame 2gang white - Allwetter 44 (IP 44)	2102-32-500	1	piece
2CKA001730A0278	Cover Frame 2gang aluminium silver - Allwetter 44 (IP 44)	2102-33	1	piece

2CKA001730A0209	Cover Frame 2gang alpine white - Allwetter 44 (IP 44)	2102-34	1	piece
2CKA001730A0283	Cover Frame 2gang alpine white - Allwetter 44 (IP 44)	2102-34-500	1	piece
2CKA001730A0233	Cover Frame 2gang anthracite - Allwetter 44 (IP 44)	2102-35	1	piece
2CKA001730A0279	Cover Frame 3gang brown - Allwetter 44 (IP 44)	2103-31	1	piece
2CKA001730A0274	Cover Frame 3gang white - Allwetter 44 (IP 44)	2103-32	1	piece
2CKA001730A0280	Cover Frame 3gang aluminium silver - Allwetter 44 (IP 44)	2103-33	1	piece
2CKA001730A0217	Cover Frame 3gang alpine white - Allwetter 44 (IP 44)	2103-34	1	piece
2CKA001730A0241	Cover Frame 3gang anthracite - Allwetter 44 (IP 44)	2103-35	1	piece
2CKA001725A0662	Cover Frame 1gang white - Busch-Duro 2000	2511 JH-212	1	piece
2CKA001725A1009	Cover Frame 1gang alpine white - Reflex SI	2511 JH-214	1	piece
2CKA001725A1552	Cover Frame 1gang white - Busch-Duro 2000	2511-212-500	1	piece
2CKA001725A0613	Cover Frame 1gang white - Busch-Duro 2000	2511-212-506	1	piece
2CKA001725A1463	Cover Frame 1gang white - Busch-Duro 2000	2511-212-507	1	piece
2CKA001725A1549	Cover Frame 1gang white - Busch-Duro 2000 SI	2511-212K-102 Linear -500	1	piece
2CKA001725A1536	Cover Frame 1gang alpine white - Reflex SI	2511-214-500	1	piece
2CKA001725A1464	Cover Frame 1gang alpine white - Reflex SI	2511-214-507	1	piece
2CKA001725A1539	Cover Frame 1gang alpine white - Reflex SI	2511-214K-102 Linear -500	1	piece
2CKA001725A1033	Cover Frame 1gang black - Reflex SI	2511-215	1	piece
2CKA001725A1563	Cover Frame 1gang red - Reflex SI	2511-217-101	1	piece
2CKA001725A1531	Cover Frame 1gang entrée grey - Basic55	2511-91-507	1	piece
2CKA001725A1484	Cover Frame 1gang white - Basic55	2511-92-507	1	piece
2CKA001725A1501	Cover Frame 1gang champagne - Basic55	2511-93-507	1	piece
2CKA001725A1479	Cover Frame 1gang alpine white - Basic55	2511-94-507	1	piece
2CKA001725A1506	Cover Frame 1gang château-black - Basic55	2511-95-507	1	piece
2CKA001725A1511	Cover Frame 1gang chalet white - Basic55	2511-96-507	1	piece
2CKA001725A1516	Cover Frame 1gang foyer red - Basic55	2511-97-507	1	piece
2CKA001725A1521	Cover Frame 1gang bistro-blue - Basic55	2511-98-507	1	piece
2CKA001725A1526	Cover Frame 1gang maison-beige - Basic55	2511-99-507	1	piece
2CKA001725A1553	Cover Frame 2gang white - Busch-Duro 2000	2512-212-500	1	piece
2CKA001725A1465	Cover Frame 2gang white - Busch-Duro 2000	2512-212-507	1	piece
2CKA001725A1550	Cover Frame 2gang white - Busch-Duro 2000 SI	2512-212K-102 Linear -500	1	piece
2CKA001725A1537	Cover Frame 2gang alpine white - Reflex SI	2512-214-500	1	piece
2CKA001725A1466	Cover Frame 2gang alpine white - Reflex SI	2512-214-507	1	piece
2CKA001725A1540	Cover Frame 2gang alpine white - Reflex SI	2512-214K-102 Linear -500	1	piece
2CKA001725A1066	Cover Frame 2gang black - Reflex SI	2512-215	1	piece
2CKA001725A1532	Cover Frame 2gang entrée grey - Basic55	2512-91-507	1	piece
2CKA001725A1485	Cover Frame 2gang white - Basic55	2512-92-507	1	piece
2CKA001725A1502	Cover Frame 2gang champagne - Basic55	2512-93-507	1	piece
2CKA001725A1480	Cover Frame 2gang alpine white - Basic55	2512-94-507	1	piece
2CKA001725A1507	Cover Frame 2gang château-black - Basic55	2512-95-507	1	piece
2CKA001725A1512	Cover Frame 2gang chalet white - Basic55	2512-96-507	1	piece
2CKA001725A1517	Cover Frame 2gang foyer red - Basic55	2512-97-507	1	piece
2CKA001725A1522	Cover Frame 2gang bistro-blue - Basic55	2512-98-507	1	piece
2CKA001725A1527	Cover Frame 2gang maison-beige - Basic55	2512-99-507	1	piece
2CKA001725A1554	Cover Frame 3gang white - Busch-Duro 2000	2513-212-500	1	piece

2CKA001725A0639	Cover Frame 3gang white - Busch-Duro 2000	2513-212-506	1	piece
2CKA001725A1468	Cover Frame 3gang white - Busch-Duro 2000	2513-212-507	1	piece
2CKA001725A1551	Cover Frame 3gang white - Busch-Duro 2000 SI	2513-212K-102	1	piece
		Linear -500		
2CKA001725A1538	Cover Frame 3gang alpine white - Reflex SI	2513-214-500	1	piece
2CKA001725A1541	Cover Frame 3gang alpine white - Reflex SI	2513-214K-102	1	piece
		Linear -500		
2CKA001725A1090	Cover Frame 3gang black - Reflex SI	2513-215	1	piece
2CKA001725A1533	Cover Frame 3gang entrée grey - Basic55	2513-91-507	1	piece
2CKA001725A1486	Cover Frame 3gang white - Basic55	2513-92-507	1	piece
2CKA001725A1503	Cover Frame 3gang champagne - Basic55	2513-93-507	1	piece
2CKA001725A1481	Cover Frame 3gang alpine white - Basic55	2513-94-507	1	piece
2CKA001725A1508	Cover Frame 3gang château-black - Basic55	2513-95-507	1	piece
2CKA001725A1513	Cover Frame 3gang chalet white - Basic55	2513-96-507	1	piece
2CKA001725A1518	Cover Frame 3gang foyer red - Basic55	2513-97-507	1	piece
2CKA001725A1523	Cover Frame 3gang bistro-blue - Basic55	2513-98-507	1	piece
2CKA001725A1528	Cover Frame 3gang maison-beige - Basic55	2513-99-507	1	piece
2CKA001725A0647	Cover Frame 4gang white - Busch-Duro 2000	2514-212-500	1	piece
2CKA001725A1492	Cover Frame 4gang white - Busch-Duro 2000 SI	2514-212K-102	1	piece
		Linear		
2CKA001725A1543	Cover Frame 4gang alpine white - Reflex SI	2514-214-500	1	piece
2CKA001725A1497	Cover Frame 4gang alpine white - Reflex SI	2514-214K-102	1	piece
		Linear		
2CKA001725A1534	Cover Frame 4gang entrée grey - Basic55	2514-91-507	1	piece
2CKA001725A1487	Cover Frame 4gang white - Basic55	2514-92-507	1	piece
2CKA001725A1504	Cover Frame 4gang champagne - Basic55	2514-93-507	1	piece
2CKA001725A1482	Cover Frame 4gang alpine white - Basic55	2514-94-507	1	piece
2CKA001725A1509	Cover Frame 4gang château-black - Basic55	2514-95-507	1	piece
2CKA001725A1514	Cover Frame 4gang chalet white - Basic55	2514-96-507	1	piece
2CKA001725A1519	Cover Frame 4gang foyer red - Basic55	2514-97-507	1	piece
2CKA001725A1524	Cover Frame 4gang bistro-blue - Basic55	2514-98-507	1	piece
2CKA001725A1529	Cover Frame 4gang maison-beige - Basic55	2514-99-507	1	piece
2CKA001725A0654	Cover Frame 5gang white - Busch-Duro 2000	2515-212-500	1	piece
2CKA001725A1467	Cover Frame 5gang white - Busch-Duro 2000	2515-212-507	1	piece
2CKA001725A1493	Cover Frame 5gang white - Busch-Duro 2000 SI	2515-212K-102	1	piece
		Linear		
2CKA001725A0969	Cover Frame 5gang alpine white - Reflex SI	2515-214	1	piece
2CKA001725A1498	Cover Frame 5gang alpine white - Reflex SI	2515-214K-102	1	piece
		Linear		
2CKA001725A1535	Cover Frame 5gang entrée grey - Basic55	2515-91-507	1	piece
2CKA001725A1488	Cover Frame 5gang white - Basic55	2515-92-507	1	piece
2CKA001725A1505	Cover Frame 5gang champagne - Basic55	2515-93-507	1	piece
2CKA001725A1483	Cover Frame 5gang alpine white - Basic55	2515-94-507	1	piece
2CKA001725A1510	Cover Frame 5gang château-black - Basic55	2515-95-507	1	piece
2CKA001725A1515	Cover Frame 5gang chalet white - Basic55	2515-96-507	1	piece
2CKA001725A1520	Cover Frame 5gang foyer red - Basic55	2515-97-507	1	piece
2CKA001725A1525	Cover Frame 5gang bistro-blue - Basic55	2515-98-507	1	piece
2CKA001725A1530	Cover Frame 5gang maison-beige - Basic55	2515-99-507	1	piece
2CKA001726A0222	Decorative Styling Frame attica / pigeon blue - Basic55	2516-901-507	1	piece
2CKA001726A0223	Decorative Styling Frame silver metallic - Basic55	2516-902-507	1	piece
2CKA001726A0224	Decorative Styling Frame light green - Basic55	2516-903-507	1	piece
2CKA001726A0225	Decorative Styling Frame orange - Basic55	2516-904-507	1	piece
2CKA001726A0226	Decorative Styling Frame yellow - Basic55	2516-905-507	1	piece

2CKA001726A0227	Decorative Styling Frame apricot - Basic55	2516-906-507	1	piece
2CKA001726A0228	Decorative Styling Frame luminous - Basic55	2516-907-507	1	piece
2CKA001726A0220	Decorative Styling Frame white - Basic55	2516-92-507	1	piece
2CKA001726A0230	Decorative Styling Frame champagne - Basic55	2516-93-507	1	piece
2CKA001726A0218	Decorative Styling Frame alpine white - Basic55	2516-94-507	1	piece
2CKA001726A0232	Decorative Styling Frame château-black - Basic55	2516-95-507	1	piece
2CKA001726A0234	Decorative Styling Frame chalet white - Basic55	2516-96-507	1	piece
2CKA001719A0111	Cover Frame 1gang white - Busch-Duro 2000	2518-212	1	piece
2CKA001719A0061	Cover Frame 1gang alpine white - Reflex SI	2518-214	1	piece

Catégories

Produits basse tension → Home and Building Automation → KNX → User Operation → Ocean → Push Button Coupling Units with Integrated Bus Coupler

