



Illuminated selector switch 2 positions

Indicator light

Indicator light

Illuminated button spring-return

Illuminated button spring-return

Non-illuminated button spring-return

Illuminated button spring-return

Emergency push button

	Contacts	Diagram
Device 1	1NO	A1 — A4 A2 — A3
Device 2	/	A6 — A3
Device 3	/	A8 — A3
Device 4	1NO	A1 — A9 A12 — A3
Device 5	1NO	B1 — B4 B2 — B3
Device 6	1NO	B1 — B5 B6 — B3
Device 7	1NO	B1 — B7 B12 — B3
Device 8	2NC	B8 — B9 B10 — B11

