



Smart Plug



220-240V, 50/60Hz, 13A, ≤3000W, -20°C to 35°C

LEDDim App



Android OS 5.1, Ram 2.5GB mid-range CPUs<




iOS 9.0, iPhone 5s<



<http://www.sg-as.no/leddim/getapp/>

Manual




ON



OFF


Manual Countdown Mode

①




ON

②



③



5 sec



1 sec






5 sec



By default.
Adjustable in App.

Smart Plug



Rev: 27.09.2018

NORWAY SG Armaturen AS
Tlf:+47 37 50 03 00
firmapost@sg-as.no
www.sg-as.no

SWEDEN SG Armaturen AB
Tel: +46 31 81 71 10
info@sg-ab.se
www.sg-ab.se

FRANCE SG Lighting SA/NV
Tel: +33(0) 4 94 93 00 00
info.france@sglighting.fr
www.sglighting.net

GERMANY SG Leuchten GmbH
Tel: +49 40 23 99 44 59
info@sg-leuchten.de
www.sg-leuchten.de



DENMARK SG Armaturen A/S
Tel: +45 70 70 72 13
info@sg-as.dk
www.sg-as.dk

FINLAND SG Armaturen Oy
info@sg-oy.fi
www.sg-oy.fi





BENELUX SG Lighting SA/NV
Tel: +32(0) 15 20 72 71
info.benelux@sglighting.net
www.sglighting.net

INTERNATIONAL SG Lighting Co Ltd.
Tel: +86 769 88 49 20 88
cindy@sgdgc.com
www.sg-as.com


On/Off Countdown Mode in App



Adjust Countdown Time



Range



Mesh grid function



LEDDIM Guide







<http://www.sg-as.no/leddim/>





iOS LEDDim Guide








1. REGISTER create account



2. LOCATION create location




3. MANAGE DEVICE add dimmers



4. GROUP
create group






5. LOCATION
Share location








Android LEDDim Guide



1. REGISTER create account



2. LOCATION create location



3. MANAGE DEVICE
add dimmers

Location Home
Connected

Sample

Dimmer (B341030615)
Dimmer (B3410304C4)
Dimmer (B34103059A)

Pair Devices

Next

Device Pairing

Step 1 Step 2 Step 3

Please Remove the Dimmer Rotary Dial and press the RESET button now

Device Successfully Paired!
B3410304C4
Dimmer 1

DONE SKIP

Note : Please remember to replace back the Dimmer rotary dial

4. GROUP
create group

Location Home
Connected

Sample

Group

Timer

Away

Welcome

Wake up

Night

Sign Out

Group

Sample

Group Name

TV

Dimmer 2

Dimmer 3

Dimmer 1

Scene 1 Scene 2 Scene 3 Scene 4

5. LOCATION
Share location

Location Home
Connected

TV

Passcode Lock

Manage Device

Pairing Reset

About

Change Password

Location

Inbox

Guide

Sign Out

Location Home

Location Home

MORE

Share

Please select a role

Admin

Email

enduser@gmail.com

CANCEL SHARE

Edit

View

Share

Cancel