

PRODUCT-DETAILS

1722 KA-21

Cover Frame 2gang bronze - alpha exclusive



Informations générales

| | |
|------------------------------|--------------------------------------------|
| Extension du type de produit | 1722 KA-21 |
| Code de produit | 2CKA001754A4383 |
| EAN | 4011395125724 |
| Description courte | Cover Frame 2gang bronze - alpha exclusive |
| Description longue | Horizontal |

Installation

| | |
|-------------------------|--------------------|
| Instructions et manuels | No document needed |
|-------------------------|--------------------|

Technique

| | |
|----------------------------------------|--------------------------|
| Fiche produit, informations techniques | No document needed |
| Number of Gangs | 2 |
| Design Range | alpha exclusive alpha |
| Type de montage | Flush Mounted |
| Type of Fastening | Clamp |
| Sens de montage | Horizontal |
| Finition de surface | Untreated |

| | |
|----------------------|-----------|
| | Glossy |
| Matériau | Aluminium |
| Label Space Provided | No |
| Couleur | bronze |

Environnement

| | |
|---------------------------------------------|------------------------------------------------------------------------|
| Indice de protection | IP20 |
| Statut RoHS | Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019 |
| Informations RoHS | 2CKA200000E2730 |
| REACH Declaration | 2CKA309999E9999 |
| Conflict Minerals Reporting Template (CMRT) | 9AKK108468A3363 |

Dimensions

| | |
|----------------------|-----------------|
| Produit Largeur Net | 152 mm |
| Produit Hauteur Net | 81 mm |
| Produit Longueur Net | 11 mm |
| Poids net | 32 g |
| Schéma dimensionnel | 2CKA000097E0318 |

Commande

| | |
|------------------------|-------------|
| ID du produit remplacé | 1754-0-4383 |
|------------------------|-------------|

Certificats et Déclarations (Numéro de document)

| | |
|--------------------------------|-----------------|
| Déclaration de Conformité - CE | 2CKA200000E2730 |
|--------------------------------|-----------------|

Classifications

| | |
|----------------|-------------------------------------------------------|
| ETIM 8 | EC000007 - Cover frame for domestic switching devices |
| ETIM 9 | EC000007 - Cover frame for domestic switching devices |
| Catégorie DEEE | Product Not in WEEE Scope |
| CN8 | 8538 90 99 |
| eClass | V11.0 : 27144001 |

Accessories

| Identifiant | Description | Type | Quantity | Unit Of Measure |
|-----------------|------------------------------------------------------------------------------------------------|-------------|----------|-----------------|
| 2CKA008200A0094 | Cover Plate Loudspeaker bronze - alpha | 8253-21 | 1 | piece |
| 2CKA001731A1930 | Cover Busch-Infolicht® bronze - alpha | 1716-21 | 1 | piece |
| 2CKA001753A1175 | Cover plate with legend Symbol "arrows" and "0" for Venetian blind, Turn button bronze - alpha | 1740 DR-21 | 1 | piece |
| 2CKA001753A8287 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button bronze - alpha | 1740 DRL-21 | 1 | piece |
| 2CKA001753A1431 | Cover Plate Blind cap 1 gang with Mounting plate bronze - alpha | 1742-21 | 1 | piece |

| | | | | |
|-----------------|--------------------------------------------------------------------------------------------|----------------|---|-------|
| 2CKA001724A2748 | Cover Plate TV / Radio / SAT 3 gang bronze - alpha | 1743-03-21-101 | 1 | piece |
| 2CKA001753A1449 | Cover Plate SAT 2 gang bronze - alpha | 1743-21 | 1 | piece |
| 2CKA001753A8568 | Cover Plate Telecommunication inserts 50 x 50 mm bronze - alpha | 1746/10-21 | 1 | piece |
| 2CKA001753A1761 | Cover Plate with Hinged Lid Telecommunication inserts 1 gang bronze - alpha | 1746-21 FN | 1 | piece |
| 2CKA001753A5986 | Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang bronze - alpha | 1746-21-101 | 1 | piece |
| 2CKA001753A1480 | Cover Plate Data connection 2 gang bronze - alpha | 1748-21 | 1 | piece |
| 2CKA001710A0946 | Cover Plate Cable outlet with Mounting plate bronze - alpha | 1749-21 | 1 | piece |
| 2CKA001723A0121 | Cover Plate Loudspeaker 2 gang bronze - alpha | 1751-21 | 1 | piece |
| 2CKA001753A1522 | Cover Plate Busch-Infolicht® bronze - alpha | 1756-21 | 1 | piece |
| 2CKA001724A1028 | Cover plate with labelling field For data connection housing 2 gang bronze - alpha | 1758-21 | 1 | piece |
| 2CKA001753A2637 | Cover Plate TAE 1 gang bronze - alpha | 1766-21 | 1 | piece |
| 2CKA001753A8840 | Data / Telecommunication / Antenna AMP-ACO 1 gang bronze - alpha | 1769-21 | 1 | piece |
| 2CKA001753A6083 | Cover plate with legend Symbol "1" for Time switch, Turn button bronze - alpha | 1770-21-101 | 1 | piece |
| 2CKA001753A6232 | Cover plate with legend Symbol "0" for Time switch, Turn button bronze - alpha | 1771-21-101 | 1 | piece |
| 2CKA001751A1757 | Rocker with labelling field for Switch/push button, Single rocker bronze - alpha | 1781-21 | 1 | piece |
| 2CKA001751A3111 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker bronze - alpha | 1785 JA/02-21 | 1 | piece |
| 2CKA001751A1831 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker bronze - alpha | 1785 JA-21 | 1 | piece |
| 2CKA001751A3139 | Rocker for Switch/push button, Two-part rocker bronze - alpha | 1785 K-21 | 1 | piece |
| 2CKA001751A1773 | Rocker for Switch/push button, Two-part rocker bronze - alpha | 1785-21 | 1 | piece |
| 2CKA001751A2706 | Mechanical Controls Without imprint for Switch/push button, Two-part rocker bronze - alpha | 1785-21-101 | 1 | piece |
| 2CKA001751A3110 | Rocker with legend Symbol "arrows" for Switch/push button, bronze - alpha | 1786 JA/02-21 | 1 | piece |
| 2CKA001751A3086 | Mechanical Controls Without imprint for Switch/push button, Single rocker bronze - alpha | 1786-21-500 | 1 | piece |
| 2CKA001751A2052 | Rocker for Switch/push button, Single rocker bronze - alpha | 1787-21 | 1 | piece |
| 2CKA001751A1765 | Rocker for Switch/push button, Single rocker bronze - alpha | 1788-21 | 1 | piece |
| 2CKA001751A1781 | Rocker with legend Heizung for Switch/push button, Single rocker bronze - alpha | 1789 H-21 | 1 | piece |
| 2CKA001751A1732 | Rocker for Switch/push button, Single rocker bronze - alpha | 1789 KI-21 | 1 | piece |
| 2CKA001751A1724 | Rocker with legend Symbol "light" for Switch/push button, Single rocker bronze - alpha | 1789 LI-21 | 1 | piece |
| 2CKA001751A1740 | Rocker for Switch/push button, Single rocker bronze - alpha | 1789 TR-21 | 1 | piece |
| 2CKA001751A1716 | Rocker for Switch/push button, Single rocker bronze - alpha | 1789-21 | 1 | piece |
| 2CKA001710A3294 | Cover plate with legend Card for Switch/push button, Hotel card Hotel card bronze - alpha | 1792-21-101 | 1 | piece |
| 2CKA001710A3685 | Cover plate with legend for Thermostat Turn button bronze - alpha | 1794 TA-21 | 1 | piece |
| 2CKA001710A3533 | Cover plate with legend for Thermostat Turn button bronze - alpha | 1794-21 | 1 | piece |

| | | | | |
|-----------------|------------------------------------------------------------------------------------------------------|--------------------|---|-------|
| 2CKA001710A3999 | Cover plate with legend for Thermostat Turn button bronze - alpha | 1795 HK-21 | 1 | piece |
| 2CKA001710A4031 | Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha | 1795 HKEA-21 | 1 | piece |
| 2CKA001710A3712 | Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha | 1795 TA-21 | 1 | piece |
| 2CKA001710A3558 | Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha | 1795-21 | 1 | piece |
| 2CKA001753A9186 | Cover plate with labelling field Modular Jack 2 gang bronze - alpha | 1800-21 | 1 | piece |
| 2CKA001753A8493 | Cover Plate UAE/IAE (ISDN) 2 gang bronze - alpha | 1803-02-21 | 1 | piece |
| 2CKA001753A8428 | Cover Plate UAE/IAE (ISDN) 1 gang bronze - alpha | 1803-21 | 1 | piece |
| 2CKA002011A6221 | Socket Outlets bronze - alpha | 20 EUC-21-500 | 1 | piece |
| 2CKA002013A4466 | SCHUKO® socket insert Safety Shutter bronze - alpha | 20 EUCKS-21 | 1 | piece |
| 2CKA002018A0703 | SCHUKO® socket insert with Hinged Lid bronze - alpha | 20 EUK-21 | 1 | piece |
| 2CKA002017A0811 | Socket insert bronze - alpha | 20 MUC-21-500 | 1 | piece |
| 2CKA002017A0835 | Socket Outlets French norm NF bronze - alpha | 20 MUCKS-21-500 | 1 | piece |
| 2CKA002113A0041 | Socket Outlets bronze - alpha | 2300-01 UC-21-500 | 1 | piece |
| 2CKA002011A3820 | Busch-Protector® SCHUKO® socket insert bronze - alpha | 2310 EUGL/VA-21-11 | 1 | piece |
| 2CKA002099A0226 | Socket Outlets bronze - alpha | 2399 UCKS-21 | 1 | piece |
| 2CKA001710A3114 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button bronze - alpha | 2542 DR/01-21 | 1 | piece |
| 2CKA001710A3425 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button bronze - alpha | 2542 DR/02-21 | 1 | piece |
| 2CKA001753A4054 | Cover Plate Modular Jack 2 gang bronze - alpha | 2561-02-21 | 1 | piece |
| 2CKA001753A3924 | Cover Plate Modular Jack 1 gang bronze - alpha | 2561-21 | 1 | piece |
| 2CKA006115A0477 | 6108/61-21-500 Coverplate f. CE | 6108/61-21-500 | 1 | piece |
| 2CKA006155A0054 | 6109/03-21-500 Coverplate f. RTC | 6109/03-21-500 | 1 | piece |
| 2CKA006430A0320 | Control Element for Venetian blind Single push button bronze - alpha | 6430-21-102 | 1 | piece |
| 2CKA006430A0292 | Cover plate with legend for Time switch bronze - alpha | 6435-21 | 1 | piece |
| 2CKA006599A1490 | Cover Plate for Dimmer Turn button bronze - alpha | 6540-21 | 1 | piece |
| 2CKA006599A1524 | Cover Plate for Cooling Central cover plate bronze - alpha | 6541-21 | 1 | piece |
| 2CKA006599A2821 | Control Element for Switch/dimmer Single push button with Neon lamp bronze - alpha | 6543-21-102 | 1 | piece |
| 2CKA006599A2891 | Control Element for Dimmer Two-part button with Neon lamp bronze - alpha | 6545-21 | 1 | piece |
| 2CKA001731A1931 | Cover Busch-Infolicht® ivory - alpha | 1716-22 | 1 | piece |
| 2CKA001731A1933 | Cover Busch-Infolicht® studio white - alpha | 1716-24G | 1 | piece |
| 2CKA001731A1938 | Cover Busch-Infolicht® palladium - alpha | 1716-260 | 1 | piece |
| 2CKA001731A1939 | Cover Busch-Infolicht® titanium - alpha | 1716-266 | 1 | piece |
| 2CKA001753A1092 | Cover plate with legend Symbol "arrows" and "0" for Venetian blind, Turn button platinum - alpha | 1740 DR-20 | 1 | piece |
| 2CKA001710A2330 | Cover Plate Symbol "arrows" and "0" for Venetian blind, Turn button ivory - alpha | 1740 DR-22G | 1 | piece |
| 2CKA001753A7263 | Cover plate with legend Symbol "arrows" and "0" for Venetian blind, Turn button studio white - alpha | 1740 DR-24G | 1 | piece |

| | | | | |
|-----------------|--------------------------------------------------------------------------------------------------|------------------|---|-------|
| 2CKA001710A3302 | Cover Plate Symbol "arrows" and "0" for Venetian blind, Turn button palladium - alpha | 1740 DR-260 | 1 | piece |
| 2CKA001710A3328 | Cover plate with legend Symbol "arrows" and "0" for Venetian blind, Turn button titanium - alpha | 1740 DR-266 | 1 | piece |
| 2CKA001753A8279 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button platinum - alpha | 1740 DRL-20 | 1 | piece |
| 2CKA001710A3032 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button ivory - alpha | 1740 DRL-22G | 1 | piece |
| 2CKA001753A8246 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button studio white - alpha | 1740 DRL-24G | 1 | piece |
| 2CKA001710A3457 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button palladium - alpha | 1740 DRL-260-503 | 1 | piece |
| 2CKA001710A3459 | Mechanical Controls Symbol "2-1-3" for Level switch, Turn button titanium - alpha | 1740 DRL-266-503 | 1 | piece |
| 2CKA001753A1118 | Cover Plate Blind cap 1 gang with Mounting plate platinum - alpha | 1742-20 | 1 | piece |
| 2CKA001710A2389 | Cover Plate Blind cap 0 gang with Mounting plate ivory - alpha | 1742-22G | 1 | piece |
| 2CKA001753A7412 | Cover Plate Blind cap 1 gang with Mounting plate studio white - alpha | 1742-24G | 1 | piece |
| 2CKA001710A3309 | Cover Plate Blind cap 1 gang with Mounting plate palladium - alpha | 1742-260 | 1 | piece |
| 2CKA001710A3335 | Cover Plate Blind cap 1 gang with Mounting plate titanium - alpha | 1742-266 | 1 | piece |
| 2CKA001724A2727 | Data / Telecommunication / Antenna SAT 1 gang ivory - alpha | 1743-01-22-500 | 1 | piece |
| 2CKA001724A2822 | Cover Plate SAT 1 gang palladium - alpha | 1743-01-260-500 | 1 | piece |
| 2CKA001724A2825 | Cover Plate SAT 1 gang titanium - alpha | 1743-01-266-500 | 1 | piece |
| 2CKA001724A2747 | Cover Plate SAT 3 gang platinum - alpha | 1743-03-20-101 | 1 | piece |
| 2CKA001724A2463 | Cover Plate TV / Radio / SAT 3 gang ivory - alpha | 1743-03-22G | 1 | piece |
| 2CKA001724A1911 | Cover Plate SAT 3 gang studio white - alpha | 1743-03-24G | 1 | piece |
| 2CKA001724A2792 | Cover Plate SAT 3 gang palladium - alpha | 1743-03-260 | 1 | piece |
| 2CKA001724A2797 | Cover Plate SAT 3 gang titanium - alpha | 1743-03-266 | 1 | piece |
| 2CKA001753A1126 | Cover Plate SAT 2 gang platinum - alpha | 1743-20 | 1 | piece |
| 2CKA001710A2454 | Cover Plate SAT 2 gang ivory - alpha | 1743-22G | 1 | piece |
| 2CKA001753A7628 | Cover Plate SAT 2 gang studio white - alpha | 1743-24G | 1 | piece |
| 2CKA001724A2791 | Cover Plate SAT 2 gang palladium - alpha | 1743-260 | 1 | piece |
| 2CKA001724A2796 | Cover Plate SAT 2 gang titanium - alpha | 1743-266 | 1 | piece |
| 2CKA001753A8550 | Cover Plate Telecommunication inserts 50 x 50 mm platinum - alpha | 1746/10-20 | 1 | piece |
| 2CKA001710A2652 | Cover Plate Telecommunication inserts 50 x 50 mm ivory - alpha | 1746/10-22G | 1 | piece |
| 2CKA001710A2744 | Cover Plate Telecommunication inserts 50 x 50 mm studio white - alpha | 1746/10-24G | 1 | piece |
| 2CKA001710A3312 | Cover Plate Telecommunication inserts 50 x 50 mm palladium - alpha | 1746/10-260 | 1 | piece |
| 2CKA001710A3338 | Cover Plate Telecommunication inserts 50 x 50 mm titanium - alpha | 1746/10-266 | 1 | piece |
| 2CKA001753A1753 | Cover Plate with Hinged Lid Telecommunication inserts 1 gang platinum - alpha | 1746-20 FN | 1 | piece |
| 2CKA001753A5978 | Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang platinum - alpha | 1746-20-101 | 1 | piece |
| 2CKA001710A2488 | Cover Plate with Hinged Lid Telecommunication inserts 1 gang ivory - alpha | 1746-22G FN | 1 | piece |
| 2CKA001710A2470 | Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang ivory - alpha | 1746-22G-101 | 1 | piece |
| 2CKA001753A7719 | Cover Plate with Hinged Lid Telecommunication inserts 1 gang studio white - alpha | 1746-24G FN | 1 | piece |

| | | | | |
|-----------------|----------------------------------------------------------------------------------------------|-------------------|---|-------|
| 2CKA001753A7685 | Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang studio white - alpha | 1746-24G-101 | 1 | piece |
| 2CKA001710A3311 | Cover Plate with Hinged Lid Telecommunication inserts 1 gang palladium - alpha | 1746-260 FN | 1 | piece |
| 2CKA001710A3313 | Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang palladium - alpha | 1746-260-101 | 1 | piece |
| 2CKA001710A3337 | Cover Plate with Hinged Lid Telecommunication inserts 1 gang titanium - alpha | 1746-266 FN | 1 | piece |
| 2CKA001710A3339 | Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang titanium - alpha | 1746-266-101 | 1 | piece |
| 2CKA001753A1167 | Cover Plate Data connection 2 gang platinum - alpha | 1748-20 | 1 | piece |
| 2CKA001710A2546 | Cover Plate Data connection 2 gang ivory - alpha | 1748-22G | 1 | piece |
| 2CKA001753A7891 | Cover Plate Data connection 2 gang studio white - alpha | 1748-24G | 1 | piece |
| 2CKA001710A3323 | Cover Plate Data connection 2 gang palladium - alpha | 1748-260 | 1 | piece |
| 2CKA001710A3349 | Cover Plate Data connection 2 gang titanium - alpha | 1748-266 | 1 | piece |
| 2CKA001710A0904 | Cover Plate Cable outlet with Mounting plate platinum - alpha | 1749-20 | 1 | piece |
| 2CKA001710A2561 | Cover Plate Cable outlet ivory - alpha | 1749-22G | 1 | piece |
| 2CKA001710A1209 | Cover Plate Cable outlet with Mounting plate studio white - alpha | 1749-24G | 1 | piece |
| 2CKA001710A3316 | Cover Plate Cable outlet palladium - alpha | 1749-260 | 1 | piece |
| 2CKA001710A3342 | Cover Plate Cable outlet with Mounting plate titanium - alpha | 1749-266 | 1 | piece |
| 2CKA001723A0113 | Cover Plate Loudspeaker 2 gang platinum - alpha | 1751-20 | 1 | piece |
| 2CKA001723A0238 | Cover Plate Loudspeaker 2 gang ivory - alpha | 1751-22G | 1 | piece |
| 2CKA001723A0204 | Cover Plate Loudspeaker 2 gang studio white - alpha | 1751-24G | 1 | piece |
| 2CKA001723A0245 | Cover Plate Loudspeaker 2 gang palladium - alpha | 1751-260 | 1 | piece |
| 2CKA001723A0246 | Cover Plate Loudspeaker 2 gang titanium - alpha | 1751-266 | 1 | piece |
| 2CKA001710A2348 | Cover plate with legend Symbol "arrows" for Venetian blind, Key ivory - alpha | 1755 PZ-22G-101 | 1 | piece |
| 2CKA001710A1522 | Cover plate with legend Symbol "arrows" for Venetian blind, Key studio white - alpha | 1755 PZ-24G-101 | 1 | piece |
| 2CKA001710A2355 | Cover plate with legend Characters 0 and 1 for Venetian blind, Key ivory - alpha | 1755 SLPZ-22G-101 | 1 | piece |
| 2CKA001710A1597 | Cover plate with legend Characters 0 and 1 for Venetian blind, Key studio white - alpha | 1755 SLPZ-24G-101 | 1 | piece |
| 2CKA001753A1506 | Cover Plate Busch-Infolicht® platinum - alpha | 1756-20 | 1 | piece |
| 2CKA001710A2413 | Cover Plate Busch-Infolicht® ivory - alpha | 1756-22G | 1 | piece |
| 2CKA001753A7503 | Cover Plate Busch-Infolicht® studio white - alpha | 1756-24G | 1 | piece |
| 2CKA001710A3306 | Cover Plate Busch-Infolicht® palladium - alpha | 1756-260 | 1 | piece |
| 2CKA001710A3332 | Cover Plate Busch-Infolicht® titanium - alpha | 1756-266 | 1 | piece |
| 2CKA001724A1010 | Cover plate with labelling field For data connection housing 2 gang platinum - alpha | 1758-20 | 1 | piece |
| 2CKA001724A2513 | Cover plate with labelling field For data connection housing 2 gang ivory - alpha | 1758-22G | 1 | piece |
| 2CKA001724A2067 | Cover plate with labelling field For data connection housing 2 gang studio white - alpha | 1758-24G | 1 | piece |
| 2CKA001724A2793 | Cover Plate For data connection housing 2 gang palladium - alpha | 1758-260 | 1 | piece |
| 2CKA001724A2798 | Cover plate with labelling field For data connection housing 2 gang titanium - alpha | 1758-266 | 1 | piece |
| 2CKA001731A1858 | Rocker with labelling field for Switch/push button, Single rocker ivory - alpha | 1764 NLI-22G | 1 | piece |
| 2CKA001731A1569 | Rocker with labelling field for Switch/push button, Single rocker studio white - alpha | 1764 NLI-24G | 1 | piece |

| | | | | |
|-----------------|---------------------------------------------------------------------------------------------|----------------|---|-------|
| 2CKA001753A2629 | Cover Plate TAE 1 gang platinum - alpha | 1766-20 | 1 | piece |
| 2CKA001710A2496 | Cover Plate TAE 1 gang ivory - alpha | 1766-22G | 1 | piece |
| 2CKA001753A7743 | Cover Plate TAE 1 gang studio white - alpha | 1766-24G | 1 | piece |
| 2CKA001710A3310 | Cover Plate TAE 1 gang palladium - alpha | 1766-260 | 1 | piece |
| 2CKA001710A3336 | Cover Plate TAE 1 gang titanium - alpha | 1766-266 | 1 | piece |
| 2CKA001753A8832 | Data / Telecommunication / Antenna AMP-ACO 1 gang platinum - alpha | 1769-20 | 1 | piece |
| 2CKA001710A2678 | Data / Telecommunication / Antenna AMP-ACO 1 gang ivory white - alpha | 1769-22G | 1 | piece |
| 2CKA001710A2736 | Cover plate with labelling field AMP-ACO 1 gang studio white - alpha | 1769-24G | 1 | piece |
| 2CKA001710A3317 | Data / Telecommunication / Antenna AMP-ACO 1 gang palladium - alpha | 1769-260 | 1 | piece |
| 2CKA001710A3343 | Data / Telecommunication / Antenna AMP-ACO 1 gang titanium - alpha | 1769-266 | 1 | piece |
| 2CKA001753A6075 | Cover plate with legend Symbol "1" for Time switch, Turn button platinum - alpha | 1770-20-101 | 1 | piece |
| 2CKA001710A2397 | Cover Plate 1 ... 15 Min for Time switch, Turn button ivory - alpha | 1770-22G-101 | 1 | piece |
| 2CKA001753A7446 | Cover plate with legend Symbol "1" for Time switch, Turn button white - alpha | 1770-24G-101 | 1 | piece |
| 2CKA001753A6224 | Cover plate with legend Symbol "0" for Time switch, Turn button platinum - alpha | 1771-20-101 | 1 | piece |
| 2CKA001710A2405 | Cover plate with legend 10 ... 120 Min for Time switch, Turn button ivory - alpha | 1771-22G-101 | 1 | piece |
| 2CKA001753A7479 | Cover plate with legend Symbol "0" for Time switch, Turn button white - alpha | 1771-24G-101 | 1 | piece |
| 2CKA001753A7354 | Accessories Timer Time indication white - alpha | 1775-24G-101 | 1 | piece |
| 2CKA001751A1666 | Rocker with labelling field for Switch/push button, Single rocker platinum - alpha | 1781-20 | 1 | piece |
| 2CKA001751A2540 | Rocker with labelling field for Switch/push button, Single rocker ivory - alpha | 1781-22G | 1 | piece |
| 2CKA001751A2292 | Rocker with labelling field for Switch/push button, Single rocker studio white - alpha | 1781-24G | 1 | piece |
| 2CKA001751A2822 | Rocker for Switch/push button, Single rocker palladium - alpha | 1781-260 | 1 | piece |
| 2CKA001751A2833 | Rocker with labelling field for Switch/push button, Single rocker titanium - alpha | 1781-266 | 1 | piece |
| 2CKA001751A3113 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker platinum - alpha | 1785 JA/02-20 | 1 | piece |
| 2CKA001751A3107 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - alpha | 1785 JA/02-24G | 1 | piece |
| 2CKA001751A3115 | Mechanical Controls palladium | 1785 JA/02-260 | 1 | piece |
| 2CKA001751A1823 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker platinum - alpha | 1785 JA-20 | 1 | piece |
| 2CKA001751A2581 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker ivory - alpha | 1785 JA-22G | 1 | piece |
| 2CKA001751A2128 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - alpha | 1785 JA-24G | 1 | piece |
| 2CKA001751A2831 | Rocker for Venetian blind, Two-part rocker palladium - alpha | 1785 JA-260 | 1 | piece |
| 2CKA001751A2842 | Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker titanium - alpha | 1785 JA-266 | 1 | piece |
| 2CKA001751A3138 | Rocker for Switch/push button, Two-part rocker platinum - alpha | 1785 K-20 | 1 | piece |
| 2CKA001751A3140 | Rocker for Switch/push button, Two-part rocker ivory - alpha | 1785 K-22G | 1 | piece |
| 2CKA001751A3142 | Rocker for Switch/push button, Two-part rocker studio white - alpha | 1785 K-24G | 1 | piece |
| 2CKA001751A3143 | Rocker for Switch/push button, Two-part rocker palladium - alpha | 1785 K-260 | 1 | piece |

| | | | | |
|-----------------|------------------------------------------------------------------------------------------------|----------------|---|-------|
| 2CKA001751A3144 | Rocker for Switch/push button, Two-part rocker titanium - alpha | 1785 K-266 | 1 | piece |
| 2CKA001751A1682 | Rocker for Switch/push button, Two-part rocker platinum - alpha | 1785-20 | 1 | piece |
| 2CKA001751A2565 | Rocker for Switch/push button, Two-part rocker ivory - alpha | 1785-22G | 1 | piece |
| 2CKA001751A2110 | Rocker for Switch/push button, Two-part rocker studio white - alpha | 1785-24G | 1 | piece |
| 2CKA001751A2827 | Rocker for Switch/push button, Two-part rocker palladium - alpha | 1785-260 | 1 | piece |
| 2CKA001751A3082 | Mechanical Controls Without imprint for Switch/push button, Two-part rocker palladium - alpha | 1785-260-500 | 1 | piece |
| 2CKA001751A2838 | Rocker for Switch/push button, Two-part rocker titanium - alpha | 1785-266 | 1 | piece |
| 2CKA001751A2722 | Mechanical Controls Characters 0 and 1 for Switch/push button, Single rocker ivory - alpha | 1786 IO-22G | 1 | piece |
| 2CKA001751A3112 | Rocker for Venetian blind, Single rocker platinum - alpha | 1786 JA/02-20 | 1 | piece |
| 2CKA001751A3106 | Rocker for Venetian blind, Single rocker studio white - alpha | 1786 JA/02-24G | 1 | piece |
| 2CKA001751A3114 | Rocker with legend Symbol "arrows" for Switch/push button, palladium - alpha | 1786 JA/02-260 | 1 | piece |
| 2CKA001751A3090 | Mechanical Controls Without imprint for Switch/push button, Single rocker platinum - alpha | 1786-20-500 | 1 | piece |
| 2CKA001751A3081 | Mechanical Controls Without imprint for Switch/push button, Single rocker ivory - alpha | 1786-22G-500 | 1 | piece |
| 2CKA001751A3078 | Mechanical Controls Without imprint for Switch/push button, Single rocker studio white - alpha | 1786-24G-500 | 1 | piece |
| 2CKA001751A3080 | Mechanical Controls Without imprint for Switch/push button, Single rocker palladium - alpha | 1786-260-500 | 1 | piece |
| 2CKA001751A3085 | Mechanical Controls Without imprint for Switch/push button, Single rocker titanium - alpha | 1786-266-500 | 1 | piece |
| 2CKA001751A2045 | Rocker for Switch/push button, Single rocker platinum - alpha | 1787-20 | 1 | piece |
| 2CKA001751A2508 | Rocker for Switch/push button, Single rocker ivory - alpha | 1787-22G | 1 | piece |
| 2CKA001751A2177 | Rocker for Switch/push button, Single rocker studio white - alpha | 1787-24G | 1 | piece |
| 2CKA001751A2824 | Rocker for Switch/push button, Single rocker palladium - alpha | 1787-260 | 1 | piece |
| 2CKA001751A2835 | Rocker for Switch/push button, Single rocker titanium - alpha | 1787-266 | 1 | piece |
| 2CKA001751A1674 | Rocker for Switch/push button, Single rocker platinum - alpha | 1788-20 | 1 | piece |
| 2CKA001751A2557 | Rocker for Switch/push button, Single rocker ivory - alpha | 1788-22G | 1 | piece |
| 2CKA001751A2326 | Rocker for Switch/push button, Single rocker studio white - alpha | 1788-24G | 1 | piece |
| 2CKA001751A2823 | Rocker for Switch/push button, Single rocker palladium - alpha | 1788-260 | 1 | piece |
| 2CKA001751A2834 | Rocker for Switch/push button, Single rocker titanium - alpha | 1788-266 | 1 | piece |
| 2CKA001751A1690 | Rocker with legend Heizung for Switch/push button, Single rocker platinum - alpha | 1789 H-20 | 1 | piece |
| 2CKA001751A2573 | Rocker with legend Heizung for Switch/push button, Single rocker ivory - alpha | 1789 H-22G | 1 | piece |
| 2CKA001751A2375 | Rocker with legend Heizung for Switch/push button, Single rocker studio white - alpha | 1789 H-24G | 1 | piece |
| 2CKA001751A2826 | Rocker with legend Heizung for Switch/push button, Single rocker palladium - alpha | 1789 H-260 | 1 | piece |

| | | | | |
|-----------------|-------------------------------------------------------------------------------------------------|--------------|---|-------|
| 2CKA001751A2837 | Rocker with legend Heizung for Switch/push button, Single rocker titanium - alpha | 1789 H-266 | 1 | piece |
| 2CKA001751A1641 | Rocker for Switch/push button, Single rocker platinum - alpha | 1789 KI-20 | 1 | piece |
| 2CKA001751A2524 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker ivory - alpha | 1789 KI-22G | 1 | piece |
| 2CKA001751A2235 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white - alpha | 1789 KI-24G | 1 | piece |
| 2CKA001751A2829 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker palladium - alpha | 1789 KI-260 | 1 | piece |
| 2CKA001751A2840 | Rocker with legend Symbol "bell" for Switch/push button, Single rocker titanium - alpha | 1789 KI-266 | 1 | piece |
| 2CKA001751A1633 | Rocker with legend Symbol "light" for Switch/push button, Single rocker platinum - alpha | 1789 LI-20 | 1 | piece |
| 2CKA001751A2516 | Rocker with legend Symbol "light" for Switch/push button, Single rocker ivory - alpha | 1789 LI-22G | 1 | piece |
| 2CKA001751A2201 | Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white - alpha | 1789 LI-24G | 1 | piece |
| 2CKA001751A2828 | Rocker with legend Symbol "light" for Switch/push button, Single rocker palladium - alpha | 1789 LI-260 | 1 | piece |
| 2CKA001751A2839 | Rocker with legend Symbol "light" for Switch/push button, Single rocker titanium - alpha | 1789 LI-266 | 1 | piece |
| 2CKA001751A1658 | Rocker with legend Symbol "key/door" for Switch/push button, Single rocker platinum - alpha | 1789 TR-20 | 1 | piece |
| 2CKA001751A2532 | Rocker for Switch/push button, Single rocker ivory - alpha | 1789 TR-22G | 1 | piece |
| 2CKA001751A2268 | Rocker for Switch/push button, Single rocker studio white - alpha | 1789 TR-24G | 1 | piece |
| 2CKA001751A2830 | Rocker for Switch/push button, Single rocker palladium - alpha | 1789 TR-260 | 1 | piece |
| 2CKA001751A2841 | Rocker for Switch/push button, Single rocker titanium - alpha | 1789 TR-266 | 1 | piece |
| 2CKA001751A1625 | Rocker for Switch/push button, Single rocker platinum - alpha | 1789-20 | 1 | piece |
| 2CKA001751A2490 | Rocker for Switch/push button, Single rocker ivory - alpha | 1789-22G | 1 | piece |
| 2CKA001751A2102 | Rocker for Switch/push button, Single rocker studio white - alpha | 1789-24G | 1 | piece |
| 2CKA001751A2825 | Rocker for Switch/push button, Single rocker palladium - alpha | 1789-260 | 1 | piece |
| 2CKA001751A2836 | Rocker for Switch/push button, Single rocker titanium - alpha | 1789-266 | 1 | piece |
| 2CKA001710A3293 | Cover plate with legend Card for Switch/push button, Hotel card Hotel card platinum - alpha | 1792-20-101 | 1 | piece |
| 2CKA001710A3295 | Cover plate with legend Card for Switch/push button, Hotel card Hotel card ivory - alpha | 1792-22G-101 | 1 | piece |
| 2CKA001710A3297 | Cover plate with legend Card for Switch/push button, Hotel card Hotel card studio white - alpha | 1792-24G-101 | 1 | piece |
| 2CKA001710A3305 | Cover plate with legend Card for Switch/push button, Hotel card Hotel card palladium - alpha | 1792-260-101 | 1 | piece |
| 2CKA001710A3331 | Cover plate with legend Card for Switch/push button, Hotel card Hotel card titanium - alpha | 1792-266-101 | 1 | piece |
| 2CKA001710A3684 | Cover plate with legend for Thermostat Turn button platinum - alpha | 1794 TA-20 | 1 | piece |
| 2CKA001710A3686 | Cover plate with legend for Thermostat Turn button ivory - alpha | 1794 TA-22G | 1 | piece |
| 2CKA001710A3688 | Cover plate with legend for Thermostat Turn button white - alpha | 1794 TA-24G | 1 | piece |
| 2CKA001710A3693 | Cover plate with legend for Thermostat Turn button palladium - alpha | 1794 TA-260 | 1 | piece |
| 2CKA001710A3694 | Cover plate with legend for Thermostat Turn button titanium - alpha | 1794 TA-266 | 1 | piece |

| | | | | |
|-----------------|---------------------------------------------------------------------------------------|---------------|---|-------|
| 2CKA001710A3532 | Cover plate with legend for Thermostat Turn button platinum - alpha | 1794-20 | 1 | piece |
| 2CKA001710A3534 | Cover plate with legend for Thermostat Turn button ivory - alpha | 1794-22G | 1 | piece |
| 2CKA001710A3536 | Cover plate with legend for Thermostat Turn button white - alpha | 1794-24G | 1 | piece |
| 2CKA001710A3541 | Cover plate with legend for Thermostat Turn button other - alpha | 1794-260 | 1 | piece |
| 2CKA001710A3542 | Cover plate with legend for Thermostat Turn button titanium - alpha | 1794-266 | 1 | piece |
| 2CKA001710A3998 | Cover plate with legend for Thermostat Turn button platinum - alpha | 1795 HK-20 | 1 | piece |
| 2CKA001710A4000 | Cover plate with legend for Thermostat Turn button ivory - alpha | 1795 HK-22G | 1 | piece |
| 2CKA001710A4002 | Cover plate with legend for Thermostat Turn button white - alpha | 1795 HK-24G | 1 | piece |
| 2CKA001710A4003 | Cover plate with legend for Thermostat Turn button other - alpha | 1795 HK-260 | 1 | piece |
| 2CKA001710A4004 | Cover plate with legend for Thermostat Turn button titanium - alpha | 1795 HK-266 | 1 | piece |
| 2CKA001710A4030 | Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha | 1795 HKEA-20 | 1 | piece |
| 2CKA001710A4032 | Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha | 1795 HKEA-22G | 1 | piece |
| 2CKA001710A4034 | Cover plate with legend for Thermostat Turn button 1 sliding switch white - alpha | 1795 HKEA-24G | 1 | piece |
| 2CKA001710A4035 | Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha | 1795 HKEA-260 | 1 | piece |
| 2CKA001710A4036 | Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha | 1795 HKEA-266 | 1 | piece |
| 2CKA001710A3711 | Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha | 1795 TA-20 | 1 | piece |
| 2CKA001710A3713 | Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha | 1795 TA-22G | 1 | piece |
| 2CKA001710A3715 | Cover plate with legend for Thermostat Turn button 1 sliding switch white - alpha | 1795 TA-24G | 1 | piece |
| 2CKA001710A3720 | Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha | 1795 TA-260 | 1 | piece |
| 2CKA001710A3721 | Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha | 1795 TA-266 | 1 | piece |
| 2CKA001710A3557 | Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha | 1795-20 | 1 | piece |
| 2CKA001710A3559 | Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha | 1795-22G | 1 | piece |
| 2CKA001710A3561 | Cover plate with legend for Thermostat Turn button 1 sliding switch white - alpha | 1795-24G | 1 | piece |
| 2CKA001710A3566 | Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha | 1795-260 | 1 | piece |
| 2CKA001710A3567 | Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha | 1795-266 | 1 | piece |
| 2CKA001753A9178 | Cover plate with labelling field Modular Jack 2 gang platinum - alpha | 1800-20 | 1 | piece |
| 2CKA001710A2645 | Cover plate with labelling field Modular Jack 2 gang ivory - alpha | 1800-22G | 1 | piece |
| 2CKA001710A2710 | Cover plate with labelling field Modular Jack 2 gang studio white - alpha | 1800-24G | 1 | piece |
| 2CKA001710A3318 | Cover Plate Modular Jack 2 gang palladium - alpha | 1800-260 | 1 | piece |
| 2CKA001710A3344 | Cover plate with labelling field Modular Jack 2 gang titanium - alpha | 1800-266 | 1 | piece |
| 2CKA001753A8485 | Cover Plate UAE/IAE (ISDN) 2 gang platinum - alpha | 1803-02-20 | 1 | piece |
| 2CKA001710A2611 | Cover Plate UAE/IAE (ISDN) 2 gang ivory - alpha | 1803-02-22G | 1 | piece |

| | | | | |
|-----------------|-------------------------------------------------------------|------------------|---|-------|
| 2CKA001710A2033 | Cover Plate UAE/IAE (ISDN) 2 gang studio white - alpha | 1803-02-24G | 1 | piece |
| 2CKA001710A3321 | Cover Plate UAE/IAE (ISDN) 2 gang palladium - alpha | 1803-02-260 | 1 | piece |
| 2CKA001710A3347 | Cover Plate UAE/IAE (ISDN) 2 gang titanium - alpha | 1803-02-266 | 1 | piece |
| 2CKA001753A8410 | Cover Plate UAE/IAE (ISDN) 1 gang platinum - alpha | 1803-20 | 1 | piece |
| 2CKA001710A2603 | Cover Plate UAE/IAE (ISDN) 2 gang ivory - alpha | 1803-22G | 1 | piece |
| 2CKA001710A2025 | Cover Plate UAE/IAE (ISDN) 1 gang studio white - alpha | 1803-24G | 1 | piece |
| 2CKA001710A3322 | Cover Plate UAE/IAE (ISDN) 1 gang palladium - alpha | 1803-260 | 1 | piece |
| 2CKA001710A3348 | Cover Plate UAE/IAE (ISDN) 1 gang titanium - alpha | 1803-266 | 1 | piece |
| 2CKA002011A6222 | Socket Outlets platinum - alpha | 20 EUC-20-500 | 1 | piece |
| 2CKA002011A6225 | Socket Outlets ivory - alpha | 20 EUC-22G-500 | 1 | piece |
| 2CKA002011A6223 | Socket Outlets studio white - alpha | 20 EUC-24G-500 | 1 | piece |
| 2CKA002011A6229 | Socket Outlets palladium - alpha | 20 EUC-260-500 | 1 | piece |
| 2CKA002011A6226 | Socket Outlets titanium - alpha | 20 EUC-266-500 | 1 | piece |
| 2CKA002013A4458 | SCHUKO® socket insert Safety Shutter platinum - alpha | 20 EUCKS-20 | 1 | piece |
| 2CKA002013A5240 | Socket insert Safety Shutter ivory white - alpha | 20 EUCKS-22G | 1 | piece |
| 2CKA002013A5377 | Socket Outlets studio white - alpha | 20 EUCKS-24G-500 | 1 | piece |
| 2CKA002013A5252 | Socket insert Safety Shutter palladium - alpha | 20 EUCKS-260 | 1 | piece |
| 2CKA002013A5253 | SCHUKO® socket insert Safety Shutter titanium - alpha | 20 EUCKS-266 | 1 | piece |
| 2CKA002018A0695 | SCHUKO® socket insert with Hinged Lid platinum - alpha | 20 EUK-20 | 1 | piece |
| 2CKA002018A1446 | Socket insert with Hinged Lid ivory white - alpha | 20 EUK-22G | 1 | piece |
| 2CKA002018A1040 | SCHUKO® socket insert with Hinged Lid studio white - alpha | 20 EUK-24G | 1 | piece |
| 2CKA002018A1464 | Socket insert with Hinged Lid palladium - alpha | 20 EUK-260 | 1 | piece |
| 2CKA002018A1466 | SCHUKO® socket insert with Hinged Lid titanium - alpha | 20 EUK-266 | 1 | piece |
| 2CKA002017A0808 | Socket insert platinum - alpha | 20 MUC-20-500 | 1 | piece |
| 2CKA002017A0813 | Socket with Earthing pin ivory white - alpha | 20 MUC-22G-500 | 1 | piece |
| 2CKA002017A0815 | Socket Outlets French norm NF studio white - alpha | 20 MUC-24G-500 | 1 | piece |
| 2CKA002017A0817 | Socket insert palladium - alpha | 20 MUC-260-500 | 1 | piece |
| 2CKA002017A0818 | Socket insert titanium - alpha | 20 MUC-266-500 | 1 | piece |
| 2CKA002017A0825 | Socket insert platinum - alpha | 20 MUCC-20-500 | 1 | piece |
| 2CKA002017A0828 | Socket Outlets French norm NF ivory - alpha | 20 MUCC-22G-500 | 1 | piece |
| 2CKA002017A0829 | Socket insert studio white - alpha | 20 MUCC-24G-500 | 1 | piece |
| 2CKA002017A0832 | Socket insert Safety Shutter platinum - alpha | 20 MUCKS-20-500 | 1 | piece |
| 2CKA002017A0802 | Socket with Earthing pin Safety Shutter ivory white - alpha | 20 MUCKS-22G-500 | 1 | piece |

| | | | | |
|-----------------|---------------------------------------------------------------------------------------------|---------------------|---|-------|
| 2CKA002017A0803 | Socket Outlets French norm NF studio white - alpha | 20 MUCKS-24G-500 | 1 | piece |
| 2CKA002017A0804 | Socket insert Safety Shutter palladium - alpha | 20 MUCKS-260-500 | 1 | piece |
| 2CKA002017A0805 | Socket insert Safety Shutter titanium - alpha | 20 MUCKS-266-500 | 1 | piece |
| 2CKA002113A0505 | Socket Outlets ivory - alpha | 2300 UCRKS-22G-503 | 1 | piece |
| 2CKA002111A0623 | Socket Outlets studio white - alpha | 2300 UCRKS-24G-503 | 1 | piece |
| 2CKA002113A0508 | Socket Outlets palladium - alpha | 2300 UCRKS-260-503 | 1 | piece |
| 2CKA002113A0509 | Socket Outlets titanium - alpha | 2300 UCRKS-266-503 | 1 | piece |
| 2CKA002113A0033 | Socket Outlets platinum - alpha | 2300-01 UC-20-500 | 1 | piece |
| 2CKA002011A3819 | Busch-Protector® SCHUKO® socket insert platinum - alpha | 2310 EUGL/VA-20-11 | 1 | piece |
| 2CKA002011A3821 | Busch-Protector® SCHUKO® socket insert ivory white - alpha | 2310 EUGL/VA-22G-11 | 1 | piece |
| 2CKA002011A3823 | Busch-Protector® SCHUKO® socket insert studio white - alpha | 2310 EUGL/VA-24G-11 | 1 | piece |
| 2CKA002011A3828 | Busch-Protector® SCHUKO® socket insert palladium - alpha | 2310 EUGL/VA-260-11 | 1 | piece |
| 2CKA002011A3829 | Busch-Protector® SCHUKO® socket insert titanium - alpha | 2310 EUGL/VA-266-11 | 1 | piece |
| 2CKA002099A0225 | Socket Outlets platinum - alpha | 2399 UCKS-20 | 1 | piece |
| 2CKA002099A0219 | Socket Outlets ivory - alpha | 2399 UCKS-22G | 1 | piece |
| 2CKA002099A0220 | Socket Outlets studio white - alpha | 2399 UCKS-24G | 1 | piece |
| 2CKA002099A0223 | Socket Outlets palladium - alpha | 2399 UCKS-260 | 1 | piece |
| 2CKA002099A0224 | Socket Outlets titanium - alpha | 2399 UCKS-266 | 1 | piece |
| 2CKA001710A3113 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button platinum - alpha | 2542 DR/01-20 | 1 | piece |
| 2CKA001710A3115 | Cover Plate Symbol "0-1-2-3" for Level switch, Turn button ivory - alpha | 2542 DR/01-22G | 1 | piece |
| 2CKA001710A3117 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white - alpha | 2542 DR/01-24G | 1 | piece |
| 2CKA001710A3464 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button palladium - alpha | 2542 DR/01-260 | 1 | piece |
| 2CKA001710A3466 | Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button titanium - alpha | 2542 DR/01-266 | 1 | piece |
| 2CKA001710A3424 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button platinum - alpha | 2542 DR/02-20 | 1 | piece |
| 2CKA001710A3426 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button ivory - alpha | 2542 DR/02-22G | 1 | piece |
| 2CKA001710A3428 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white - alpha | 2542 DR/02-24G | 1 | piece |
| 2CKA001710A3465 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button palladium - alpha | 2542 DR/02-260 | 1 | piece |
| 2CKA001710A3467 | Cover plate with legend Symbol "1-2-3" for Level switch, Turn button titanium - alpha | 2542 DR/02-266 | 1 | piece |
| 2CKA001753A4047 | Cover Plate Modular Jack 2 gang platinum - alpha | 2561-02-20 | 1 | piece |
| 2CKA001710A2512 | Cover Plate Modular Jack 2 gang ivory - alpha | 2561-02-22G | 1 | piece |
| 2CKA001753A7800 | Cover Plate Modular Jack 2 gang studio white - alpha | 2561-02-24G | 1 | piece |
| 2CKA001710A3315 | Cover Plate Modular Jack 2 gang palladium - alpha | 2561-02-260 | 1 | piece |
| 2CKA001710A3341 | Cover Plate Modular Jack 2 gang titanium - alpha | 2561-02-266 | 1 | piece |

| | | | | |
|-----------------|----------------------------------------------------------------------------|-----------------|---|-------|
| 2CKA001753A3916 | Cover Plate Modular Jack 1 gang platinum - alpha | 2561-20 | 1 | piece |
| 2CKA001710A2504 | Cover Plate Modular Jack 1 gang ivory - alpha | 2561-22G | 1 | piece |
| 2CKA001753A7776 | Cover Plate Modular Jack 1 gang studio white - alpha | 2561-24G | 1 | piece |
| 2CKA001710A3314 | Cover Plate Modular Jack 1 gang palladium - alpha | 2561-260 | 1 | piece |
| 2CKA001710A3340 | Cover Plate Modular Jack 1 gang titanium - alpha | 2561-266 | 1 | piece |
| 2CKA002122A0028 | Busch-NEMA Socket insert studio white - alpha 3016 EUC-24G | | 1 | piece |
| 2CKA006115A0476 | 6108/61-20-500 Coverplate f. CE | 6108/61-20-500 | 1 | piece |
| 2CKA006115A0478 | 6108/61-22G-500 Coverplate f. CE | 6108/61-22G-500 | 1 | piece |
| 2CKA006115A0480 | 6108/61-24G-500 Coverplate f. CE | 6108/61-24G-500 | 1 | piece |
| 2CKA006115A0481 | 6108/61-260-500 Coverplate f. CE | 6108/61-260-500 | 1 | piece |
| 2CKA006115A0482 | 6108/61-266-500 Coverplate f. CE | 6108/61-266-500 | 1 | piece |
| 2CKA006155A0053 | 6109/03-20-500 Coverplate f. RTC | 6109/03-20-500 | 1 | piece |
| 2CKA006155A0055 | 6109/03-22G-500 Coverplate f. RTC | 6109/03-22G-500 | 1 | piece |
| 2CKA006155A0057 | 6109/03-24G-500 Coverplate f. RTC | 6109/03-24G-500 | 1 | piece |
| 2CKA006155A0058 | 6109/03-260-500 Coverplate f. RTC | 6109/03-260-500 | 1 | piece |
| 2CKA006155A0059 | 6109/03-266-500 Coverplate f. RTC | 6109/03-266-500 | 1 | piece |
| 2CKA006430A0319 | Control Element for Venetian blind Single push button platinum - alpha | 6430-20-102 | 1 | piece |
| 2CKA006430A0321 | Control Element for Venetian blind Single push button ivory - alpha | 6430-22G-102 | 1 | piece |
| 2CKA006430A0323 | Control Element for Venetian blind Single push button studio white - alpha | 6430-24G-102 | 1 | piece |
| 2CKA006430A0317 | Control Element for Venetian blind Single push button palladium - alpha | 6430-260-102 | 1 | piece |
| 2CKA006430A0318 | Control Element for Venetian blind Single push button titanium - alpha | 6430-266-102 | 1 | piece |
| 2CKA006430A0291 | Cover plate with legend for Time switch platinum - alpha | 6435-20 | 1 | piece |
| 2CKA006430A0293 | Cover plate with legend for Time switch ivory - alpha | 6435-22G | 1 | piece |
| 2CKA006430A0295 | Cover plate with legend for Time switch studio white - alpha | 6435-24G | 1 | piece |
| 2CKA006430A0289 | Cover plate with legend for Time switch palladium - alpha | 6435-260 | 1 | piece |
| 2CKA006430A0290 | Cover plate with legend for Time switch titanium - alpha | 6435-266 | 1 | piece |
| 2CKA006599A1458 | Cover Plate for Dimmer Turn button platinum - alpha | 6540-20 | 1 | piece |
| 2CKA006599A2324 | Cover Plate for Dimmer Turn button studio white - alpha | 6540-24G | 1 | piece |
| 2CKA006599A2852 | Cover Plate for Dimmer Turn button palladium - alpha | 6540-260 | 1 | piece |
| 2CKA006599A2855 | Cover Plate for Dimmer Turn button titanium - alpha | 6540-266 | 1 | piece |
| 2CKA006599A1466 | Cover Plate for Cooling Central cover plate platinum - alpha | 6541-20 | 1 | piece |
| 2CKA006599A2795 | Cover Plate for Cooling Central cover plate ivory - alpha | 6541-22G | 1 | piece |
| 2CKA006599A2332 | Cover Plate for Cooling Central cover plate studio white - alpha | 6541-24G | 1 | piece |

| | | | | |
|-----------------|------------------------------------------------------------------------------------------|--------------|---|-------|
| 2CKA006599A2853 | Cover Plate for Cooling Central cover plate palladium - alpha | 6541-260 | 1 | piece |
| 2CKA006599A2856 | Cover Plate for Cooling Central cover plate titanium - alpha | 6541-266 | 1 | piece |
| 2CKA006599A2820 | Control Element for Switch/dimmer Single push button with Neon lamp platinum - alpha | 6543-20-102 | 1 | piece |
| 2CKA006599A2822 | Control Element for Switch/dimmer Single push button with Neon lamp ivory - alpha | 6543-22G-102 | 1 | piece |
| 2CKA006599A2824 | Control Element for Switch/dimmer Single push button with Neon lamp studio white - alpha | 6543-24G-102 | 1 | piece |
| 2CKA006599A2869 | Control Element for Switch/dimmer Single push button with Neon lamp palladium - alpha | 6543-260-102 | 1 | piece |
| 2CKA006599A2870 | Control Element for Switch/dimmer Single push button with Neon lamp titanium - alpha | 6543-266-102 | 1 | piece |
| 2CKA006599A2890 | Control Element for Dimmer Two-part button with Neon lamp platinum - alpha | 6545-20 | 1 | piece |
| 2CKA006599A2892 | Control Element for Dimmer Two-part button with Neon lamp ivory - alpha | 6545-22G | 1 | piece |
| 2CKA006599A2894 | Control Element for Dimmer Two-part button with Neon lamp studio white - alpha | 6545-24G | 1 | piece |
| 2CKA006599A2899 | Control Element for Dimmer Two-part button with Neon lamp palladium - alpha | 6545-260 | 1 | piece |
| 2CKA006599A2900 | Control Element for Dimmer Two-part button with Neon lamp titanium - alpha | 6545-266 | 1 | piece |

Catégories

Produits basse tension → Wiring Accessories - Light Switch Ranges → Frames

