

PRODUCT-DETAILS

1721 KA-20

Cover Frame 1gang platinum - alpha exclusive



Informations générales

Extension du type de produit	1721 KA-20
Code de produit	2CKA001754A4373
EAN	4011395125625
Description courte	Cover Frame 1gang platinum - alpha exclusive
Description longue	1721 KA-20 Frame 1-gang

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	No document needed
Number of Gangs	1
Design Range	alpha exclusive alpha
Type de montage	Flush Mounted
Type of Fastening	Clamp
Sens de montage	Horizontal Vertical

Finition de surface	Matt Anodised
Matériau	Aluminium
Label Space Provided	No
Couleur	platinum

Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E2720
REACH Declaration	2CKA309999E9999
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Dimensions

Produit Largeur Net	81 mm
Produit Hauteur Net	81 mm
Produit Longueur Net	11 mm
Poids net	19 g
Schéma dimensionnel	2CKA000097E0310

Commande

ID du produit remplacé	1754-0-4373
------------------------	-------------

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E2720
--------------------------------	-----------------

Classifications

ETIM 8	EC000007 - Cover frame for domestic switching devices
ETIM 9	EC000007 - Cover frame for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144001

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
2CKA001753A1092	Cover plate with legend Symbol "arrows" and "0" for Venetian blind, Turn button platinum - alpha	1740 DR-20	1	piece
2CKA001753A8279	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button platinum - alpha	1740 DRL-20	1	piece
2CKA001753A1118	Cover Plate Blind cap 1 gang with Mounting plate platinum - alpha	1742-20	1	piece

2CKA001724A2747	Cover Plate SAT 3 gang platinum - alpha	1743-03-20-101	1	piece
2CKA001753A1126	Cover Plate SAT 2 gang platinum - alpha	1743-20	1	piece
2CKA001753A8550	Cover Plate Telecommunication inserts 50 x 50 mm platinum - alpha	1746/10-20	1	piece
2CKA001753A1753	Cover Plate with Hinged Lid Telecommunication inserts 1 gang platinum - alpha	1746-20 FN	1	piece
2CKA001753A5978	Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang platinum - alpha	1746-20-101	1	piece
2CKA001753A1167	Cover Plate Data connection 2 gang platinum - alpha	1748-20	1	piece
2CKA001710A0904	Cover Plate Cable outlet with Mounting plate platinum - alpha	1749-20	1	piece
2CKA001723A0113	Cover Plate Loudspeaker 2 gang platinum - alpha	1751-20	1	piece
2CKA001753A1506	Cover Plate Busch-Infolicht® platinum - alpha	1756-20	1	piece
2CKA001724A1010	Cover plate with labelling field For data connection housing 2 gang platinum - alpha	1758-20	1	piece
2CKA001753A2629	Cover Plate TAE 1 gang platinum - alpha	1766-20	1	piece
2CKA001753A8832	Data / Telecommunication / Antenna AMP-ACO 1 gang platinum - alpha	1769-20	1	piece
2CKA001753A6075	Cover plate with legend Symbol "1" for Time switch, Turn button platinum - alpha	1770-20-101	1	piece
2CKA001753A6224	Cover plate with legend Symbol "0" for Time switch, Turn button platinum - alpha	1771-20-101	1	piece
2CKA001751A1666	Rocker with labelling field for Switch/push button, Single rocker platinum - alpha	1781-20	1	piece
2CKA001751A3113	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker platinum - alpha	1785 JA/02-20	1	piece
2CKA001751A1823	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker platinum - alpha	1785 JA-20	1	piece
2CKA001751A3138	Rocker for Switch/push button, Two-part rocker platinum - alpha	1785 K-20	1	piece
2CKA001751A1682	Rocker for Switch/push button, Two-part rocker platinum - alpha	1785-20	1	piece
2CKA001751A3112	Rocker for Venetian blind, Single rocker platinum - alpha	1786 JA/02-20	1	piece
2CKA001751A3090	Mechanical Controls Without imprint for Switch/push button, Single rocker platinum - alpha	1786-20-500	1	piece
2CKA001751A2045	Rocker for Switch/push button, Single rocker platinum - alpha	1787-20	1	piece
2CKA001751A1674	Rocker for Switch/push button, Single rocker platinum - alpha	1788-20	1	piece
2CKA001751A1690	Rocker with legend Heizung for Switch/push button, Single rocker platinum - alpha	1789 H-20	1	piece
2CKA001751A1641	Rocker for Switch/push button, Single rocker platinum - alpha	1789 KI-20	1	piece
2CKA001751A1633	Rocker with legend Symbol "light" for Switch/push button, Single rocker platinum - alpha	1789 LI-20	1	piece
2CKA001751A1658	Rocker with legend Symbol "key/door" for Switch/push button, Single rocker platinum - alpha	1789 TR-20	1	piece
2CKA001751A1625	Rocker for Switch/push button, Single rocker platinum - alpha	1789-20	1	piece
2CKA001710A3293	Cover plate with legend Card for Switch/push button, Hotel card Hotel card platinum - alpha	1792-20-101	1	piece
2CKA001710A3684	Cover plate with legend for Thermostat Turn button platinum - alpha	1794 TA-20	1	piece
2CKA001710A3532	Cover plate with legend for Thermostat Turn button platinum - alpha	1794-20	1	piece
2CKA001710A3998	Cover plate with legend for Thermostat Turn button platinum - alpha	1795 HK-20	1	piece
2CKA001710A4030	Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha	1795 HKEA-20	1	piece

2CKA001710A3711	Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha	1795 TA-20	1	piece
2CKA001710A3557	Cover plate with legend for Thermostat Turn button 1 sliding switch platinum - alpha	1795-20	1	piece
2CKA001753A9178	Cover plate with labelling field Modular Jack 2 gang platinum - alpha	1800-20	1	piece
2CKA001753A8485	Cover Plate UAE/IAE (ISDN) 2 gang platinum - alpha	1803-02-20	1	piece
2CKA001753A8410	Cover Plate UAE/IAE (ISDN) 1 gang platinum - alpha	1803-20	1	piece
2CKA002011A6222	Socket Outlets platinum - alpha	20 EUC-20-500	1	piece
2CKA002013A4458	SCHUKO® socket insert Safety Shutter platinum - alpha	20 EUCKS-20	1	piece
2CKA002018A0695	SCHUKO® socket insert with Hinged Lid platinum - alpha	20 EUK-20	1	piece
2CKA002017A0808	Socket insert platinum - alpha	20 MUC-20-500	1	piece
2CKA002017A0825	Socket insert platinum - alpha	20 MUCC-20-500	1	piece
2CKA002017A0832	Socket insert Safety Shutter platinum - alpha	20 MUCKS-20-500	1	piece
2CKA002113A0033	Socket Outlets platinum - alpha	2300-01 UC-20-500	1	piece
2CKA002011A3819	Busch-Protector® SCHUKO® socket insert platinum - alpha	2310 EUGL/VA-20-11	1	piece
2CKA002099A0225	Socket Outlets platinum - alpha	2399 UCKS-20	1	piece
2CKA001710A3113	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button platinum - alpha	2542 DR/01-20	1	piece
2CKA001710A3424	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button platinum - alpha	2542 DR/02-20	1	piece
2CKA001753A4047	Cover Plate Modular Jack 2 gang platinum - alpha	2561-02-20	1	piece
2CKA001753A3916	Cover Plate Modular Jack 1 gang platinum - alpha	2561-20	1	piece
2CKA006115A0476	6108/61-20-500 Coverplate f. CE	6108/61-20-500	1	piece
2CKA006155A0053	6109/03-20-500 Coverplate f. RTC	6109/03-20-500	1	piece
2CKA006430A0319	Control Element for Venetian blind Single push button platinum - alpha	6430-20-102	1	piece
2CKA006430A0291	Cover plate with legend for Time switch platinum - alpha	6435-20	1	piece
2CKA006599A1458	Cover Plate for Dimmer Turn button platinum - alpha	6540-20	1	piece
2CKA006599A1466	Cover Plate for Cooling Central cover plate platinum - alpha	6541-20	1	piece
2CKA006599A2820	Control Element for Switch/dimmer Single push button with Neon lamp platinum - alpha	6543-20-102	1	piece
2CKA006599A2890	Control Element for Dimmer Two-part button with Neon lamp platinum - alpha	6545-20	1	piece
2CKA008200A0093	Cover Plate Loudspeaker platinum - alpha	8253-20	1	piece
2CKA001731A1931	Cover Busch-Infolicht® ivory - alpha	1716-22	1	piece
2CKA001731A1933	Cover Busch-Infolicht® studio white - alpha	1716-24G	1	piece
2CKA001731A1938	Cover Busch-Infolicht® palladium - alpha	1716-260	1	piece
2CKA001731A1939	Cover Busch-Infolicht® titanium - alpha	1716-266	1	piece
2CKA001753A1175	Cover plate with legend Symbol "arrows" and "0" for Venetian blind, Turn button bronze - alpha	1740 DR-21	1	piece
2CKA001710A2330	Cover Plate Symbol "arrows" and "0" for Venetian blind, Turn button ivory - alpha	1740 DR-22G	1	piece
2CKA001753A7263	Cover plate with legend Symbol "arrows" and "0" for Venetian blind, Turn button studio white - alpha	1740 DR-24G	1	piece

2CKA001710A3302	Cover Plate Symbol "arrows" and "0" for Venetian blind, Turn button palladium - alpha	1740 DR-260	1	piece
2CKA001710A3328	Cover plate with legend Symbol "arrows" and "0" for Venetian blind, Turn button titanium - alpha	1740 DR-266	1	piece
2CKA001753A8287	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button bronze - alpha	1740 DRL-21	1	piece
2CKA001710A3032	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button ivory - alpha	1740 DRL-22G	1	piece
2CKA001753A8246	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button studio white - alpha	1740 DRL-24G	1	piece
2CKA001710A3457	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button palladium - alpha	1740 DRL-260-503	1	piece
2CKA001710A3459	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button titanium - alpha	1740 DRL-266-503	1	piece
2CKA001753A1431	Cover Plate Blind cap 1 gang with Mounting plate bronze - alpha	1742-21	1	piece
2CKA001710A2389	Cover Plate Blind cap 0 gang with Mounting plate ivory - alpha	1742-22G	1	piece
2CKA001753A7412	Cover Plate Blind cap 1 gang with Mounting plate studio white - alpha	1742-24G	1	piece
2CKA001710A3309	Cover Plate Blind cap 1 gang with Mounting plate palladium - alpha	1742-260	1	piece
2CKA001710A3335	Cover Plate Blind cap 1 gang with Mounting plate titanium - alpha	1742-266	1	piece
2CKA001724A2727	Data / Telecommunication / Antenna SAT 1 gang ivory - alpha	1743-01-22-500	1	piece
2CKA001724A2822	Cover Plate SAT 1 gang palladium - alpha	1743-01-260-500	1	piece
2CKA001724A2825	Cover Plate SAT 1 gang titanium - alpha	1743-01-266-500	1	piece
2CKA001724A2748	Cover Plate TV / Radio / SAT 3 gang bronze - alpha	1743-03-21-101	1	piece
2CKA001724A2463	Cover Plate TV / Radio / SAT 3 gang ivory - alpha	1743-03-22G	1	piece
2CKA001724A1911	Cover Plate SAT 3 gang studio white - alpha	1743-03-24G	1	piece
2CKA001724A2792	Cover Plate SAT 3 gang palladium - alpha	1743-03-260	1	piece
2CKA001724A2797	Cover Plate SAT 3 gang titanium - alpha	1743-03-266	1	piece
2CKA001753A1449	Cover Plate SAT 2 gang bronze - alpha	1743-21	1	piece
2CKA001710A2454	Cover Plate SAT 2 gang ivory - alpha	1743-22G	1	piece
2CKA001753A7628	Cover Plate SAT 2 gang studio white - alpha	1743-24G	1	piece
2CKA001724A2791	Cover Plate SAT 2 gang palladium - alpha	1743-260	1	piece
2CKA001724A2796	Cover Plate SAT 2 gang titanium - alpha	1743-266	1	piece
2CKA001753A8568	Cover Plate Telecommunication inserts 50 x 50 mm bronze - alpha	1746/10-21	1	piece
2CKA001710A2652	Cover Plate Telecommunication inserts 50 x 50 mm ivory - alpha	1746/10-22G	1	piece
2CKA001710A2744	Cover Plate Telecommunication inserts 50 x 50 mm studio white - alpha	1746/10-24G	1	piece
2CKA001710A3312	Cover Plate Telecommunication inserts 50 x 50 mm palladium - alpha	1746/10-260	1	piece
2CKA001710A3338	Cover Plate Telecommunication inserts 50 x 50 mm titanium - alpha	1746/10-266	1	piece
2CKA001753A1761	Cover Plate with Hinged Lid Telecommunication inserts 1 gang bronze - alpha	1746-21 FN	1	piece
2CKA001753A5986	Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang bronze - alpha	1746-21-101	1	piece
2CKA001710A2488	Cover Plate with Hinged Lid Telecommunication inserts 1 gang ivory - alpha	1746-22G FN	1	piece
2CKA001710A2470	Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang ivory - alpha	1746-22G-101	1	piece
2CKA001753A7719	Cover Plate with Hinged Lid Telecommunication inserts 1 gang studio white - alpha	1746-24G FN	1	piece

2CKA001753A7685	Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang studio white - alpha	1746-24G-101	1	piece
2CKA001710A3311	Cover Plate with Hinged Lid Telecommunication inserts 1 gang palladium - alpha	1746-260 FN	1	piece
2CKA001710A3313	Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang palladium - alpha	1746-260-101	1	piece
2CKA001710A3337	Cover Plate with Hinged Lid Telecommunication inserts 1 gang titanium - alpha	1746-266 FN	1	piece
2CKA001710A3339	Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang titanium - alpha	1746-266-101	1	piece
2CKA001753A1480	Cover Plate Data connection 2 gang bronze - alpha	1748-21	1	piece
2CKA001710A2546	Cover Plate Data connection 2 gang ivory - alpha	1748-22G	1	piece
2CKA001753A7891	Cover Plate Data connection 2 gang studio white - alpha	1748-24G	1	piece
2CKA001710A3323	Cover Plate Data connection 2 gang palladium - alpha	1748-260	1	piece
2CKA001710A3349	Cover Plate Data connection 2 gang titanium - alpha	1748-266	1	piece
2CKA001710A0946	Cover Plate Cable outlet with Mounting plate bronze - alpha	1749-21	1	piece
2CKA001710A2561	Cover Plate Cable outlet ivory - alpha	1749-22G	1	piece
2CKA001710A1209	Cover Plate Cable outlet with Mounting plate studio white - alpha	1749-24G	1	piece
2CKA001710A3316	Cover Plate Cable outlet palladium - alpha	1749-260	1	piece
2CKA001710A3342	Cover Plate Cable outlet with Mounting plate titanium - alpha	1749-266	1	piece
2CKA001723A0121	Cover Plate Loudspeaker 2 gang bronze - alpha	1751-21	1	piece
2CKA001723A0238	Cover Plate Loudspeaker 2 gang ivory - alpha	1751-22G	1	piece
2CKA001723A0204	Cover Plate Loudspeaker 2 gang studio white - alpha	1751-24G	1	piece
2CKA001723A0245	Cover Plate Loudspeaker 2 gang palladium - alpha	1751-260	1	piece
2CKA001723A0246	Cover Plate Loudspeaker 2 gang titanium - alpha	1751-266	1	piece
2CKA001710A2348	Cover plate with legend Symbol "arrows" for Venetian blind, Key ivory - alpha	1755 PZ-22G-101	1	piece
2CKA001710A1522	Cover plate with legend Symbol "arrows" for Venetian blind, Key studio white - alpha	1755 PZ-24G-101	1	piece
2CKA001710A2355	Cover plate with legend Characters 0 and 1 for Venetian blind, Key ivory - alpha	1755 SLPZ-22G-101	1	piece
2CKA001710A1597	Cover plate with legend Characters 0 and 1 for Venetian blind, Key studio white - alpha	1755 SLPZ-24G-101	1	piece
2CKA001753A1522	Cover Plate Busch-Infolicht® bronze - alpha	1756-21	1	piece
2CKA001710A2413	Cover Plate Busch-Infolicht® ivory - alpha	1756-22G	1	piece
2CKA001753A7503	Cover Plate Busch-Infolicht® studio white - alpha	1756-24G	1	piece
2CKA001710A3306	Cover Plate Busch-Infolicht® palladium - alpha	1756-260	1	piece
2CKA001710A3332	Cover Plate Busch-Infolicht® titanium - alpha	1756-266	1	piece
2CKA001724A1028	Cover plate with labelling field For data connection housing 2 gang bronze - alpha	1758-21	1	piece
2CKA001724A2513	Cover plate with labelling field For data connection housing 2 gang ivory - alpha	1758-22G	1	piece
2CKA001724A2067	Cover plate with labelling field For data connection housing 2 gang studio white - alpha	1758-24G	1	piece
2CKA001724A2793	Cover Plate For data connection housing 2 gang palladium - alpha	1758-260	1	piece
2CKA001724A2798	Cover plate with labelling field For data connection housing 2 gang titanium - alpha	1758-266	1	piece
2CKA001731A1858	Rocker with labelling field for Switch/push button, Single rocker ivory - alpha	1764 NLI-22G	1	piece
2CKA001731A1569	Rocker with labelling field for Switch/push button, Single rocker studio white - alpha	1764 NLI-24G	1	piece

2CKA001753A2637	Cover Plate TAE 1 gang bronze - alpha	1766-21	1	piece
2CKA001710A2496	Cover Plate TAE 1 gang ivory - alpha	1766-22G	1	piece
2CKA001753A7743	Cover Plate TAE 1 gang studio white - alpha	1766-24G	1	piece
2CKA001710A3310	Cover Plate TAE 1 gang palladium - alpha	1766-260	1	piece
2CKA001710A3336	Cover Plate TAE 1 gang titanium - alpha	1766-266	1	piece
2CKA001753A8840	Data / Telecommunication / Antenna AMP-ACO 1 gang bronze - alpha	1769-21	1	piece
2CKA001710A2678	Data / Telecommunication / Antenna AMP-ACO 1 gang ivory white - alpha	1769-22G	1	piece
2CKA001710A2736	Cover plate with labelling field AMP-ACO 1 gang studio white - alpha	1769-24G	1	piece
2CKA001710A3317	Data / Telecommunication / Antenna AMP-ACO 1 gang palladium - alpha	1769-260	1	piece
2CKA001710A3343	Data / Telecommunication / Antenna AMP-ACO 1 gang titanium - alpha	1769-266	1	piece
2CKA001753A6083	Cover plate with legend Symbol "1" for Time switch, Turn button bronze - alpha	1770-21-101	1	piece
2CKA001710A2397	Cover Plate 1 ... 15 Min for Time switch, Turn button ivory - alpha	1770-22G-101	1	piece
2CKA001753A7446	Cover plate with legend Symbol "1" for Time switch, Turn button white - alpha	1770-24G-101	1	piece
2CKA001753A6232	Cover plate with legend Symbol "0" for Time switch, Turn button bronze - alpha	1771-21-101	1	piece
2CKA001710A2405	Cover plate with legend 10 ... 120 Min for Time switch, Turn button ivory - alpha	1771-22G-101	1	piece
2CKA001753A7479	Cover plate with legend Symbol "0" for Time switch, Turn button white - alpha	1771-24G-101	1	piece
2CKA001753A7354	Accessories Timer Time indication white - alpha	1775-24G-101	1	piece
2CKA001751A1757	Rocker with labelling field for Switch/push button, Single rocker bronze - alpha	1781-21	1	piece
2CKA001751A2540	Rocker with labelling field for Switch/push button, Single rocker ivory - alpha	1781-22G	1	piece
2CKA001751A2292	Rocker with labelling field for Switch/push button, Single rocker studio white - alpha	1781-24G	1	piece
2CKA001751A2822	Rocker for Switch/push button, Single rocker palladium - alpha	1781-260	1	piece
2CKA001751A2833	Rocker with labelling field for Switch/push button, Single rocker titanium - alpha	1781-266	1	piece
2CKA001751A3111	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker bronze - alpha	1785 JA/02-21	1	piece
2CKA001751A3107	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - alpha	1785 JA/02-24G	1	piece
2CKA001751A3115	Mechanical Controls palladium	1785 JA/02-260	1	piece
2CKA001751A1831	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker bronze - alpha	1785 JA-21	1	piece
2CKA001751A2581	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker ivory - alpha	1785 JA-22G	1	piece
2CKA001751A2128	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker studio white - alpha	1785 JA-24G	1	piece
2CKA001751A2831	Rocker for Venetian blind, Two-part rocker palladium - alpha	1785 JA-260	1	piece
2CKA001751A2842	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker titanium - alpha	1785 JA-266	1	piece
2CKA001751A3139	Rocker for Switch/push button, Two-part rocker bronze - alpha	1785 K-21	1	piece
2CKA001751A3140	Rocker for Switch/push button, Two-part rocker ivory - alpha	1785 K-22G	1	piece
2CKA001751A3142	Rocker for Switch/push button, Two-part rocker studio white - alpha	1785 K-24G	1	piece
2CKA001751A3143	Rocker for Switch/push button, Two-part rocker palladium - alpha	1785 K-260	1	piece

2CKA001751A3144	Rocker for Switch/push button, Two-part rocker titanium - alpha	1785 K-266	1	piece
2CKA001751A1773	Rocker for Switch/push button, Two-part rocker bronze - alpha	1785-21	1	piece
2CKA001751A2706	Mechanical Controls Without imprint for Switch/push button, Two-part rocker bronze - alpha	1785-21-101	1	piece
2CKA001751A2565	Rocker for Switch/push button, Two-part rocker ivory - alpha	1785-22G	1	piece
2CKA001751A2110	Rocker for Switch/push button, Two-part rocker studio white - alpha	1785-24G	1	piece
2CKA001751A2827	Rocker for Switch/push button, Two-part rocker palladium - alpha	1785-260	1	piece
2CKA001751A3082	Mechanical Controls Without imprint for Switch/push button, Two-part rocker palladium - alpha	1785-260-500	1	piece
2CKA001751A2838	Rocker for Switch/push button, Two-part rocker titanium - alpha	1785-266	1	piece
2CKA001751A2722	Mechanical Controls Characters 0 and 1 for Switch/push button, Single rocker ivory - alpha	1786 IO-22G	1	piece
2CKA001751A3110	Rocker with legend Symbol "arrows" for Switch/push button, bronze - alpha	1786 JA/02-21	1	piece
2CKA001751A3106	Rocker for Venetian blind, Single rocker studio white - alpha	1786 JA/02-24G	1	piece
2CKA001751A3114	Rocker with legend Symbol "arrows" for Switch/push button, palladium - alpha	1786 JA/02-260	1	piece
2CKA001751A3086	Mechanical Controls Without imprint for Switch/push button, Single rocker bronze - alpha	1786-21-500	1	piece
2CKA001751A3081	Mechanical Controls Without imprint for Switch/push button, Single rocker ivory - alpha	1786-22G-500	1	piece
2CKA001751A3078	Mechanical Controls Without imprint for Switch/push button, Single rocker studio white - alpha	1786-24G-500	1	piece
2CKA001751A3080	Mechanical Controls Without imprint for Switch/push button, Single rocker palladium - alpha	1786-260-500	1	piece
2CKA001751A3085	Mechanical Controls Without imprint for Switch/push button, Single rocker titanium - alpha	1786-266-500	1	piece
2CKA001751A2052	Rocker for Switch/push button, Single rocker bronze - alpha	1787-21	1	piece
2CKA001751A2508	Rocker for Switch/push button, Single rocker ivory - alpha	1787-22G	1	piece
2CKA001751A2177	Rocker for Switch/push button, Single rocker studio white - alpha	1787-24G	1	piece
2CKA001751A2824	Rocker for Switch/push button, Single rocker palladium - alpha	1787-260	1	piece
2CKA001751A2835	Rocker for Switch/push button, Single rocker titanium - alpha	1787-266	1	piece
2CKA001751A1765	Rocker for Switch/push button, Single rocker bronze - alpha	1788-21	1	piece
2CKA001751A2557	Rocker for Switch/push button, Single rocker ivory - alpha	1788-22G	1	piece
2CKA001751A2326	Rocker for Switch/push button, Single rocker studio white - alpha	1788-24G	1	piece
2CKA001751A2823	Rocker for Switch/push button, Single rocker palladium - alpha	1788-260	1	piece
2CKA001751A2834	Rocker for Switch/push button, Single rocker titanium - alpha	1788-266	1	piece
2CKA001751A1781	Rocker with legend Heizung for Switch/push button, Single rocker bronze - alpha	1789 H-21	1	piece
2CKA001751A2573	Rocker with legend Heizung for Switch/push button, Single rocker ivory - alpha	1789 H-22G	1	piece
2CKA001751A2375	Rocker with legend Heizung for Switch/push button, Single rocker studio white - alpha	1789 H-24G	1	piece

2CKA001751A2826	Rocker with legend Heizung for Switch/push button, Single rocker palladium - alpha	1789 H-260	1	piece
2CKA001751A2837	Rocker with legend Heizung for Switch/push button, Single rocker titanium - alpha	1789 H-266	1	piece
2CKA001751A1732	Rocker for Switch/push button, Single rocker bronze - alpha	1789 KI-21	1	piece
2CKA001751A2524	Rocker with legend Symbol "bell" for Switch/push button, Single rocker ivory - alpha	1789 KI-22G	1	piece
2CKA001751A2235	Rocker with legend Symbol "bell" for Switch/push button, Single rocker studio white - alpha	1789 KI-24G	1	piece
2CKA001751A2829	Rocker with legend Symbol "bell" for Switch/push button, Single rocker palladium - alpha	1789 KI-260	1	piece
2CKA001751A2840	Rocker with legend Symbol "bell" for Switch/push button, Single rocker titanium - alpha	1789 KI-266	1	piece
2CKA001751A1724	Rocker with legend Symbol "light" for Switch/push button, Single rocker bronze - alpha	1789 LI-21	1	piece
2CKA001751A2516	Rocker with legend Symbol "light" for Switch/push button, Single rocker ivory - alpha	1789 LI-22G	1	piece
2CKA001751A2201	Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white - alpha	1789 LI-24G	1	piece
2CKA001751A2828	Rocker with legend Symbol "light" for Switch/push button, Single rocker palladium - alpha	1789 LI-260	1	piece
2CKA001751A2839	Rocker with legend Symbol "light" for Switch/push button, Single rocker titanium - alpha	1789 LI-266	1	piece
2CKA001751A1740	Rocker for Switch/push button, Single rocker bronze - alpha	1789 TR-21	1	piece
2CKA001751A2532	Rocker for Switch/push button, Single rocker ivory - alpha	1789 TR-22G	1	piece
2CKA001751A2268	Rocker for Switch/push button, Single rocker studio white - alpha	1789 TR-24G	1	piece
2CKA001751A2830	Rocker for Switch/push button, Single rocker palladium - alpha	1789 TR-260	1	piece
2CKA001751A2841	Rocker for Switch/push button, Single rocker titanium - alpha	1789 TR-266	1	piece
2CKA001751A1716	Rocker for Switch/push button, Single rocker bronze - alpha	1789-21	1	piece
2CKA001751A2490	Rocker for Switch/push button, Single rocker ivory - alpha	1789-22G	1	piece
2CKA001751A2102	Rocker for Switch/push button, Single rocker studio white - alpha	1789-24G	1	piece
2CKA001751A2825	Rocker for Switch/push button, Single rocker palladium - alpha	1789-260	1	piece
2CKA001751A2836	Rocker for Switch/push button, Single rocker titanium - alpha	1789-266	1	piece
2CKA001710A3294	Cover plate with legend Card for Switch/push button, Hotel card Hotel card bronze - alpha	1792-21-101	1	piece
2CKA001710A3295	Cover plate with legend Card for Switch/push button, Hotel card Hotel card ivory - alpha	1792-22G-101	1	piece
2CKA001710A3297	Cover plate with legend Card for Switch/push button, Hotel card Hotel card studio white - alpha	1792-24G-101	1	piece
2CKA001710A3305	Cover plate with legend Card for Switch/push button, Hotel card Hotel card palladium - alpha	1792-260-101	1	piece
2CKA001710A3331	Cover plate with legend Card for Switch/push button, Hotel card Hotel card titanium - alpha	1792-266-101	1	piece
2CKA001710A3685	Cover plate with legend for Thermostat Turn button bronze - alpha	1794 TA-21	1	piece
2CKA001710A3686	Cover plate with legend for Thermostat Turn button ivory - alpha	1794 TA-22G	1	piece
2CKA001710A3688	Cover plate with legend for Thermostat Turn button white - alpha	1794 TA-24G	1	piece
2CKA001710A3693	Cover plate with legend for Thermostat Turn button palladium - alpha	1794 TA-260	1	piece

2CKA001710A3694	Cover plate with legend for Thermostat Turn button titanium - alpha	1794 TA-266	1	piece
2CKA001710A3533	Cover plate with legend for Thermostat Turn button bronze - alpha	1794-21	1	piece
2CKA001710A3534	Cover plate with legend for Thermostat Turn button ivory - alpha	1794-22G	1	piece
2CKA001710A3536	Cover plate with legend for Thermostat Turn button white - alpha	1794-24G	1	piece
2CKA001710A3541	Cover plate with legend for Thermostat Turn button other - alpha	1794-260	1	piece
2CKA001710A3542	Cover plate with legend for Thermostat Turn button titanium - alpha	1794-266	1	piece
2CKA001710A3999	Cover plate with legend for Thermostat Turn button bronze - alpha	1795 HK-21	1	piece
2CKA001710A4000	Cover plate with legend for Thermostat Turn button ivory - alpha	1795 HK-22G	1	piece
2CKA001710A4002	Cover plate with legend for Thermostat Turn button white - alpha	1795 HK-24G	1	piece
2CKA001710A4003	Cover plate with legend for Thermostat Turn button other - alpha	1795 HK-260	1	piece
2CKA001710A4004	Cover plate with legend for Thermostat Turn button titanium - alpha	1795 HK-266	1	piece
2CKA001710A4031	Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha	1795 HKEA-21	1	piece
2CKA001710A4032	Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha	1795 HKEA-22G	1	piece
2CKA001710A4034	Cover plate with legend for Thermostat Turn button 1 sliding switch white - alpha	1795 HKEA-24G	1	piece
2CKA001710A4035	Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha	1795 HKEA-260	1	piece
2CKA001710A4036	Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha	1795 HKEA-266	1	piece
2CKA001710A3712	Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha	1795 TA-21	1	piece
2CKA001710A3713	Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha	1795 TA-22G	1	piece
2CKA001710A3715	Cover plate with legend for Thermostat Turn button 1 sliding switch white - alpha	1795 TA-24G	1	piece
2CKA001710A3720	Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha	1795 TA-260	1	piece
2CKA001710A3721	Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha	1795 TA-266	1	piece
2CKA001710A3558	Cover plate with legend for Thermostat Turn button 1 sliding switch bronze - alpha	1795-21	1	piece
2CKA001710A3559	Cover plate with legend for Thermostat Turn button 1 sliding switch ivory - alpha	1795-22G	1	piece
2CKA001710A3561	Cover plate with legend for Thermostat Turn button 1 sliding switch white - alpha	1795-24G	1	piece
2CKA001710A3566	Cover plate with legend for Thermostat Turn button 1 sliding switch palladium - alpha	1795-260	1	piece
2CKA001710A3567	Cover plate with legend for Thermostat Turn button 1 sliding switch titanium - alpha	1795-266	1	piece
2CKA001753A9186	Cover plate with labelling field Modular Jack 2 gang bronze - alpha	1800-21	1	piece
2CKA001710A2645	Cover plate with labelling field Modular Jack 2 gang ivory - alpha	1800-22G	1	piece
2CKA001710A2710	Cover plate with labelling field Modular Jack 2 gang studio white - alpha	1800-24G	1	piece
2CKA001710A3318	Cover Plate Modular Jack 2 gang palladium - alpha	1800-260	1	piece
2CKA001710A3344	Cover plate with labelling field Modular Jack 2 gang titanium - alpha	1800-266	1	piece

2CKA001753A8493	Cover Plate UAE/IAE (ISDN) 2 gang bronze - alpha	1803-02-21	1	piece
2CKA001710A2611	Cover Plate UAE/IAE (ISDN) 2 gang ivory - alpha	1803-02-22G	1	piece
2CKA001710A2033	Cover Plate UAE/IAE (ISDN) 2 gang studio white - alpha	1803-02-24G	1	piece
2CKA001710A3321	Cover Plate UAE/IAE (ISDN) 2 gang palladium - alpha	1803-02-260	1	piece
2CKA001710A3347	Cover Plate UAE/IAE (ISDN) 2 gang titanium - alpha	1803-02-266	1	piece
2CKA001753A8428	Cover Plate UAE/IAE (ISDN) 1 gang bronze - alpha	1803-21	1	piece
2CKA001710A2603	Cover Plate UAE/IAE (ISDN) 2 gang ivory - alpha	1803-22G	1	piece
2CKA001710A2025	Cover Plate UAE/IAE (ISDN) 1 gang studio white - alpha	1803-24G	1	piece
2CKA001710A3322	Cover Plate UAE/IAE (ISDN) 1 gang palladium - alpha	1803-260	1	piece
2CKA001710A3348	Cover Plate UAE/IAE (ISDN) 1 gang titanium - alpha	1803-266	1	piece
2CKA002011A6221	Socket Outlets bronze - alpha	20 EUC-21-500	1	piece
2CKA002011A6225	Socket Outlets ivory - alpha	20 EUC-22G-500	1	piece
2CKA002011A6223	Socket Outlets studio white - alpha	20 EUC-24G-500	1	piece
2CKA002011A6229	Socket Outlets palladium - alpha	20 EUC-260-500	1	piece
2CKA002011A6226	Socket Outlets titanium - alpha	20 EUC-266-500	1	piece
2CKA002013A4466	SCHUKO® socket insert Safety Shutter bronze - alpha	20 EUCKS-21	1	piece
2CKA002013A5240	Socket insert Safety Shutter ivory white - alpha	20 EUCKS-22G	1	piece
2CKA002013A5377	Socket Outlets studio white - alpha	20 EUCKS-24G-500	1	piece
2CKA002013A5252	Socket insert Safety Shutter palladium - alpha	20 EUCKS-260	1	piece
2CKA002013A5253	SCHUKO® socket insert Safety Shutter titanium - alpha	20 EUCKS-266	1	piece
2CKA002018A0703	SCHUKO® socket insert with Hinged Lid bronze - alpha	20 EUK-21	1	piece
2CKA002018A1446	Socket insert with Hinged Lid ivory white - alpha	20 EUK-22G	1	piece
2CKA002018A1040	SCHUKO® socket insert with Hinged Lid studio white - alpha	20 EUK-24G	1	piece
2CKA002018A1464	Socket insert with Hinged Lid palladium - alpha	20 EUK-260	1	piece
2CKA002018A1466	SCHUKO® socket insert with Hinged Lid titanium - alpha	20 EUK-266	1	piece
2CKA002017A0811	Socket insert bronze - alpha	20 MUC-21-500	1	piece
2CKA002017A0813	Socket with Earthing pin ivory white - alpha	20 MUC-22G-500	1	piece
2CKA002017A0815	Socket Outlets French norm NF studio white - alpha	20 MUC-24G-500	1	piece
2CKA002017A0817	Socket insert palladium - alpha	20 MUC-260-500	1	piece
2CKA002017A0818	Socket insert titanium - alpha	20 MUC-266-500	1	piece
2CKA002017A0828	Socket Outlets French norm NF ivory - alpha	20 MUCC-22G-500	1	piece
2CKA002017A0829	Socket insert studio white - alpha	20 MUCC-24G-500	1	piece
2CKA002017A0835	Socket Outlets French norm NF bronze - alpha	20 MUCKS-21-500	1	piece

2CKA002017A0802	Socket with Earthing pin Safety Shutter ivory white - alpha	20 MUCKS-22G-500	1	piece
2CKA002017A0803	Socket Outlets French norm NF studio white - alpha	20 MUCKS-24G-500	1	piece
2CKA002017A0804	Socket insert Safety Shutter palladium - alpha	20 MUCKS-260-500	1	piece
2CKA002017A0805	Socket insert Safety Shutter titanium - alpha	20 MUCKS-266-500	1	piece
2CKA002113A0505	Socket Outlets ivory - alpha	2300 UCRKS-22G-503	1	piece
2CKA002111A0623	Socket Outlets studio white - alpha	2300 UCRKS-24G-503	1	piece
2CKA002113A0508	Socket Outlets palladium - alpha	2300 UCRKS-260-503	1	piece
2CKA002113A0509	Socket Outlets titanium - alpha	2300 UCRKS-266-503	1	piece
2CKA002113A0041	Socket Outlets bronze - alpha	2300-01 UC-21-500	1	piece
2CKA002011A3820	Busch-Protector® SCHUKO® socket insert bronze - alpha	2310 EUGLVA-21-11	1	piece
2CKA002011A3821	Busch-Protector® SCHUKO® socket insert ivory white - alpha	2310 EUGLVA-22G-11	1	piece
2CKA002011A3823	Busch-Protector® SCHUKO® socket insert studio white - alpha	2310 EUGLVA-24G-11	1	piece
2CKA002011A3828	Busch-Protector® SCHUKO® socket insert palladium - alpha	2310 EUGLVA-260-11	1	piece
2CKA002011A3829	Busch-Protector® SCHUKO® socket insert titanium - alpha	2310 EUGLVA-266-11	1	piece
2CKA002099A0226	Socket Outlets bronze - alpha	2399 UCKS-21	1	piece
2CKA002099A0219	Socket Outlets ivory - alpha	2399 UCKS-22G	1	piece
2CKA002099A0220	Socket Outlets studio white - alpha	2399 UCKS-24G	1	piece
2CKA002099A0223	Socket Outlets palladium - alpha	2399 UCKS-260	1	piece
2CKA002099A0224	Socket Outlets titanium - alpha	2399 UCKS-266	1	piece
2CKA001710A3114	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button bronze - alpha	2542 DR/01-21	1	piece
2CKA001710A3115	Cover Plate Symbol "0-1-2-3" for Level switch, Turn button ivory - alpha	2542 DR/01-22G	1	piece
2CKA001710A3117	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button studio white - alpha	2542 DR/01-24G	1	piece
2CKA001710A3464	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button palladium - alpha	2542 DR/01-260	1	piece
2CKA001710A3466	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button titanium - alpha	2542 DR/01-266	1	piece
2CKA001710A3425	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button bronze - alpha	2542 DR/02-21	1	piece
2CKA001710A3426	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button ivory - alpha	2542 DR/02-22G	1	piece
2CKA001710A3428	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button studio white - alpha	2542 DR/02-24G	1	piece
2CKA001710A3465	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button palladium - alpha	2542 DR/02-260	1	piece
2CKA001710A3467	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button titanium - alpha	2542 DR/02-266	1	piece
2CKA001753A4054	Cover Plate Modular Jack 2 gang bronze - alpha	2561-02-21	1	piece
2CKA001710A2512	Cover Plate Modular Jack 2 gang ivory - alpha	2561-02-22G	1	piece
2CKA001753A7800	Cover Plate Modular Jack 2 gang studio white - alpha	2561-02-24G	1	piece

2CKA001710A3315	Cover Plate Modular Jack 2 gang palladium - alpha	2561-02-260	1	piece
2CKA001710A3341	Cover Plate Modular Jack 2 gang titanium - alpha	2561-02-266	1	piece
2CKA001753A3924	Cover Plate Modular Jack 1 gang bronze - alpha	2561-21	1	piece
2CKA001710A2504	Cover Plate Modular Jack 1 gang ivory - alpha	2561-22G	1	piece
2CKA001753A7776	Cover Plate Modular Jack 1 gang studio white - alpha	2561-24G	1	piece
2CKA001710A3314	Cover Plate Modular Jack 1 gang palladium - alpha	2561-260	1	piece
2CKA001710A3340	Cover Plate Modular Jack 1 gang titanium - alpha	2561-266	1	piece
2CKA002122A0028	Busch-NEMA Socket insert studio white - alpha 3016 EUC-24G		1	piece
2CKA006115A0477	6108/61-21-500 Coverplate f. CE	6108/61-21-500	1	piece
2CKA006115A0478	6108/61-22G-500 Coverplate f. CE	6108/61-22G-500	1	piece
2CKA006115A0480	6108/61-24G-500 Coverplate f. CE	6108/61-24G-500	1	piece
2CKA006115A0481	6108/61-260-500 Coverplate f. CE	6108/61-260-500	1	piece
2CKA006115A0482	6108/61-266-500 Coverplate f. CE	6108/61-266-500	1	piece
2CKA006155A0054	6109/03-21-500 Coverplate f. RTC	6109/03-21-500	1	piece
2CKA006155A0055	6109/03-22G-500 Coverplate f. RTC	6109/03-22G-500	1	piece
2CKA006155A0057	6109/03-24G-500 Coverplate f. RTC	6109/03-24G-500	1	piece
2CKA006155A0058	6109/03-260-500 Coverplate f. RTC	6109/03-260-500	1	piece
2CKA006155A0059	6109/03-266-500 Coverplate f. RTC	6109/03-266-500	1	piece
2CKA006430A0320	Control Element for Venetian blind Single push button bronze - alpha	6430-21-102	1	piece
2CKA006430A0321	Control Element for Venetian blind Single push button ivory - alpha	6430-22G-102	1	piece
2CKA006430A0323	Control Element for Venetian blind Single push button studio white - alpha	6430-24G-102	1	piece
2CKA006430A0317	Control Element for Venetian blind Single push button palladium - alpha	6430-260-102	1	piece
2CKA006430A0318	Control Element for Venetian blind Single push button titanium - alpha	6430-266-102	1	piece
2CKA006430A0292	Cover plate with legend for Time switch bronze - alpha	6435-21	1	piece
2CKA006430A0293	Cover plate with legend for Time switch ivory - alpha	6435-22G	1	piece
2CKA006430A0295	Cover plate with legend for Time switch studio white - alpha	6435-24G	1	piece
2CKA006430A0289	Cover plate with legend for Time switch palladium - alpha	6435-260	1	piece
2CKA006430A0290	Cover plate with legend for Time switch titanium - alpha	6435-266	1	piece
2CKA006599A1490	Cover Plate for Dimmer Turn button bronze - alpha	6540-21	1	piece
2CKA006599A2324	Cover Plate for Dimmer Turn button studio white - alpha	6540-24G	1	piece
2CKA006599A2852	Cover Plate for Dimmer Turn button palladium - alpha	6540-260	1	piece
2CKA006599A2855	Cover Plate for Dimmer Turn button titanium - alpha	6540-266	1	piece
2CKA006599A1524	Cover Plate for Cooling Central cover plate bronze - alpha	6541-21	1	piece

2CKA006599A2795	Cover Plate for Cooling Central cover plate ivory - alpha	6541-22G	1	piece
2CKA006599A2332	Cover Plate for Cooling Central cover plate studio white - alpha	6541-24G	1	piece
2CKA006599A2853	Cover Plate for Cooling Central cover plate palladium - alpha	6541-260	1	piece
2CKA006599A2856	Cover Plate for Cooling Central cover plate titanium - alpha	6541-266	1	piece
2CKA006599A2821	Control Element for Switch/dimmer Single push button with Neon lamp bronze - alpha	6543-21-102	1	piece
2CKA006599A2822	Control Element for Switch/dimmer Single push button with Neon lamp ivory - alpha	6543-22G-102	1	piece
2CKA006599A2824	Control Element for Switch/dimmer Single push button with Neon lamp studio white - alpha	6543-24G-102	1	piece
2CKA006599A2869	Control Element for Switch/dimmer Single push button with Neon lamp palladium - alpha	6543-260-102	1	piece
2CKA006599A2870	Control Element for Switch/dimmer Single push button with Neon lamp titanium - alpha	6543-266-102	1	piece
2CKA006599A2891	Control Element for Dimmer Two-part button with Neon lamp bronze - alpha	6545-21	1	piece
2CKA006599A2892	Control Element for Dimmer Two-part button with Neon lamp ivory - alpha	6545-22G	1	piece
2CKA006599A2894	Control Element for Dimmer Two-part button with Neon lamp studio white - alpha	6545-24G	1	piece
2CKA006599A2899	Control Element for Dimmer Two-part button with Neon lamp palladium - alpha	6545-260	1	piece
2CKA006599A2900	Control Element for Dimmer Two-part button with Neon lamp titanium - alpha	6545-266	1	piece
2CKA008200A0094	Cover Plate Loudspeaker bronze - alpha	8253-21	1	piece
2CKA008200A0095	Cover Plate Loudspeaker ivory white - alpha	8253-22G	1	piece
2CKA008200A0097	Cover Plate Loudspeaker studio white - alpha	8253-24G	1	piece

Catégories

Produits basse tension → Wiring Accessories - Light Switch Ranges → Frames

